

[Manuals.plus](#) /

› [Timex](#) /

› Timex Men's TW4B08100 Expedition Acadia Watch User Manual

Timex TW4B08100

Timex Expedition Acadia Watch User Manual

Model: TW4B08100

INTRODUCTION

This manual provides instructions for the Timex Men's TW4B08100 Expedition Acadia watch. This rugged and reliable timepiece is designed for outdoor use, featuring a durable resin case, a comfortable leather/nylon strap, and a 50-meter water resistance rating. Key features include a date window and the Indiglo night-light for visibility in low-light conditions.



Image: Front view of the Timex Expedition Acadia watch, showcasing the black dial, white numerals, and black leather/nylon strap.

SETUP

Setting the Time

1. **Pull the crown out** to the furthest position (position 3).
2. **Rotate the crown** in either direction to move the hour and minute hands until the correct time is displayed.
3. **Push the crown back in** to its original position (position 1) to start the watch.

Setting the Date

1. **Pull the crown out** to the middle position (position 2).
2. **Rotate the crown** clockwise or counter-clockwise (depending on the movement) until the correct date appears in the date window.
3. **Push the crown back in** to its original position (position 1).



Image: Side view of the watch, highlighting the crown used for time and date adjustments.

OPERATING INSTRUCTIONS

Indiglo Night-Light

To activate the Indiglo night-light, **press and hold the crown in**. The entire dial will illuminate for easy reading in low-light conditions. Release the crown to turn off the light.

Water Resistance

This watch is water resistant to 50 meters (165 feet). This means it is suitable for recreational swimming in shallow water. It is **not suitable for diving or snorkeling**. To maintain water resistance, ensure the crown is fully pushed in before any contact with water. Do not operate the crown while the watch is wet or submerged.

Your browser does not support the video tag.

Video: An overview of the Timex Expedition watch series, including features like Indiglo backlight, quick-date, and 50-meter water resistance. This video is provided by Timex Corporation.

MAINTENANCE

Battery Replacement

The watch uses one Lithium Metal battery (CR2016). When the watch stops running, the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Cleaning

- For the watch case, wipe with a soft, damp cloth. Avoid harsh chemicals.
- For the leather/nylon strap, clean with a mild soap solution and a soft brush, then rinse thoroughly and allow to air dry completely. Avoid prolonged exposure to direct sunlight or extreme heat.



Image: Close-up view of the watch's black leather and nylon strap with the buckle, illustrating the material and construction.

TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed in. If it still does not run, the battery may need replacement.
- **Indiglo not working:** Check if the crown is fully pushed in. If the light does not activate, the battery may be low or depleted.
- **Date not changing:** Ensure the time is set correctly past midnight for the date to advance. If the date is stuck, try resetting it manually.

For persistent issues, contact Timex customer support or a certified watch repair center.

SPECIFICATIONS

Model Name	Expedition Acadia
Model Number	TW4B08100
Case Material	Resin
Strap Material	Fabric (Leather/Nylon)
Dial Color	Black
Case Diameter	40 Millimeters
Case Thickness	11.5 Millimeters
Band Width	20 Millimeters
Water Resistance Depth	50 Meters (165 Feet)
Movement Type	Quartz
Battery Type	1 Lithium Metal (CR2016)
Crystal Material	Acrylic
Additional Features	Arabic Numerals, Glow In The Dark (Indiglo), Second Hand, Date Window

Your browser does not support the video tag.

Video: A guide to Timex watch sizing, demonstrating how different case sizes appear on various wrist sizes. This video is provided by Timex Corporation.

WARRANTY AND SUPPORT

This Timex watch is covered by a manufacturer's warranty. For detailed warranty information, service, or additional support, please refer to the official Timex website or contact their customer service directly. Keep your purchase receipt as proof of purchase. [Visit the official Timex website for more information.](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question