

[Manuals.plus](#) /

› [Schleich](#) /

› Schleich 72105 Horse Club Large Riding School with Pick-up and Trailer Instruction Manual

## Schleich 72105

# Schleich 72105 Horse Club Large Riding School with Pick-up and Trailer Instruction Manual

### PRODUCT OVERVIEW

---

The Schleich 72105 Horse Club Large Riding School with Pick-up and Trailer is a comprehensive playset designed for imaginative play. It includes a detailed riding school, a pick-up truck, and a horse trailer, allowing for various equestrian scenarios and adventures. This set encourages creative storytelling and role-playing.



Image: The complete Schleich 72105 Horse Club Large Riding School with Pick-up and Trailer playset.

## SAFETY INFORMATION

**WARNING:** This product is not suitable for children under three years of age. It contains small parts that may be swallowed, posing a choking hazard. Adult supervision is recommended during play.

## WHAT'S IN THE BOX

The Schleich 72105 playset includes the following components:

- 1 x Podium with roof
- 1 x Door
- 21 x Fence sections
- 1 x Trakehner stallion figure
- 1 x Red jumping rider figure
- 1 x Jumping saddle
- 2 x Bridles
- 1 x Tournament rider figure

- 1 x Competition saddle
- 1 x Blue jump obstacle
- 1 x Red jump obstacle
- 1 x Green jump obstacle
- 1 x Wall jump obstacle
- 1 x Ditch jump with flowers
- 4 x Large flags
- 2 x Small flags
- 2 x Box trees
- 1 x Trophy
- 1 x Silver medal
- 1 x Yellow ribbon
- 1 x Red winner's ribbon
- 1 x Purple winner's ribbon
- 1 x Flower crown
- 2 x Sticker sheets
- 7 x Jump numbers
- 1 x Pick-up truck
- 1 x Driver figure
- 1 x Horse trailer
- 1 x Friesian mare figure
- 1 x Groom figure
- 1 x Blanket
- 1 x Halter
- 1 x Carrot accessory
- 1 x Black grooming brush
- 1 x Blue curry comb
- 1 x Saddle
- 1 x Bridle
- 2 x Hay bales

## **ASSEMBLY INSTRUCTIONS**

---

The Schleich 72105 playset requires assembly. Please follow these general guidelines for construction:

1. Unpack all components carefully and verify them against the 'What's in the Box' list.
2. Identify the main structural pieces for the riding school. Connect them securely, ensuring all tabs and slots align correctly.
3. Assemble the 21 fence sections to create the riding arena perimeter. Ensure they are stable and interlocked.
4. Attach any smaller accessories such as the podium, roof, and decorative elements to their designated positions.
5. Assemble the pick-up truck and horse trailer. Ensure all wheels are securely attached and the trailer can connect properly to the truck.
6. Place the horse figures, rider figures, and other accessories within the playset as desired to set up

your scene.

7. Before play, ensure all connections are stable and secure to prevent parts from detaching during use.



Image: An assembled Schleich Horse Club playset in use, showing the stable and horse trailer.

## OPERATING INSTRUCTIONS

This playset is designed for creative and imaginative play. Children can use the included figures, horses, pick-up truck, and trailer to simulate various equestrian activities. The riding school provides a central location for training and competitions, while the pick-up and trailer allow for transporting horses to different events or locations within their imaginative world.

- Arrange the fence sections to create different arena configurations.
- Position the jump obstacles for show jumping scenarios.
- Use the pick-up truck to tow the horse trailer, transporting horses and riders.
- Engage in role-playing with the rider and groom figures, caring for the horses and preparing for events.

## MAINTENANCE

To ensure the longevity and cleanliness of your Schleich playset, follow these maintenance tips:

- **Cleaning:** Wipe figures and playset components with a damp cloth and mild soap. Avoid using abrasive cleaners or harsh chemicals, as these can damage the paint or plastic.
- **Storage:** Store the playset in a dry, cool place away from direct sunlight. Prolonged exposure to sunlight can cause colors to fade and materials to degrade.
- **Inspection:** Periodically inspect all parts for any signs of wear, damage, or loose connections. Replace any damaged parts to maintain safety and playability.

## TROUBLESHOOTING

- **Missing Parts:** If you discover any components are missing upon unboxing, please refer to the

'Warranty and Support' section to contact Schleich customer service for assistance.

- **Assembly Difficulties:** If you encounter difficulties during assembly, re-examine the instructions and ensure all pieces are correctly oriented. Do not force parts together, as this may cause damage.
- **Damaged Parts:** In the event of a damaged part, discontinue use of the affected component and contact customer service for replacement options.

## SPECIFICATIONS

---

|                           |                           |
|---------------------------|---------------------------|
| <b>Brand</b>              | Schleich                  |
| <b>Model Number</b>       | 72105                     |
| <b>Product Dimensions</b> | 57 x 14 x 38 cm (Playset) |
| <b>Product Weight</b>     | 3.7 kg (8.16 lbs)         |
| <b>Material</b>           | Plastic                   |
| <b>Recommended Age</b>    | 5 - 12 years              |
| <b>Assembly Required</b>  | Yes                       |

## WARRANTY AND SUPPORT

---

This Schleich product comes with a **2-year manufacturer's warranty**. For warranty claims, inquiries about missing parts, or any other support needs, please contact Schleich customer service directly. It is advisable to retain your proof of purchase for warranty validation.

For further assistance, please visit the official Schleich website or contact their customer support channels.