

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BLACK+DECKER](#) /
- › [BLACK+DECKER 5-in-1 Steam Mop and Portable Steamer User Manual](#)

BLACK+DECKER HSMC1321

BLACK+DECKER 5-in-1 Steam Mop and Portable Steamer

MODEL: HSMC1321

Introduction

The BLACK+DECKER HSMC1321 5-in-1 Steam Mop and Portable Steamer is designed for versatile and efficient cleaning throughout your home. Its convertible mop-to-handheld design allows for seamless transitions between cleaning sealed floors and various surfaces like glass shower doors, countertops, and more. With a large capacity water tank, it's ready for use in just 20 seconds, providing a long cleaning cycle. The swiveling mop head ensures easy maneuverability around objects and into corners, while the smart select variable steam control allows for precise steam regulation for any task.





Image: The BLACK+DECKER 5-in-1 Steam Mop in its upright configuration.

Important Safety Instructions

- Read all instructions thoroughly before operating the appliance.
- Use only distilled water in the water tank to prevent mineral buildup and ensure optimal performance.
- Do not use the steam mop on unsealed hardwood floors or surfaces that are sensitive to heat or moisture.
- Keep the appliance and its cord out of reach of children and pets.
- Always unplug the steam mop when not in use and before performing any maintenance or cleaning.
- Do not direct steam at people, animals, or electrical appliances.

Package Contents

Verify that all items are present in your package before beginning assembly or operation.



1) 2-in-1 Steam Mop & Handheld Cleaner: The main unit that functions as both a floor mop and a portable steamer.



2) Steam Mop Pads: Reusable microfiber pads for floor cleaning. (Shown in accessory image)



1) Accessory Hose: Flexible hose for extended reach with handheld attachments.



1) Small Squeegee with Pad: Ideal for cleaning glass and smooth surfaces.



1) Small Detail Brush: For focused cleaning of small areas and crevices.



1) Grout Brush: Specifically designed for cleaning grout lines.



1) **Copper Brush:** For tougher, more abrasive cleaning tasks.


1) **Accessory Bag:** For convenient storage of all attachments.



Accessory hose



Small squeegee with pad



Microfiber mop pads



Detail brush



Copper brush



Grout brush

Image: A collection of the various accessories included with the steam mop.

Setup and First Use

1. **Assemble the Mop:** Insert the handle into the main steam unit until it clicks securely into place.
2. **Attach Mop Head:** Slide the mop head onto the bottom of the main unit until it locks.
3. **Fill Water Tank:** Open the water tank cap and fill the tank with distilled water. The tank has a capacity of 19.6 ounces (approximately 1.2 pounds). Close the cap securely.



Large Water Tank Capacity

Image: A hand filling the large capacity water tank of the steam mop.

4. **Attach Mop Pad:** Secure a clean microfiber mop pad to the bottom of the mop head using the hook-and-loop fasteners.
5. **Power On:** Plug the power cord into a grounded electrical outlet. The unit will be ready to produce steam in approximately 20 seconds.

Operating Instructions

Steam Mop Mode (for Floors)

Once the unit is heated, select the appropriate steam setting using the smart select variable steam control dial (e.g., for sealed hardwood, ceramic tile, or vinyl floors). Gently push the mop across the floor surface. The swiveling mop head allows for easy navigation around furniture and into tight spaces.



Maneuver Around Objects With Ease

Image: The steam mop easily maneuvering around objects on a floor.

Using steam and a microfiber pad, the steam mop is effective at killing up to 99% of germs on sealed hard surfaces without the need for cleaning chemicals.

**Kills up to
99% of Germs***



*Using steam and a microfiber pad on sealed hardwood, ceramic tile and vinyl floors against staphylococcus aureus, escherichia coli, and aspergillus terreus. No cleaning chemicals required.

Image: Steam being emitted from the mop head, illustrating its germ-killing capability.

Handheld Steamer Mode (for Surfaces)

To convert to handheld mode, detach the main steam unit from the mop handle and head. Attach the accessory hose or desired direct attachment (small detail brush, grout brush, copper brush, small squeegee with pad) to the handheld unit.



Convertible Mop-to-Handheld Design

Image: A user converting the steam mop into its portable handheld configuration.

Use the handheld steamer for deep cleaning various surfaces such as kitchen counters, bathroom tiles, glass shower doors, and even upholstery. The different brushes and squeegee allow for specialized cleaning tasks.

Versatile application

For cleaning all areas
of your house.



Image: The detail brush attachment being used to clean a countertop, demonstrating versatile application.



Image: A collage showcasing the various 5-in-1 cleaning applications of the steam mop.

Maintenance and Care

- **Cleaning Mop Pads:** The microfiber mop pads are washable. Remove them from the mop head and machine wash with similar colors. Do not use bleach or fabric softeners. Air dry or tumble dry on low.
- **Emptying Water Tank:** After each use, allow the unit to cool completely, then empty any remaining water from the tank.
- **Storing the Unit:** Store the steam mop in a cool, dry place. Ensure the power cord is neatly wrapped. The compact design allows for easy storage.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or not properly filled. Unit not heated sufficiently. Steam nozzles are clogged.	Refill water tank with distilled water. Allow 20 seconds for heating. Refer to maintenance for cleaning nozzles.
Water leaking from unit.	Water tank cap not securely closed. Mop pad not properly attached.	Ensure water tank cap is tightly sealed. Re-attach mop pad correctly.
Mop not gliding smoothly.	Mop pad is dirty or worn out.	Replace or clean the mop pad.

Product Specifications

Feature	Detail
Brand	BLACK+DECKER
Model Name	Steam Mop
Item Model Number	HSMC1321
Wattage	1300 watts
Item Weight	6 Pounds
Capacity (Water Tank)	19.6 ounces (approximately 1.2 Pounds)
Voltage	120 Volts
Product Dimensions	7"D x 12"W x 25"H
Special Feature	Portable, Lightweight, Steam Control, Compact Design
Surface Recommendation	Doors, Shower, Sealed Hardwood, Ceramic Tile, Vinyl Floors
Included Components	2-in-1 Steam Mop & Handheld cleaner, 2 Steam mop pads, Accessory Hose, Small squeegee with pad, Small detail brush, Grout brush, Copper brush, Accessory bag.

Warranty and Support


This BLACK+DECKER Steam Mop (Model HSMC1321) comes with a **2-year limited warranty**. For detailed warranty terms, conditions, and to register your product, please refer to the official BLACK+DECKER website or the full user manual.


For further assistance, technical support, or to order replacement parts and accessories, please visit the official BLACK+DECKER support page or contact their customer service. You can also download the complete user manual in PDF format for comprehensive information:

[Download Full User Manual \(PDF\)](#)

© 2024 BLACK+DECKER. All rights reserved.

Related Documents - HSMC1321

	<p>BLACK+DECKER Steam Mop Instruction Manual - HSMC1321 Series</p> <p>Official instruction manual for the BLACK+DECKER Steam Mop, detailing setup, operation, safety precautions, and maintenance for models HSMC1321, HSMC1351SG, HSMC1361SG, HSMC1361SGP, and HSMC13712SG. Find support at www.blackanddecker.com/instantanswers.</p>
	<p>BLACK+DECKER HGS011 Series Easy Garment Steamer Use and Care Manual</p> <p>Comprehensive guide for the BLACK+DECKER HGS011 Series Easy Garment Steamer, covering important safeguards, how to use, troubleshooting, cleaning, and care instructions.</p>
	<p>BLACK+DECKER Press & Steam 2-in-1 Iron & Steamer HGS500 User Manual</p> <p>Comprehensive user and care manual for the BLACK+DECKER Press & Steam 2-in-1 Iron & Steamer (Model HGS500). Includes safety instructions, operating procedures, attachment details, maintenance, troubleshooting, and product specifications.</p>
	<p>BLACK+DECKER HGS500 Press & Steam 2-in-1 Iron & Steamer: Use and Care Manual</p> <p>Comprehensive guide for the BLACK+DECKER HGS500 Press & Steam 2-in-1 Iron & Steamer, covering essential safety instructions, usage guidelines, attachment details, care and maintenance, and troubleshooting tips.</p>
	<p>BLACK+DECKER Advanced Handheld Steamer HGS350 User Manual</p> <p>Comprehensive use and care manual for the BLACK+DECKER HGS350 Advanced Handheld Steamer. Learn about safety instructions, operation, cleaning, and troubleshooting.</p>



[BLACK+DECKER HGS011 Series Easy Garment Steamer User Manual and Care Guide](#)

Comprehensive guide for the BLACK+DECKER HGS011 Series Easy Garment Steamer, covering important safety precautions, setup, usage, troubleshooting, cleaning, and warranty information.