Kichler 42993SNLED

Kichler 42993SNLED Moderne LED Chandelier Instruction Manual

Model: 42993SNLED

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler 42993SNLED Moderne 2-Light LED Chandelier Oval Pendant. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Safety Information

Observe the following safety precautions to prevent injury or damage to the fixture.

- Always turn off the main power supply at the circuit breaker before installing, servicing, or cleaning the fixture.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.
- The fixture is designed for indoor use only.
- Ensure the mounting surface can support the weight of the fixture (approximately 23.6 pounds).
- Do not connect this fixture to an ungrounded electrical system.

Package Contents

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact Kichler customer service.

- Kichler 42993SNLED Moderne LED Chandelier Fixture
- Mounting Hardware (e.g., screws, wire nuts, canopy)
- Installation Guide (this manual)



Image: Front view of the Kichler 42993SNLED Moderne LED Chandelier, showcasing its oval shape and satin nickel finish with integrated LED lighting.

Specifications

Feature	Detail

Feature	Detail
Brand	Kichler
Model Number	42993SNLED
Style	Moderne, Contemporary
Finish	Satin Nickel
Material	Metal, Glass
Light Source Type	Integrated LED
Number of Lights	2
Color Temperature	3000 Kelvin
Brightness	2525 Lumens
Wattage	60 Watts (total)
Voltage	120 Volts
Product Dimensions	16.25"L x 16.25"W x 34.25"H
Item Weight	23.6 Pounds
Installation Type	Semi Flush Mount / Pendant
Safety Rating	ETL Listed, Damp Location Rated

Setup and Installation

This fixture requires assembly. Professional installation is recommended. Ensure power is OFF at the circuit breaker before proceeding with any installation steps.

Tools Required (Not Included)

- Screwdriver (Phillips and Flathead)
- Wire Strippers
- Pliers
- Electrical Tape
- Ladder
- Safety Glasses

Installation Steps

1. **Prepare for Installation:** Turn off electricity at the main fuse box or circuit breaker. Clear the work area and ensure you have all necessary tools and components.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the junction box in the ceiling using the provided screws. Ensure it is firmly attached and capable of supporting the fixture's weight.



Image: A close-up view of the chandelier's canopy, showing the suspension wires and mounting points. This illustrates how the fixture connects to the ceiling.

3. **Wiring Connections:**
    - Connect the fixture's ground wire (bare copper or green) to the house ground wire.
    - Connect the fixture's hot wire (black or smooth) to the house hot wire (black).
    - Connect the fixture's neutral wire (white or ribbed) to the house neutral wire (white).
    - Secure all connections with wire nuts and electrical tape, ensuring no bare wires are exposed.



Image: A detailed view of the chandelier's ceiling canopy, highlighting the electrical connections and the secure attachment points for the suspension cables.

4. **Fixture Assembly and Hanging:** Carefully attach the chandelier body to the mounting bracket, ensuring all wires are tucked safely into the junction box. Adjust the suspension cables to the desired height for the pendant.



Image: Underside view of the Kichler Moderne Chandelier, revealing the arrangement of the satin nickel panels and the integrated LED light sources.

5. **Final Check:** Ensure all connections are secure and the fixture is stable. Restore power at the circuit breaker.

Operating Instructions

The Kichler 42993SNLED Moderne LED Chandelier is designed for simple operation.

- **Power On/Off:** Control the fixture using a standard wall switch (not included). The fixture is designed to respond to a push-button or touch control method, typically integrated into the wall switch.
- **Light Output:** The integrated LED lights provide a consistent 3000 Kelvin white light with 2525 lumens of brightness. This fixture is generally not designed for dimming unless explicitly stated by the manufacturer and used with compatible LED dimmers.



Image: The Kichler Moderne LED Chandelier installed in a room, demonstrating its ambient lighting effect and modern aesthetic.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your Kichler chandelier.

- **Cleaning:** Turn off power before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LED Care:** The integrated LED components are designed for long life and are not user-replaceable. If the LEDs fail, contact Kichler customer service for assistance.
- **Inspection:** Periodically check all electrical connections and mounting hardware for tightness and signs of wear.

Troubleshooting

If your Kichler chandelier is not functioning correctly, refer to the following common issues and solutions.

1. **Light Does Not Turn On:**
    - Ensure the power supply at the circuit breaker is ON.
    - Check the wall switch for proper operation.
    - Verify all wiring connections are secure.
    - If the issue persists, contact a qualified electrician.
2. **Flickering Lights:**

- Ensure all electrical connections are tight.
- If using a dimmer, ensure it is specifically rated as LED-compatible. This fixture is generally not designed for dimming unless explicitly stated.
- Consult an electrician if flickering continues.

3. **Fixture Appears Loose:**
    - Turn off power at the circuit breaker.
    - Carefully re-tighten mounting screws and check suspension cables for proper adjustment and security.

Warranty and Support

Kichler stands behind the quality of its products.

- **Warranty:** This Kichler fixture comes with a 1-year manufacturer's limited warranty. This warranty covers defects in materials and workmanship under normal use and service.
- **Customer Support:** For technical assistance, warranty claims, or replacement parts, please contact Kichler customer service.

Visit the official Kichler website for contact information:www.kichler.com

© 2023 Kichler. All rights reserved.