

Michael Kors MK8561

Michael Kors Lexington MK8561 Men's Watch Instruction Manual

Stainless Steel Bracelet Watch - Gunmetal/Rose Gold

1. PRODUCT OVERVIEW

The Michael Kors Lexington MK8561 is a sophisticated men's chronograph watch featuring a durable stainless steel bracelet and case with a distinctive gunmetal and rose gold finish. This timepiece combines classic design with modern functionality, suitable for various occasions.



Figure 1: Front view of the Michael Kors Lexington MK8561 watch, showcasing the gunmetal dial, rose gold accents, and chronograph subdials.

2. SETUP AND INITIAL USE

2.1 Unboxing

Your Michael Kors Lexington watch comes securely packaged in a branded box. Carefully remove the watch and any protective films.



Figure 2: The white Michael Kors watch box, indicating original packaging.

2.2 Adjusting the Bracelet

The stainless steel bracelet is designed for a comfortable fit. If the watch is too loose or too tight, it may require adjustment. This typically involves removing or adding links. It is recommended to have this adjustment performed by a professional jeweler to prevent damage to the bracelet or clasp.

2.3 Setting Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to its outermost position.
2. **Set the time:** Rotate the crown to move the hour and minute hands to the correct time. Ensure you set the correct AM/PM for the date change.
3. **Set the date:** Push the crown halfway back in. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.
4. **Push in the crown:** Once the time and date are set, push the crown fully back into its original position to start the watch and ensure water resistance.

3. OPERATING THE WATCH

3.1 Chronograph Function

The watch features three chronograph subdials for measuring elapsed time:

- **Top Subdial:** Measures minutes.
- **Bottom Subdial:** Measures seconds.
- **Right Subdial:** Displays 24-hour time.

To operate the chronograph:

1. **Start:** Press the top pusher button to start the chronograph.
2. **Stop/Pause:** Press the top pusher button again to stop or pause the chronograph.
3. **Reset:** Press the bottom pusher button to reset the chronograph hands to zero.





Figure 3: Side view of the watch, highlighting the crown and pusher buttons for time setting and chronograph operation.

3.2 Water Resistance

This watch is water-resistant up to 330 feet (10 ATM). It is suitable for swimming and snorkeling. However, it is not recommended for scuba diving or high-impact water sports. Always ensure the crown is fully pushed in before any water exposure.

4. CARE AND MAINTENANCE

4.1 Cleaning

To maintain the appearance of your watch, regularly clean the case and bracelet with a soft, damp cloth. For deeper cleaning of the stainless steel bracelet, a soft toothbrush with mild soap and water can be used, followed by thorough rinsing and drying. Avoid harsh chemicals or abrasive materials.

4.2 Battery Replacement

The watch is powered by a Lithium Metal battery (included). When the watch stops or the timekeeping becomes erratic, the battery may need replacement. It is recommended to have the battery replaced by a certified watch technician to ensure proper sealing and maintain water resistance.

4.3 Crystal Care

The watch features a scratch-resistant mineral crystal. While durable, it is not entirely impervious to scratches. Avoid contact with sharp or abrasive surfaces to preserve its clarity.

5. TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Date not changing:** Ensure the time is set correctly for AM/PM. Avoid setting the date between 9 PM and 3 AM.
- **Clasp opening unexpectedly:** Inspect the deployment clasp for any damage or debris. If issues persist, consult a jeweler for repair or adjustment.

6. SPECIFICATIONS

Feature	Detail
Model Number	MK8561
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	44 Millimeters
Band Width	22 Millimeters
Case Thickness	13 Millimeters
Water Resistance Depth	330 Feet (10 ATM)
Movement Type	Quartz
Crystal Type	Mineral
Closure Type	Deployment Clasp
Power Source	Battery Powered (1 Lithium Metal battery included)

7. WARRANTY AND SUPPORT

This Michael Kors watch comes with a manufacturer's warranty. For specific details regarding coverage, duration, and how to make a claim, please refer to the warranty information provided with your purchase or visit the official Michael Kors website. For additional support or service inquiries, please contact Michael Kors customer service.