

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jimmyjane](#) /

› [JIMMY JANE Intro 8 G-Spot Vibrator User Manual](#)

Jimmyjane JJ12492

JIMMY JANE Intro 8 G-Spot Vibrator User Manual

Model: JJ12492

1. INTRODUCTION

The JIMMY JANE Intro 8 is a sophisticated G-spot vibrator designed for dynamic stimulation. It features a flexible, curved neck specifically engineered for G-spot targeting, complemented by additional motors for comprehensive clitoral stimulation. This device incorporates three powerful motors, is fully waterproof, and made from body-safe silicone for a comfortable and hygienic experience.

Key Features:

- Designed for G-spot and clitoral stimulation.
- Engineered for maximum versatility.
- Simple and intuitive controls.
- Powerful yet quiet operation.
- Constructed from body-safe silicone.
- Waterproof and washable design.
- Operates with 3 speeds and 3 modes.






Figure 1: The JIMMY JANE Intro 8 G-Spot Vibrator shown in its retail packaging. The packaging highlights key features such as "Intro 8", "Flexible Rabbit Vibrator", "3 Speeds - 3 Modes", "Waterproof", "Body-Safe Silicone", and "Batteries Included". The device itself is visible through a clear window, showcasing its purple color and curved design.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions and warnings before using the JIMMY JANE Intro 8. Keep this manual for future reference.

- **For Adult Use Only:** This product is intended for adult use only.
- **Material Safety:** The device is made from body-safe silicone. If you experience any irritation or discomfort, discontinue use immediately.
- **Battery Safety:**
 - Do not mix old and new batteries.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Insert batteries with correct polarity (+ and -).
 - Remove batteries if the device will not be used for an extended period.
 - Dispose of batteries properly according to local regulations.
- **Cleaning:** Always clean the device before and after each use as instructed in the Maintenance section.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid storing with other silicone products that may react and cause damage.
- **Damage:** Do not use the device if the silicone appears damaged, bubbled, or warped. Contact customer support if you notice any defects.

3. SETUP AND BATTERY INSTALLATION

The JIMMY JANE Intro 8 requires 2 AAA batteries, which are included with the product.

1. **Locate the Battery Compartment:** Identify the battery cap, typically located at the base of the device.
2. **Open the Compartment:** Twist or pull the battery cap to open the compartment. Refer to the device's specific design for exact opening mechanism.
3. **Insert Batteries:** Insert 2 AAA batteries into the compartment, ensuring the positive (+) and negative (-) ends align correctly with the indicators inside the compartment.
4. **Close the Compartment:** Securely close the battery cap, ensuring it is tightly sealed to maintain the device's waterproof integrity.

Your Intro 8 is now ready for use.

4. OPERATING INSTRUCTIONS

The JIMMY JANE Intro 8 features simple and intuitive controls for a personalized experience.

Basic Operation:

- **Power On/Off:** Locate the power button, usually a single button on the device. Press and hold for a few seconds to turn the device on or off.
- **Change Speeds/Modes:** Once powered on, short presses of the power button will cycle through the 3 speeds and 3 distinct vibration modes. Experiment to find your preferred setting.

Usage Tips:

- Apply a water-based lubricant to the device and desired areas for enhanced comfort and sensation.
- The flexible, curved neck is designed to target the G-spot, while the additional "ears" with their own motors are intended for clitoral stimulation. Explore different angles and pressures to discover what feels best.
- The triple motor design provides powerful and varied sensations.

5. CARE AND MAINTENANCE

Proper care ensures the longevity and hygiene of your JIMMY JANE Intro 8.

Cleaning:

- The Intro 8 is fully waterproof and washable.
- Before and after each use, clean the device thoroughly with warm water and a mild, toy-safe soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.

Storage:

- Store the device in a clean, dry, and cool place.
- Avoid direct sunlight or extreme temperatures, which can degrade the silicone over time.
- Do not store the silicone device with products made of other materials (e.g., certain plastics, rubber, or other silicone types) as this can sometimes lead to material degradation, stickiness, or bubbling. Store separately or in a dedicated pouch.

6. TROUBLESHOOTING

If you encounter issues with your JIMMY JANE Intro 8, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA batteries, ensuring correct polarity. Ensure battery cap is securely closed.
Vibration is weak or inconsistent.	Low battery power.	Replace batteries with new AAA batteries.
Silicone appears bubbled, warped, or sticky.	Improper storage or reaction with other materials.	Ensure device is stored separately from other materials. If damage is significant, discontinue use and contact customer support.
Device makes unusual noises.	Internal component issue.	Discontinue use and contact customer support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Product Name	Vibromasseur G Spot Intro 8, Voilet (JIMMY JANE Intro 8 G-Spot Vibrator)
Model Number	JJ12492
Brand	Jimmyjane
Color	Violet
Material	Silicone
Dimensions (L x W x H)	7.62 x 7.62 x 20.32 cm (3 x 3 x 8 inches)

Feature	Detail
Weight	204.12 grams (approx. 0.45 lbs)
Power Source	2 x AAA Batteries (included)
Features	3 Powerful Motors, 3 Speeds, 3 Modes, Waterproof
Manufacturer	ABS Holdings
UPC	603912739855

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the original purchase documentation or contact the retailer/manufacturer directly.

You may also visit the official Jimmyjane website for further assistance: www.jimmyjane.com

