

[Manuals.plus](#) /

› [Kärcher](#) /

› Kärcher Universal Hard Floor Cleaner Concentrate User Manual

Kärcher 6.295-944.0

Kärcher Universal Hard Floor Cleaner Concentrate User Manual

Model: 6.295-944.0

1. PRODUCT OVERVIEW

The Kärcher Universal Hard Floor Cleaner Concentrate (Model 6.295-944.0) is a highly effective, multi-purpose cleaning solution designed for use with Kärcher Electric Hard Floor Cleaners, including models FC 3, FC 5, and FC 7. This concentrate provides optimal, streak-free cleaning and protection for a wide variety of hard floor surfaces, ensuring a brilliant shine and a pleasant lemon fragrance.

Its gentle, non-abrasive formula is suitable for sealed wood, vinyl, PVC, laminate, stone, and tile floors, offering moisture protection to guard against floor swelling. The concentrated formula ensures long-lasting use and efficient cleaning results.



Figure 1: Kärcher Universal Hard Floor Cleaner Concentrate bottle.

2. SETUP AND PREPARATION

Before using the Kärcher Universal Hard Floor Cleaner Concentrate, ensure your Kärcher Electric Hard Floor Cleaner is clean and ready for operation. Proper dilution of the concentrate is crucial for optimal cleaning performance and to prevent streaking.

2.1 Dilution Instructions

1. Locate the clean water tank on your Kärcher Electric Hard Floor Cleaner (e.g., FC 3, FC 5, FC 7).
2. Fill the clean water tank with fresh tap water up to the indicated fill line.
3. Add approximately **1/4 cap** of the Kärcher Universal Hard Floor Cleaner Concentrate to the full tank of water. Do not overfill or use more than the recommended amount, as this can lead to residue or streaking.
4. Securely close the clean water tank and reattach it to your Kärcher floor cleaner according to your device's specific instructions.

Note: Always refer to your specific Kärcher Electric Hard Floor Cleaner's user manual for detailed instructions on filling tanks and operating the device.

3. OPERATING INSTRUCTIONS

Once the concentrate is properly diluted and the clean water tank is installed, you can begin cleaning your hard floors. The Kärcher Universal Hard Floor Cleaner Concentrate is designed to work seamlessly with your Kärcher Electric Hard Floor Cleaner for efficient and effective cleaning.

3.1 Cleaning Process

1. Ensure your Kärcher Electric Hard Floor Cleaner is charged (if cordless) or plugged in.
2. Turn on the device. The rollers will begin to rotate and dispense the cleaning solution.
3. Guide the cleaner slowly and steadily across the hard floor surface. Allow the rotating rollers to do the work, picking up dirt and applying the cleaning solution.
4. For heavily soiled areas, you may need to pass over the area multiple times or allow the solution to sit for a moment before re-cleaning.
5. The dual-tank system of Kärcher cleaners ensures that fresh cleaning solution is always applied, while dirty water is collected into a separate tank, preventing the spread of grime.



Figure 2: Kärcher Electric Hard Floor Cleaner in operation, demonstrating effective cleaning.

The quick-drying formula allows floors to dry rapidly, typically within two minutes, minimizing disruption and allowing for immediate use of the cleaned area.

4. MAINTENANCE AND STORAGE

Proper maintenance of your Kärcher Electric Hard Floor Cleaner after using the concentrate is essential for its longevity and continued performance. The concentrate itself should be stored correctly.

4.1 After Each Use (for the Cleaner)

1. **Empty Dirty Water Tank:** After each cleaning session, remove and empty the dirty water tank. Rinse it thoroughly with clean water to remove any residue.
2. **Clean Rollers:** Most Kärcher Electric Hard Floor Cleaners feature a self-cleaning function or removable rollers. Utilize the self-cleaning function if available, or remove the rollers and rinse them under running water. For deeper cleaning, rollers can often be machine washed (refer to your cleaner's manual for specific instructions).
3. **Rinse Components:** Rinse any other removable components that came into contact with dirty water or solution.
4. **Dry Thoroughly:** Allow all components to air dry completely before reassembling or storing the cleaner to prevent mold or odors.



Figure 3: Kärcher Electric Hard Floor Cleaner in its parking station, ready for self-cleaning or storage.

4.2 Concentrate Storage

- Store the Kärcher Universal Hard Floor Cleaner Concentrate in its original sealed container.
- Keep it in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the cap is tightly closed to prevent evaporation or contamination.
- Keep out of reach of children and pets.

5. TROUBLESHOOTING

If you encounter issues while using the Kärcher Universal Hard Floor Cleaner Concentrate, consider the following common troubleshooting tips:

Problem	Possible Cause	Solution
Streaks on floor after cleaning.	<ul style="list-style-type: none">• Incorrect concentrate dilution (too much concentrate).• Dirty rollers or dirty water tank.• Floor not thoroughly dried.	<ul style="list-style-type: none">• Ensure correct 1/4 cap dilution per full tank of water.• Clean rollers and empty/rinse dirty water tank after each use.• Allow the machine to properly dry the floor.

Problem	Possible Cause	Solution
Poor cleaning performance.	<ul style="list-style-type: none">• Insufficient concentrate.• Heavily soiled floor requiring multiple passes.• Rollers are worn or clogged.	<ul style="list-style-type: none">• Verify concentrate amount (1/4 cap).• Make additional passes over stubborn dirt.• Clean or replace rollers as needed.
Unpleasant odor from cleaner.	<ul style="list-style-type: none">• Dirty water left in tank.• Rollers not cleaned or dried properly.	<ul style="list-style-type: none">• Always empty and rinse dirty water tank immediately after use.• Clean and thoroughly dry rollers and all removable parts.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Product Name	Kärcher Floor Cleaner Concentrate for All Hard Floors, Universal
Model Number	6.295-944.0
Item Form	Liquid Concentrate
Volume	16.9 Fluid Ounces (500 ml)
Scent	Lemon
Suitable For	All hard floors (Wood, Vinyl, PVC, Laminate, Stone, Tile)
Compatibility	Kärcher Electric Hard Floor Cleaners (FC 3, FC 5, FC 7)
Country of Origin	Germany
Product Dimensions	2.56 x 2.56 x 8.27 inches
Item Weight	1.1 pounds

7. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or any other inquiries, please contact Kärcher Customer Service. You can find contact details and additional resources on the official Kärcher website or through your local Kärcher distributor.

Always use genuine Kärcher accessories and cleaning solutions to ensure optimal performance and to maintain your product's warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01NBNBZH5>

More documents and user manuals: <https://manuals.plus/>