

Home Zone 64321 Mark 1

Home Zone Mark 1 Outdoor LED Flood Security Light

Model: 64321 Mark 1

INTRODUCTION

Thank you for purchasing the Home Zone Mark 1 Outdoor LED Flood Security Light. This product is designed to provide bright, energy-efficient illumination and enhanced security for your outdoor spaces. Featuring a super bright LED light, a 180-degree motion sensor, and adjustable detection range, this floodlight offers reliable performance. Please read this manual thoroughly before installation and operation to ensure proper use and longevity of your device.

SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of electric shock, fire, or injury:

- **Outdoor Use Only:** This product is designed exclusively for outdoor applications. Do not install indoors.
- **Electrical Safety:** Installation must be performed by a qualified electrician or in accordance with local electrical codes. Ensure power is turned off at the circuit breaker before installation or servicing.
- **Voltage:** Operate only on a 120 Volts AC circuit.
- **Mounting:** Securely mount the fixture to a stable surface to prevent it from falling.
- **Heat:** The LED light heads may become warm during operation. Avoid direct contact.
- **Cleaning:** Do not use abrasive cleaners or solvents on the light fixture. Clean with a soft, damp cloth.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Home Zone Mark 1 Outdoor LED Flood Security Light (with integrated bulbs)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

SETUP AND INSTALLATION

This floodlight is designed for wall mount installation. Ensure the mounting surface is sturdy and capable of supporting the fixture's weight.



Image shows the product packaging for the Home Zone Mark 1 Outdoor LED Flood Security Light. The box highlights key features such as 'SECURITY MOTION ACTIVATED LED LIGHT', '22 yr Long-life LED', '2137 Lumens', '30.6 Watts', '180° DETECTION', and 'MOTION ACTIVATED OR MANUAL OVERRIDE'. The light itself, with two adjustable LED heads and a motion sensor, is prominently displayed on the front of the box.

Mounting

1. Turn off power at the circuit breaker before starting installation.
2. Attach the mounting plate to the electrical junction box using the provided screws.
3. Ensure the mounting plate is level and securely fastened.

Wiring

1. Connect the black wire from the fixture to the black (live) wire from the junction box using a wire nut.
2. Connect the white wire from the fixture to the white (neutral) wire from the junction box using a wire nut.
3. Connect the green (ground) wire from the fixture to the bare copper (ground) wire from the junction box using a wire nut.
4. Carefully tuck all wires into the junction box.
5. Align the fixture with the mounting plate and secure it with the provided screws.
6. Adjust the angle of the two LED light heads and the motion sensor to cover the desired area.
7. Restore power at the circuit breaker.

OPERATING INSTRUCTIONS

Motion Sensor Operation

The integrated motion sensor detects movement within a 180-degree field and up to 32.8 feet forward range. The light will automatically turn on when motion is detected and turn off after a set duration if no further motion is sensed.

Timer Control & Lux Sensor

The light features a timer control to adjust how long the light stays on after motion detection. It also includes a Lux sensor (photocell) that prevents the light from activating during daylight hours, saving energy. Adjust these settings according to your preference using the controls on the fixture.

Manual Override Function

The floodlight includes a manual override function, allowing the light to be continuously turned on regardless of motion detection or ambient light. To activate this mode, quickly turn the light switch OFF and then ON within 2 seconds. The light will remain on until the switch is turned OFF again. To return to automatic mode, turn the light OFF for at least 2 minutes, then turn it back ON.

MAINTENANCE

The Home Zone Mark 1 LED Flood Security Light requires minimal maintenance. Follow these guidelines for optimal performance:

- **Cleaning:** Periodically clean the light fixture and motion sensor lens with a soft, damp cloth to remove dirt, dust, or debris that may obstruct the sensor or reduce light output. Do not use harsh chemicals or abrasive materials.
- **LEDs:** The integrated LED bulbs are designed for long life (22 years). They are not user-replaceable. If the LEDs fail, the entire fixture may need replacement.
- **Inspection:** Regularly inspect the wiring and mounting for any signs of wear, damage, or loosening. Address any issues promptly.

TROUBLESHOOTING

If you experience issues with your Home Zone Mark 1 Flood Security Light, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power; Sensor obstructed; Incorrect Lux setting; Manual override active.	Check circuit breaker; Clear sensor lens; Adjust Lux setting; Turn light OFF for 2 minutes then ON to reset.
Light stays on continuously.	Manual override active; Constant motion detected; Wiring issue.	Turn light OFF for 2 minutes then ON to reset; Adjust sensor sensitivity or position; Consult a qualified electrician.
Light flashes or flickers.	Loose wiring; Power fluctuations; Faulty unit.	Check all wire connections; Ensure stable power supply; Contact customer support if problem persists.
Motion sensor range is poor.	Sensor obstructed; Incorrect angle; Environmental factors.	Clear sensor lens; Adjust sensor angle; Consider ambient temperature or large objects blocking detection.

SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	Home Zone
Model Name	Mark 1
Part Number	64321
Light Source Type	LED
Brightness	2200 Lumen (2137 Lumens)
Wattage	25 Watts (30.6 Watts)
Color Temperature	5600 Kelvin
Voltage	120 Volts
Motion Detection Angle	180 degrees
Motion Detection Range	Up to 32.8 feet
Material	Aluminum (Fixture), Plastic (Shade)
Installation Type	Wall Mount
Dimensions	9 x 9 x 7 inches
Item Weight	1.2 Pounds
Special Feature	Dawn-To-Dusk, Motion Sensor, Manual Override

WARRANTY AND SUPPORT

This Home Zone Mark 1 Outdoor LED Flood Security Light is covered by a **5 Year Limited Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or general inquiries, please visit the official Home Zone website or contact their customer service department. Refer to the product packaging or the Home Zone website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question