

[Manuals.plus](#) /

> [Spin Master](#) /

> Spin Master Hatchimal Draggie Electronic Pet Instruction Manual

## Spin Master Draggie

# Spin Master Hatchimal Draggie Instruction Manual

Model: Draggie

## INTRODUCTION

Welcome to the world of Hatchimals! Your Hatchimal Draggie is an interactive electronic pet that lives inside an egg. This manual will guide you through the exciting process of hatching your new friend and raising it through its various developmental stages.

Each Hatchimal is a unique companion that requires your care and interaction to hatch and grow. From hearing its heartbeat to encouraging it to peck its way out of the egg, your involvement is crucial for its development.

Once hatched, your Hatchimal Draggie will progress through three stages: Baby, Toddler, and Kid. You will teach it to walk, talk, dance, and play games, fostering a bond as it grows.

## SETUP

### Unboxing Your Hatchimal

Carefully remove the Hatchimal egg from its packaging. Ensure all components, including the instruction booklet and reference guide, are present. The Hatchimal comes with 2 AA batteries pre-installed.





Image: A child holding the Hatchimal egg, ready for interaction.

### **Initial Interaction (In-Egg Stage)**

Before hatching, your Hatchimal will respond to your touch and sound. Hold the egg to hear its heartbeat. Flip it gently for fun reactions. Tap on the egg, and it will tap back. These interactions help prepare your Hatchimal for

hatching.

## OPERATING YOUR HATCHIMAL

### Hatching Process

When your Hatchimal is ready to hatch, you will see rainbow-colored eyes glowing from inside the egg. This indicates it needs your help. Continue to encourage it with your touch. The Hatchimal will begin to peck its way out of the egg. This process can take some time and requires your continued interaction.



Image: A Hatchimal actively pecking its way out of the egg.

### Raising Your Hatchimal (Post-Hatch)

Once hatched, your Hatchimal will enter its first stage of development. You will need to nurture it to help it grow through three stages: Baby, Toddler, and Kid. Each stage unlocks new interactions and games.



Image: Two hatched Hatchimal Draggle pets, showcasing their appearance.

- **Baby Stage:** Your Hatchimal will need feeding, comforting, and basic care. Its eyes will indicate its needs.
- **Toddler Stage:** Your Hatchimal will learn to walk and talk. Guide it by holding its head or tapping its back. It will repeat words you say.
- **Kid Stage:** Your Hatchimal can now dance, play games, and interact more complexly. Refer to the included reference guide for a full list of games and interactions.

## MAINTENANCE

### Cleaning

To clean your Hatchimal, gently wipe its surface with a soft, dry cloth. Do not use water or cleaning solutions, as this can damage the electronic components.

### Battery Replacement

Your Hatchimal requires 2 AA batteries. When the Hatchimal's responses become sluggish or it stops responding, it may be time to replace the batteries. Use a small screwdriver to open the battery compartment located on the underside of the Hatchimal. Replace with new AA batteries, ensuring correct polarity, and securely close the

compartment.

## Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage. Store your Hatchimal in a cool, dry place away from direct sunlight.

## TROUBLESHOOTING

- **Hatchimal not hatching:** Ensure you are consistently interacting with the egg (holding, tapping, flipping). If rainbow eyes are visible, continue to encourage it.
- **Hatchimal not responding:** Check the batteries. Replace them if they are low or depleted. Ensure there is no debris obstructing sensors or moving parts.
- **Hatchimal not moving/talking:** This may indicate low batteries or a need for a reset. Try replacing batteries first. If issues persist, refer to the manufacturer's support.
- **Resetting your Hatchimal:** If your Hatchimal is unresponsive, you can try turning it off and on again using the power switch (if available) or temporarily removing and reinserting the batteries.

For persistent issues, please contact Spin Master customer support.

## SPECIFICATIONS

Feature	Detail
Model	Draggle
Manufacturer	Spin Master
ASIN	B01NCKIM3K
Batteries	2 AA batteries (included)
Item Weight	1.75 pounds
Package Dimensions	10.1 x 8.2 x 5.8 inches
Date First Available	December 10, 2016

## WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official Spin Master website or contact their customer service department. Keep your proof of purchase for warranty claims.

**Manufacturer:** Spin Master

**Website:** [www.spinmaster.com](http://www.spinmaster.com) (Please note: This is a placeholder link as the actual support link was not provided in the product data.)



