

Casio MTP-V301D-1AUDF (A1320)

Casio Enticer Analog Watch User Manual

Model: MTP-V301D-1AUDF (A1320)

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Casio Enticer Analog Watch, Model MTP-V301D-1AUDF (A1320). Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

2. PRODUCT OVERVIEW

The Casio Enticer MTP-V301D-1AUDF (A1320) is an analog watch featuring a black dial, a stainless steel band, and multiple sub-dials for day, date, and 24-hour time display. It is designed for everyday wear and offers reliable timekeeping.




Figure 2.1: Front view of the Casio Enticer Analog Watch MTP-V301D-1AUDF (A1320). The watch features a round black dial with silver hour markers and hands, three sub-dials for day, date, and 24-hour format, and a silver-toned stainless steel bracelet. The crown is visible on the right side of the watch case.

2.1 Dial Components

- **Main Dial:** Displays hours, minutes, and seconds.
- **Day Sub-dial:** Located at the 9 o'clock position, indicates the day of the week (e.g., SUN, MON, TUE).
- **Date Sub-dial:** Located at the 6 o'clock position, indicates the date of the month (1-31).
- **24-Hour Sub-dial:** Located at the 3 o'clock position, indicates the current hour in a 24-hour format.
- **Crown:** Used for setting time and date.

3. SETUP

3.1 Setting the Time

1. Pull the crown out to the **second click** position. The second hand will stop.
2. Rotate the crown to move the hour and minute hands to the desired time. Ensure the 24-hour sub-dial also reflects the correct AM/PM (or 24-hour) setting.
3. Push the crown back in to the normal position. The second hand will resume movement.

3.2 Setting the Date and Day

1. Pull the crown out to the **first click** position.
2. Rotate the crown *clockwise* to adjust the date.
3. Rotate the crown *counter-clockwise* to adjust the day of the week.
4. Once the date and day are set, push the crown back in to the normal position.

Note: Avoid setting the date and day between 9:00 PM and 4:00 AM, as this may interfere with the automatic date change mechanism. If you need to set the date during this period, first advance the time past 4:00 AM, then set the date, and finally reset the time.

4. OPERATING INSTRUCTIONS

Once the time, date, and day are set, your watch will operate continuously. The quartz movement ensures accurate timekeeping.

4.1 Water Resistance

This watch has a water resistance depth of 30 meters. This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, diving, or showering.

- Do not operate the crown while the watch is wet.
- Avoid exposing the watch to hot water or steam.

5. MAINTENANCE

5.1 Cleaning

- Wipe the watch case and band periodically with a soft, dry cloth to remove dirt and moisture.
- For stainless steel bands, a soft brush with mild soapy water can be used, followed by thorough rinsing and drying. Ensure the watch is water-resistant before using water.
- Avoid using chemical cleaners or abrasive materials.

5.2 Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the second hand begins to move in two-second intervals, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to prevent damage to the watch's internal components and to ensure water resistance is maintained.

5.3 Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs erratically.	Low battery.	Replace battery (refer to Section 5.2).
Date/Day does not change at midnight.	Time is set incorrectly (AM/PM).	Adjust time, ensuring the 24-hour sub-dial is correct.

Problem	Possible Cause	Solution
Condensation inside the watch.	Exposure to extreme temperature changes or moisture ingress.	Consult a qualified watch technician immediately.

If the problem persists after attempting the suggested solutions, please contact Casio customer support or an authorized service center.

7. SPECIFICATIONS

- **Model Number:** MTP-V301D-1AUDF (A1320)
- **Movement:** Quartz (Japanese Quartz)
- **Display Type:** Analog
- **Dial Color:** Black
- **Case Material:** Metal
- **Case Diameter:** 39.4 millimeters
- **Dial Glass Material:** Mineral
- **Band Material:** Stainless Steel
- **Band Color:** Silver
- **Clasp Type:** Fold-Over Clasp
- **Water Resistance Depth:** 30 meters
- **Item Weight:** 90 grams

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This product comes with a **2-year manufacturer warranty** on manufacturing defects. Please retain your purchase receipt as proof of purchase for warranty claims.

8.2 Customer Support

For further assistance, service, or warranty claims, please contact Casio customer support or visit an authorized Casio service center. Contact details can typically be found on the official Casio website or your product's warranty card.

Casio Official Website: www.casio.com

© 2024 Casio. All rights reserved.

	<p>Casio AQW-100, MTP-1298 Watch User Manual - Features, Settings, and Care</p> <p>Comprehensive user manual for Casio watches Module No. 5028, covering models AQW-100 and MTP-1298. Learn about timekeeping, alarms, stopwatch, water resistance, and maintenance.</p>
	<p>Casio LAW-21 Модуль 2789: Руководство пользователя и характеристики</p> <p>Полное руководство пользователя для часов Casio LAW-21 (Модуль 2789). Содержит инструкции по эксплуатации, уходу, описания режимов работы (текущее время, мировое время, таймер, секундомер, будильник) и технические характеристики.</p>
	<p>CASIO MTP-1326/1353 Watch User Manual - Module 5228</p> <p>Comprehensive user guide for the CASIO MTP-1326/1353 watch (Module 5228). Covers essential care, water resistance guidelines, setting time and date, using the rotating bezel, and technical specifications.</p>
	<p>Casio MTP-1369/1370, MTD-1076 Watch User Manual Module 5336/5337</p> <p>Detailed user manual for Casio MTP-1369/1370 and MTD-1076 watches, covering technical specifications, water resistance, time setting, maintenance, and care instructions for modules 5336 and 5337.</p>
	<p>CASIO 3502 Watch User Manual</p> <p>Comprehensive user manual for CASIO watches, model 3502. Learn about water resistance, setting time and date, alarms, stopwatch, timer, backlight, and proper care.</p>
	<p>Casio GW-600 Watch User Manual Module 2972/2973 Instructions</p> <p>Comprehensive user manual for the Casio GW-600 watch (Module 2972/2973). Learn about water resistance, world time, alarms, stopwatch, timer, solar charging, power saving, and maintenance.</p>