

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Qanba](#) /
- › [Qanba Dragon Joystick User Manual for PlayStation 4, PlayStation 3, and PC \(Model Q5-PS4-01\)](#)

Qanba Q5-PS4-01

Qanba Dragon Joystick User Manual

Model: Q5-PS4-01

Compatible with PlayStation 4, PlayStation 3, and PC

INTRODUCTION

The Qanba Dragon Joystick is a premium fighting stick designed for an authentic arcade experience. This officially licensed Sony product offers compatibility with PlayStation 4, PlayStation 3, and PC platforms via a wired USB connection. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Qanba Dragon Joystick.



Image: Top view of the Qanba Dragon Joystick, highlighting its sleek design, metallic joystick, and button layout, with the Qanba Dragon logo prominently displayed.

KEY FEATURES

- **Sanwa Components:** Equipped with high-quality Sanwa buttons and a Sanwa joystick with a square gate for precise and responsive control.
- **Multi-Platform Compatibility:** Fully compatible with PlayStation 4, PlayStation 3, and PC, supporting all video game titles on these platforms.
- **Durable Wired Connection:** Features a braided, wired USB cable for reliable and low-latency performance.
- **Integrated LED Lighting:** Subtle LED lighting enhances the aesthetic appeal of the joystick.
- **Premium Construction:** Boasts a stunning aluminum dragon scale interior and a robust, heavy-duty casing for durability and stability.

SETUP GUIDE

1. Connecting to PlayStation 4 or PlayStation 3

1. Ensure your PlayStation console is powered off or in standby mode.
2. Locate an available USB port on your PlayStation console.
3. Connect the braided USB cable from the Qanba Dragon Joystick to the USB port on your console.
4. Power on your PlayStation console. The joystick should be automatically recognized.
5. Select the appropriate platform mode (PS4 or PS3) using the mode switch located on the joystick's control panel. Refer to the diagram below for switch location.

2. Connecting to PC

1. Ensure your PC is powered on.
2. Locate an available USB port on your PC.
3. Connect the braided USB cable from the Qanba Dragon Joystick to the USB port on your PC.
4. The PC should automatically detect and install the necessary drivers. This may take a few moments.
5. Select the PC mode using the mode switch on the joystick's control panel.
6. For optimal performance, ensure your PC's operating system is up to date.



Image: Side view of the Qanba Dragon Arcade Joystick, illustrating the robust casing and the layout of the control panel, including the mode switch.

OPERATING INSTRUCTIONS

The Qanba Dragon Joystick is designed for intuitive use, replicating the classic arcade experience. Familiarize yourself with the primary controls:

- **Joystick:** The primary control for directional input. The Sanwa joystick provides precise movement for fighting games and other genres.
- **Action Buttons:** The large, responsive Sanwa buttons are arranged in a standard arcade layout for quick and accurate inputs.
- **System Buttons:** Dedicated buttons for PlayStation (PS button, Share, Options) and PC functions are located on the control panel.
- **LED Lighting:** The integrated LED lighting will illuminate upon connection, indicating power and operational status.

Mode Selection

A mode switch allows you to toggle between PS4, PS3, and PC compatibility. Ensure the correct mode is selected for your connected device to guarantee proper functionality.

Video Demonstration

Watch this official video for a visual overview of the Qanba Dragon Joystick's features and design.

Your browser does not support the video tag.

Video: An official merchant video showcasing the Qanba Dragon Joystick, highlighting its design, components, and overall build quality.

MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your Qanba Dragon Joystick.

Cleaning

- The joystick features a glossy surface that can attract fingerprints and smudges. Regularly wipe the surface with a soft, lint-free microfiber cloth.
- For stubborn marks, slightly dampen the cloth with water; avoid harsh chemicals or abrasive cleaners.
- Keep the joystick and buttons free from dust and debris. Use compressed air to clean crevices if necessary.

Internal Access and Modding

The Qanba Dragon Joystick is designed with easy access levers, allowing the top panel to hinge upward. This provides convenient access to the internal components for cleaning, maintenance, or customization (modding). Exercise caution when accessing internal components to avoid damage.



Image: The Qanba Dragon Joystick with its top panel opened, showcasing the organized internal wiring and high-quality Sanwa components, designed for easy access and maintenance.

TROUBLESHOOTING

If you encounter issues with your Qanba Dragon Joystick, refer to the following common solutions:

Problem	Possible Cause	Solution
Joystick not recognized by console/PC	Incorrect mode selected, loose USB connection, driver issue (PC)	Ensure the mode switch is set to the correct platform (PS4/PS3/PC). Disconnect and reconnect the USB cable. Try a different USB port. For PC, check Device Manager for driver status.

Problem	Possible Cause	Solution
Buttons or joystick unresponsive	Internal connection issue, debris under buttons, software conflict	Test the joystick on another device if possible. Open the top panel (refer to Maintenance section) to check for loose connections or obstructions. Ensure no other input devices are causing conflicts.
LED lighting is dim or not working	Power issue, internal LED connection	Ensure the joystick is properly powered via the USB connection. If the issue persists, it may indicate an internal component issue.
Input lag or delayed response	USB port issue, system performance, cable damage	Try connecting to a different USB port, preferably a direct port on the motherboard for PCs. Ensure your console/PC is not under heavy load. Inspect the USB cable for any visible damage.

If these steps do not resolve your issue, please contact Qanba customer support for further assistance.

SPECIFICATIONS

- **Model Number:** Q5-PS4-01
- **Compatibility:** PlayStation 4, PlayStation 3, PC
- **Connectivity:** Wired USB
- **Dimensions (L x W x H):** Approximately 20 x 12.5 x 5 inches
- **Weight:** Approximately 11.6 pounds (5.26 kg)
- **Components:** Sanwa Denshi Joystick and Buttons
- **Special Features:** LED Lighting, Easy Access Panel for Modding/Maintenance
- **Release Date:** February 1, 2016
- **Manufacturer:** Qanba

WARRANTY AND SUPPORT

The Qanba Dragon Joystick is an officially licensed Sony product, ensuring quality and reliability. For specific warranty details, please refer to the documentation included with your purchase or visit the official Qanba website. For technical support, troubleshooting assistance beyond this manual, or inquiries regarding parts and service, please contact Qanba customer support directly.

Qanba Support Information: Please refer to the Qanba official website or product packaging for the most current contact details.