

[Manuals.plus](#) /

› [DICKIE TOYS](#) /

› DICKIE TOYS - Large Action Fire Fighter Vehicle Instruction Manual

DICKIE TOYS 203308371

DICKIE TOYS - Large Action Fire Fighter Vehicle

Instruction Manual

Brand: DICKIE TOYS | Model: 203308371

PRODUCT OVERVIEW

The Dickie Toys Large Action Fire Fighter Vehicle is a meticulously designed toy fire engine, approximately 15 inches in length, offering an immersive play experience. It features realistic light and sound effects, a freewheel mechanism for smooth movement, and a manually operated water pump for interactive play. The vehicle also includes opening side panels that reveal typical fire engine accessories, providing a detailed insight into emergency vehicle operations. This rescue vehicle is suitable for children aged three years and over.



Front view of the Dickie Toys Large Action Fire Fighter Vehicle, showcasing its detailed design and illuminated lights.

SETUP

Battery Installation

The fire fighter vehicle requires 2 AA batteries for its light and sound functions. These batteries are included with the product. The battery compartment is located on the underside of the vehicle. Use a small screwdriver to open the compartment, insert the batteries according to the polarity indicators, and securely close the cover.



The underside of the fire truck, where the battery compartment is located for installing the 2 AA batteries.

Water Tank Filling

To utilize the water spraying function, fill the integrated water tank. The water inlet is located on the bottom of the vehicle. Carefully pour clean water into the tank. Ensure the tank is not overfilled to prevent leaks.

OPERATING INSTRUCTIONS

Freewheel Movement

The vehicle is equipped with a freewheel mechanism, allowing it to be pushed and rolled smoothly across various surfaces for dynamic play.

Light and Sound Effects

Activate the realistic light and sound effects by pressing the designated buttons on the vehicle. These features enhance the play experience by simulating an authentic fire engine.



The fire truck with its emergency lights activated, providing realistic visual effects during play.

Water Spray Function

To spray water, ensure the water tank is filled. Locate the manual pump button, typically a yellow knob, on the top of the vehicle. Press this button repeatedly to activate the pump and spray water from the nozzle located at the end of the telescopic ladder. Be aware that water will be expelled during this operation.



The fire truck actively spraying water from its extended ladder, demonstrating its functional water pump.

Telescopic Ladder Operation

The vehicle features a telescopic ladder with a swiveling arm. Manually extend and retract the ladder to simulate rescue operations. The ladder can also be swiveled to different angles for versatile play scenarios.



The fire truck with its telescopic ladder fully extended, ready for simulated rescue missions.

Opening Side Panels

The side panels of the fire engine can be opened to reveal detailed compartments and accessories, providing an enhanced realistic play experience.

MAINTENANCE

- **Cleaning:** Wipe the vehicle with a damp cloth to remove dust and dirt. Do not immerse the vehicle in water, especially the electronic components.
- **Water Tank:** After use, empty any remaining water from the tank to prevent mold or mildew buildup. Allow the tank to air dry.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.
- **Storage:** Store the vehicle in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights and sounds not working.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AA batteries.
Water pump not spraying.	Water tank empty or pump mechanism clogged.	Ensure water tank is filled. Check for any obstructions in the pump or nozzle.
Ladder not extending/retracting smoothly.	Debris or minor misalignment.	Inspect the ladder mechanism for any foreign objects. Gently adjust alignment if necessary.

SPECIFICATIONS

Product Dimensions: 17.91 x 6.1 x 9.45 inches

Item Weight: 1.1 pounds

ASIN: B06VSL5HN1

Item Model Number: 203308371

Manufacturer Recommended Age: 3 years and up

Batteries: 2 AA batteries required (included)

Release Date: July 24, 2017

Manufacturer: DICNS

WARRANTY AND SUPPORT

For information regarding product warranty or technical support, please contact the manufacturer, DICKIE TOYS, directly. Refer to the product packaging or the official DICKIE TOYS website for contact details and further assistance.

Warning: CHOKING HAZARD -- small parts. Not for children under 3 yrs.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question