

[Manuals.plus](#) /

> [Yamazaki](#) /

> Yamazaki 3295 One-Handed Cut Under Cabinet Kitchen Paper Holder Manual

Yamazaki 3295

Yamazaki 3295 One-Handed Cut Under Cabinet Kitchen Paper Holder Manual

INTRODUCTION

This manual provides instructions for the Yamazaki 3295 One-Handed Cut Under Cabinet Kitchen Paper Holder. This product is designed for convenient, one-handed dispensing and cutting of kitchen paper rolls, installing easily under your kitchen cabinet. Please read these instructions carefully before installation and use to ensure proper function and safety.

SETUP INSTRUCTIONS

The Yamazaki 3295 kitchen paper holder is designed for simple installation under a cabinet or shelf.

Package Contents:

- Main unit (steel, powder coated)
- Anti-slip rings x2

Installation Steps:

1. Identify a suitable location under a cabinet or shelf. The shelf thickness should be approximately 1.5 to 2.5 cm.
2. Slide the holder onto the cabinet shelf.
3. Tighten the screw mechanism to secure the holder firmly in place. Ensure the holder is stable and does not wobble.



Image: Close-up of the screw mechanism for securing the holder.

4. Insert a kitchen paper roll onto the holder's rod. Ensure the roll diameter is within 11 cm, height within 24 cm, and core diameter is 3.6 cm or more.
5. Place the anti-slip rings (if desired) onto the rod to help secure the paper roll and aid in cutting.



Image: The paper holder fully installed with a kitchen paper roll.

OPERATING INSTRUCTIONS

This holder allows for easy, one-handed dispensing and cutting of kitchen paper.

1. Pull the desired length of kitchen paper downwards. The design of the holder allows the paper to be held in place for cutting.



Image: Pulling kitchen paper from the holder.

2. With one hand, firmly pull the paper against the cutting edge to tear it. After cutting, the remaining paper will be positioned for the next use.



Image: Tearing kitchen paper with one hand.

MAINTENANCE

To ensure the longevity and hygiene of your kitchen paper holder, follow these simple maintenance guidelines:

- Clean the holder regularly with a soft, damp cloth.
- Avoid using abrasive cleaners or scouring pads, as these may damage the powder-coated finish.
- Ensure the holder is dry after cleaning to prevent water spots.
- Periodically check the securing screw for tightness to maintain stability.

TROUBLESHOOTING

Paper Roll Does Not Fit:

Ensure your kitchen paper roll meets the specified dimensions: diameter within 11 cm, height within 24 cm, and core diameter 3.6 cm or more. Some larger or thicker paper rolls, particularly those from certain international brands, may not fit.

Difficulty Cutting Paper:

Ensure the paper roll is properly seated on the holder. Verify that the anti-slip rings are correctly positioned to provide tension for cutting. If the paper is very thin or tears unevenly, try adjusting the angle or force when pulling to cut.

Holder is Not Stable:

Tighten the securing screw firmly against the cabinet shelf. Ensure the shelf thickness is within the recommended range of 1.5 to 2.5 cm. If the holder still moves, ensure the anti-slip rings are in place on the clamping mechanism.

PRODUCT SPECIFICATIONS



Image: Product dimensions diagram.

Dimension (W x D x H)	Approx. 8 x 26 x 17.5 cm
Material	Steel (powder coated)
Weight	0.3 kg

Load Capacity	500g
Compatible Shelf Thickness	1.5 to 2.5 cm
Compatible Paper Roll Size	Diameter within 11 cm, Height within 24 cm, Core diameter 3.6 cm or more
Color	White
Model Number	3295
Manufacturer	Yamazaki
Country of Origin	China

WARRANTY INFORMATION

Specific warranty details for the Yamazaki 3295 Kitchen Paper Holder are not provided in the product information. Please refer to the retailer's return policy or contact Yamazaki customer support for warranty inquiries.

CUSTOMER SUPPORT

For further assistance or inquiries regarding your Yamazaki 3295 Kitchen Paper Holder, please contact your point of purchase or visit the official Yamazaki website for support resources.