

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Schildmeyer](#) /
- › [Schildmeyer Milan 134885 Base Cabinet Instruction Manual](#)

## Schildmeyer 134885

# Schildmeyer Milan 134885 Base Cabinet Instruction Manual

Model: 134885

## INTRODUCTION

Welcome to the instruction manual for your **Schildmeyer Milan 134885 Base Cabinet**. This document provides essential information for the safe assembly, proper use, and effective maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference. Adhering to these guidelines will ensure the longevity and optimal performance of your cabinet.

## SAFETY INSTRUCTIONS

Please observe the following safety guidelines during assembly and use:

- Keep all small parts, such as screws and dowels, out of reach of children to prevent choking hazards.
- Use appropriate tools for assembly. Ensure all connections are tightened securely, but do not overtighten.
- Assemble the cabinet on a clean, soft surface (e.g., a carpet or blanket) to prevent scratches.
- Do not overload shelves or drawers. Refer to the specifications for weight limits.
- For stability, it is recommended to anchor the cabinet to a wall, especially if children are present. Wall anchoring hardware may not be included and should be selected based on your wall type.
- Always lift the cabinet when moving it; do not drag it, as this can damage the feet or structure.

## PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact your retailer.

- Cabinet panels (top, bottom, sides, back)
- 1 x Door with soft-close hinges
- 2 x Drawers (fronts, sides, backs, bottoms)

- 1 x Adjustable shelf
- 2 x Metal handles with industrial design screw heads
- Drawer runners
- Plastic feet
- Assembly hardware (screws, dowels, cam locks, etc.)

## ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. Two people are recommended for easier and safer assembly.

1. **Preparation:** Unpack all components and lay them out on a soft, clean surface. Identify each part using the provided diagrams (if available). Ensure you have a screwdriver (Phillips head) and a hammer.
2. **Attach Feet:** Secure the plastic feet to the bottom panel of the cabinet using the provided screws.
3. **Assemble Cabinet Frame:** Connect the side panels to the bottom panel using dowels and cam locks/screws. Then, attach the top panel to complete the basic frame. Ensure all connections are tight and the frame is square.
4. **Install Drawer Runners:** Attach the drawer runners to the inner sides of the cabinet frame according to the pre-drilled holes. Ensure they are level and correctly oriented.
5. **Assemble Drawers:** Construct the two drawers by connecting the front, side, and back panels. Slide the drawer bottom into the grooves. Attach the remaining parts of the drawer runners to the sides of the assembled drawers.
6. **Insert Shelf:** Place the adjustable shelf into the desired position using the shelf pins.
7. **Attach Door:** Secure the soft-close hinges to the door. Then, attach the door to the cabinet frame. The door stop can be chosen during assembly (left or right opening).
8. **Install Handles:** Attach the metal handles to the drawer fronts and the door using the provided screws.
9. **Adjustments:** After full assembly, check the alignment of the door and drawers. Adjust hinges and runners as necessary to ensure smooth operation and proper closure.



Image: The Schildmeyer Milan 134885 Base Cabinet with its door open revealing an internal shelf, and two drawers pulled out, showcasing the internal storage and metal handles.

## OPERATING INSTRUCTIONS

Your Schildmeyer Milan 134885 Base Cabinet is designed for practical storage. Here are some operational

guidelines:

- **Door Operation:** The cabinet features a soft-close door. Gently push the door to close it, and the mechanism will ensure a quiet and smooth closing action.
- **Drawer Operation:** The two drawers operate on smooth runners. Pull them out gently to access contents and push them in fully to close.
- **Shelf Adjustment:** The internal shelf is adjustable. To change its height, remove any items, lift the shelf, remove the shelf pins, reposition them to the desired height, and then replace the shelf.
- **Weight Distribution:** Distribute weight evenly across shelves and within drawers. Avoid placing excessively heavy items on the top surface or in a single drawer to maintain stability.





Image: A front view of the Schildmeyer Milan 134885 Base Cabinet, highlighting its two drawers and single door with industrial-style metal handles and a country house oak decor finish.

## MAINTENANCE AND CARE

To ensure your Schildmeyer Milan 134885 Base Cabinet remains in excellent condition, follow these care instructions:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaning agent. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the tactile surface finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage, especially on the wood decor surfaces.
- **Hardware:** Periodically check all screws, bolts, and fittings to ensure they are tight. Retighten if necessary to maintain stability.
- **Environment:** Avoid placing the cabinet in direct sunlight or near heat sources, as this can cause discoloration or warping over time. Maintain a stable room temperature and humidity.
- **Handles:** Clean metal handles with a soft, dry cloth. Avoid using abrasive cleaners that could scratch the finish.



# MADE IN GERMANY

Image: A close-up view of the metal handle and the tactile country house oak decor surface of the Schildmeyer Milan 134885 Base Cabinet, showing the texture and industrial design details.

## TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Door Not Closing Properly:** Check the hinge adjustments. Most hinges have screws that allow for vertical,

horizontal, and depth adjustments. Refer to the hinge manufacturer's instructions or gently adjust screws until the door aligns and closes smoothly.

- **Drawers Sticking or Not Sliding Smoothly:** Ensure the drawer runners are correctly installed and aligned. Check for any obstructions in the runners. Verify that the drawer box itself is assembled squarely.
- **Cabinet Feels Wobbly:** Ensure all assembly screws and cam locks are fully tightened. Check that the plastic feet are level on the floor. If necessary, use shims under the feet to stabilize the cabinet on uneven surfaces. Consider wall anchoring for added stability.
- **Scratches or Minor Damage:** For minor scratches on the wood decor, touch-up pens or furniture repair kits designed for laminate surfaces can be used.

## SPECIFICATIONS

Feature	Detail
Model Number	134885
Brand	Schildmeyer
Dimensions (W x D x H)	40.3 cm x 32 cm x 94.8 cm
Weight	17 Kilograms
Color/Finish	Country House Oak Decor (Tactile Surface)
Material	Melamine-coated particle board (body and front), Metal (handles, runners, hardware), Plastic (feet)
Storage	1 soft-close door, 2 drawers, 1 adjustable shelf
Assembly Required	Yes



94.8cm

32cm

40.3cm



