Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hasbro Gaming B10011020

Hasbro Elefun & Friends Hungry Hungry Hippos Grab & Go Game Instruction Manual

Model: B10011020

1. About the Game

The Hasbro Elefun & Friends Hungry Hungry Hippos Grab & Go Game is a compact, portable version of the classic marble-chomping game. Designed for quick setup and play, it's perfect for travel and on-the-go entertainment. Players control their hungry hippos, aiming to gobble up as many marbles as possible.

Image: Front view of the Hungry Hungry Hippos Grab & Go game box, showing the game unit and characters.

2. Safety Information

WARNING: This game contains small parts (marbles) and is not suitable for children under 3 years due to choking hazard. Recommended for ages 4 and up.
Always supervise young children during play. Keep marbles away from infants and toddlers.

3. Package Contents

- 1 x Hungry Hungry Hippos Grab & Go Game Unit
- Marbles (various colors, typically yellow and red)
- Instruction Guide (this document)

Image: The Hungry Hungry Hippos Grab & Go game unit, showing the hippos and marbles within the playing area.

4. Setup

1. **Unpack the Game:** Carefully remove the game unit and marbles from the packaging.
2. **Prepare the Marbles:** Place all the marbles into the central playing area of the game unit. Ensure they are evenly distributed.
3. **Position Players:** Each player should sit in front of one of the hippo levers. The game supports up to 4 players.

5. Operating (How to Play)

The objective of Hungry Hungry Hippos is to make your hippo eat the most marbles. The yellow marble is typically worth more points, or it can be used as a tie-breaker.

Gameplay Instructions:

1. **Start the Game:** On the count of three, all players simultaneously press their hippo's tail lever repeatedly. This will make their hippo's head extend and retract, attempting to "eat" the marbles.
2. **Eat Marbles:** Continue pressing the lever as fast as possible to make your hippo gobble up marbles. The marbles will fall into a collection area beneath each hippo.
3. **End of Round:** The round ends when all marbles have been eaten from the central playing area.
4. **Count Marbles:** Each player counts the marbles collected by their hippo. The player with the most marbles wins the round. If a special marble (e.g., yellow) is designated as a bonus, that player might win automatically or receive extra points.

5. **Repeat:** To play another round, simply return all marbles to the center and begin again.

6. Maintenance

Cleaning:

- Wipe the game unit with a soft, damp cloth.
- Do not submerge the game in water.
- Avoid using harsh chemicals or abrasive cleaners.

Storage:

- Ensure all marbles are collected and stored securely within the game unit's designated storage compartment (if available) or in a small bag.
- Store the game in its original box or a clean, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

- **Hippo not eating marbles:** Ensure the lever is being pressed fully and rapidly. Check for any obstructions in the hippo's mouth or path.
- **Marbles getting stuck:** Gently shake the game unit to redistribute marbles. Ensure the game is on a flat, stable surface.
- **Missing marbles:** Check all collection areas and around the game unit. Replacement marbles may be available from the manufacturer or general toy stores.

8. Specifications

Product Name	Hasbro Elefun & Friends Hungry Hungry Hippos Grab & Go Game
Model Number	B10011020
Brand	Hasbro Gaming
Product Dimensions	4.8 x 15.9 x 23.5 cm
Weight	180 g
Recommended Age	4 years and up
Number of Players	Up to 4
Assembly Required	No
Batteries Required	No
Material	Plastic
Color	Multicolour
First Available Date	20 March 2017

Image: Diagram illustrating the compact dimensions of the Hungry Hungry Hippos Grab & Go game unit.

9. Warranty Information

Specific warranty details for the Hasbro Elefun & Friends Hungry Hungry Hippos Grab & Go Game are typically provided within the product packaging or on the official Hasbro Gaming website. Please refer to the documentation included with your purchase for the most accurate and up-to-date warranty information.

10. Support

For further assistance, questions, or to report any issues with your Hasbro Elefun & Friends Hungry Hungry Hippos Grab & Go Game, please contact Hasbro Gaming customer support through their official channels.

- **Official Website:** Visit the Hasbro official website for product information and support contacts.
- **Brand Store:** Explore other Hasbro Gaming products at theHasbro Gaming Store on Amazon.

© 2024 Hasbro. All Rights Reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06W521R3X

More documents and user manuals: **https://manuals.plus/**