

[manuals.plus](#) /

› [WMF](#) /

› [WMF Impulse Insulated Thermos Flask 1.0 L Instruction Manual](#)

WMF Impulse 690697390

WMF Impulse Insulated Thermos Flask 1.0 L Instruction Manual

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your WMF Impulse Insulated Thermos Flask. This 1.0 L flask is designed to maintain the temperature of hot or cold beverages for extended periods, featuring a pressure closure for convenient pouring.



Figure 1: WMF Impulse Insulated Thermos Flask, black, 1.0 L capacity.

2. SAFETY INSTRUCTIONS

- Do not use for carbonated beverages, as pressure buildup may cause the lid to eject forcefully.
- Keep out of reach of children when filled with hot liquids.
- Handle the glass insert with care, as it is fragile. Avoid dropping or subjecting the flask to strong impacts.
- Ensure the lid is securely closed before transporting to prevent spills.
- Do not place the flask in a microwave oven or conventional oven.
- Do not immerse the entire flask in water for cleaning; refer to the 'Maintenance and Cleaning' section.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1x WMF Impulse Insulated Thermos Flask (1.0 L capacity)
- 1x Lid with automatic pressure closure

- 1x Glass insert (pre-installed)



Figure 2: Product packaging.

4. SETUP (FIRST USE)

Before first use, thoroughly clean the flask and its components.

1. Unscrew and remove the lid from the flask.
2. Wash the flask interior and lid with warm water and a mild detergent. Rinse thoroughly.
3. Allow all parts to air dry completely before reassembling.






Figure 3: Removing the lid for cleaning or filling.

5. OPERATING INSTRUCTIONS

5.1 Filling the Flask

1. Remove the lid.
2. Pour your desired hot or cold beverage into the flask. Do not overfill; leave a small space below the rim.
3. For optimal temperature retention, pre-warm the flask with hot water for hot beverages or pre-chill with cold water for cold beverages before filling.

5.2 Closing the Lid

1. Place the lid back onto the flask and screw it on clockwise until it is securely tightened.
2. The pressure closure mechanism is activated by a central button.



Figure 4: Activating the pressure closure by pressing the central button.

5.3 Pouring

1. To pour, press the central button on the lid. This opens the pouring mechanism.
2. Tilt the flask to pour the beverage.
3. After pouring, press the central button again to close the mechanism. This ensures the flask is sealed and leakproof.



Figure 5: Pouring a beverage from the flask.



Figure 6: The flask is designed for drip-free pouring.

6. INSULATION PERFORMANCE

The WMF Impulse flask features ThermaPro insulation with a high-quality glass core, designed to keep contents hot or cold for up to 24 hours.




Figure 7: 24-hour hot and cold retention.

7. MAINTENANCE AND CLEANING

7.1 General Cleaning

- After each use, rinse the flask interior and lid with warm water.
- For thorough cleaning, use a bottle brush with warm soapy water.
- Do not use abrasive cleaners, scouring pads, or bleach, as these can damage the flask's finish or interior.
- The exterior can be wiped clean with a damp cloth.
- Ensure all parts are completely dry before storage to prevent odors or mildew.

7.2 Glass Insert Replacement

The glass insert is replaceable. To access it:

1. Turn the flask upside down.
2. Locate the screw mechanism at the bottom of the flask.
3. Unscrew the base to release the glass insert.

4. Carefully remove the old insert and replace it with a new one.
5. Re-secure the base by screwing it back on.



Figure 8: Accessing the glass insert by unscrewing the base.



Figure 9: Bottom view of the flask with the screw mechanism.

8. TROUBLESHOOTING

- **Poor Temperature Retention:** Ensure the lid is securely tightened and the pressure closure button is in the closed position. Pre-warming or pre-chilling the flask before filling can improve performance.
- **Leaking:** Check that the lid is properly screwed on and the pressure closure button is fully engaged in the closed position. Inspect the lid's silicone seal for any damage or misalignment.
- **Difficulty Pouring:** Ensure the pressure closure button is pressed to the open position before attempting to pour.

9. SPECIFICATIONS

| Feature | Specification |
|-------------------|--|
| Brand | WMF |
| Model Name | Impulse |
| Item Model Number | 690697390 |
| Capacity | 1 Liters |
| Material | Stainless Steel (exterior), Glass (interior) |
| Color | Black |

| Feature | Specification |
|--------------------|--|
| Special Features | Insulated, Leakproof, Pressure Closure |
| Product Dimensions | 11.42"W x 9.45"H (approximate) |
| Item Weight | 1.03 Kilograms (2.26 pounds) |

10. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation provided at the time of purchase or contact WMF customer service directly. Keep your proof of purchase for any warranty claims.