

[Manuals.plus](#) /

› [Brabantia](#) /

› Brabantia Touch Trash Can New 8 Gallon Brilliant Steel User Manual

Brabantia Touch Trash Can New, 8 Gallon

Brabantia Touch Trash Can New 8 Gallon Brilliant Steel User Manual

Model: Touch Trash Can New, 8 Gallon

INTRODUCTION

Thank you for choosing the Brabantia Touch Trash Can New. This manual provides essential information for the proper setup, operation, and maintenance of your new 8-gallon (30-liter) Brilliant Steel waste bin. Please read these instructions carefully before use to ensure optimal performance and longevity of your product.



Image: The Brabantia Touch Trash Can New, 8 Gallon, in Brilliant Steel. This cylindrical waste bin features a sleek, polished stainless steel body and a dark, soft-touch lid.

SETUP

1. **Unpacking:** Carefully remove all packaging materials. Ensure all components are present: the outer trash can, the lid, the removable inner bucket, and a sample roll of liners.
2. **Placement:** Position the trash can in your desired location, such as a kitchen or living room. Its cylindrical shape and flush-to-wall design allow for efficient space utilization.
3. **Insert Inner Bucket:** Place the black removable inner bucket inside the brilliant steel outer casing. Ensure it sits securely at the bottom.
4. **Insert Liner:** Take a Brabantia PerfectFit waste bag (size G recommended for 23-30L capacity) and fit it around the rim of the inner bucket. The special ventilation holes in the inner bucket prevent a vacuum when removing a full liner, making bag changes easier.
5. **Attach Lid:** Place the lid unit onto the top of the outer casing, ensuring it aligns correctly.



Image: A close-up view of the Brabantia Touch Trash Can with its lid removed, showing the black removable inner bucket. This design facilitates easy liner changes and cleaning.

OPERATING INSTRUCTIONS

The Brabantia Touch Trash Can features a "Soft-Touch" opening mechanism for convenient use.

- **Opening the Lid:** Gently press the center of the lid. The lid will open quietly and smoothly.
- **Closing the Lid:** Gently push the lid down until it clicks into place. The lid provides a secure seal to contain odors.



Image: A hand gently pressing the lid of the Brabantia Touch Trash Can, demonstrating the soft-touch opening mechanism. The lid opens wide for easy waste disposal.

Product Video



Video: Official product video demonstrating the features of the Brabantia Touch Trash Can New, 8 Gallon. This video highlights the soft-touch opening, the spacious XL opening, the removable inner bucket for easy cleaning, and the use of PerfectFit waste bags.

MAINTENANCE AND CLEANING

Regular cleaning will help maintain the appearance and hygiene of your Brabantia Touch Trash Can.

- **Changing Liners:** When the waste bag is full, remove the lid, lift the inner bucket, and tie the bag. Dispose of the bag responsibly. Replace with a new Brabantia PerfectFit waste bag (size G).
- **Cleaning the Inner Bucket:** The removable inner bucket can be easily lifted out for thorough cleaning. Wash with warm soapy water and rinse well. Allow it to dry completely before placing it back into the outer casing.

- **Cleaning the Outer Casing:** The brilliant steel exterior is made of corrosion-resistant materials. Wipe the exterior with a soft, damp cloth and a mild detergent if necessary. Avoid abrasive cleaners or scouring pads, as these can damage the finish. Dry thoroughly with a soft, dry cloth to prevent water spots.
- **Lid Mechanism:** Periodically check the lid mechanism for any debris that might hinder smooth operation. Clean gently with a soft cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not open/close smoothly.	Debris in the mechanism or misalignment.	Check the lid mechanism for any obstructions and clean. Ensure the lid is correctly seated on the bin.
Waste bag does not fit properly.	Incorrect size or type of waste bag.	Use Brabantia PerfectFit waste bags, size G, designed for 23-30L bins.
Unpleasant odors emanating from the bin.	Lid not fully closed, dirty inner bucket, or old waste.	Ensure the lid is securely closed. Clean the inner bucket thoroughly. Empty the bin regularly.

SPECIFICATIONS

Feature	Detail
Brand	Brabantia
Model	Touch Trash Can New
Capacity	8 Gallons (30 Liters)
Color	Brilliant Steel
Opening Mechanism	Press-Top (Soft-Touch)
Material	Steel
Finish Type	Polished
Shape	Cylindrical
Recommended Uses	Kitchen, Living Room
Special Features	Durable, Removable Inner Bucket, Corrosion-Resistant
Item Weight	3.7 Kilograms
Dimensions (L x W x H)	12.6"L x 11.61"W x 28.35"H
Included Components	Trash Can, Lid, Inner bucket, sample roll of liners

WARRANTY

This Brabantia Touch Trash Can New is covered by a **10-year warranty**. For detailed information regarding warranty terms and conditions, please refer to the official Brabantia website or contact customer support.

CUSTOMER SUPPORT

Should you have any questions, require assistance, or need to report an issue with your Brabantia Touch Trash Can, please contact Brabantia customer support through their official website or the contact information provided with your purchase. Please have your model information ready when contacting support.

For more information and to explore other Brabantia products, visit the [Brabantia Store on Amazon](#).

