

- Manuals.plus /
- > [Berkel](#) /
 - > Berkel Elegance Salmon Knife Instruction Manual - 10 Inch Stainless Steel Blade

Berkel Elegance Salmon Knife

Berkel Elegance Salmon Knife Instruction Manual

Model: 10" Stainless Steel Blade

PRODUCT OVERVIEW

The Berkel Elegance Salmon Knife is crafted with a 10-inch stainless steel blade, specifically designed for the delicate task of slicing raw fish such as salmon, tuna, and swordfish. Its flexible blade ensures consistent, thin slices, making it an essential tool for culinary precision. This knife embodies Berkel's commitment to high-quality craftsmanship and elegant design, originating from Italy's rich tradition of fine cutlery.




Image: Berkel Elegance Salmon Knife featuring its distinctive red handle and stainless steel blade.

SETUP AND INITIAL CARE

Upon receiving your Berkel Elegance Salmon Knife, carefully remove it from its packaging. Before first use, wash the knife by hand with warm water and a mild detergent. Rinse thoroughly and dry immediately with a soft cloth. This prevents water spots and maintains the blade's integrity. **The knife is not dishwasher safe.**



Image: Close-up view of the Berkel Elegance Salmon Knife handle, highlighting its ergonomic design.

OPERATING INSTRUCTIONS

The Berkel Elegance Salmon Knife is designed for precision slicing of delicate foods. Its long, flexible blade allows for smooth, even cuts, particularly when preparing raw fish.

Slicing Technique for Fish:

1. Place the fish fillet on a stable cutting board.
2. Hold the knife at a shallow angle to the fish.
3. Using a single, long, sweeping motion, draw the knife across the fish, allowing the blade's length and flexibility to do the work. Avoid a sawing motion.
4. Apply gentle, consistent pressure to achieve uniform, thin slices.

The knife's tip and smooth edge enable precise cutting, making it ideal for delicate tasks.

Demonstration Video:

Your browser does not support the video tag.

Video: Berkel Elegance Knife Catalog. This video demonstrates various knives from the Elegance line, including techniques for slicing and preparing different foods. The salmon knife's use is shown for delicate fish preparation.

MAINTENANCE AND STORAGE

Cleaning:

- Always hand wash your knife immediately after use.
- Use warm water and a mild dish soap.
- Avoid abrasive cleaners or scrubbers that can damage the blade or handle.
- Dry the knife completely with a soft towel to prevent rust and water spots.
- *Do not wash in a dishwasher*, as harsh detergents and high temperatures can dull the blade and damage the handle material.

Sharpening:

Regular sharpening maintains the knife's performance. Use a quality sharpening steel or stone. For best results, consider professional sharpening services periodically.

Storage:

Store your Berkel Elegance Salmon Knife in a knife block, magnetic strip, or blade guard to protect the edge and prevent accidental injury. Ensure it is stored in a dry environment.

TROUBLESHOOTING

Dull Blade:

If the knife feels dull, it requires sharpening. Refer to the "Sharpening" section under Maintenance. A dull knife can be more dangerous than a sharp one as it requires more force to cut, increasing the risk of slippage.

Rust Spots:

Stainless steel is resistant to rust, but not entirely rust-proof. Rust spots can occur if the knife is left wet or exposed to corrosive substances. To remove minor rust spots, use a non-abrasive cleaner designed for stainless steel. Prevent rust by always drying the knife immediately after washing.

SPECIFICATIONS

Feature	Detail
Blade Material	Stainless Steel
Blade Length	10 Inches (25.4 cm)
Blade Edge	Smooth
Handle Color	Red (also available in Black)
Item Weight	4.9 Ounces (139 grams)

Construction Type	Forged
Dishwasher Safe	No
Origin	Made in Italy

WARRANTY AND SUPPORT

Berkel products are known for their quality and craftsmanship. For specific warranty information and customer support, please refer to the documentation included with your purchase or visit the official Berkel website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact Berkel customer service through their official channels.

© 2026 Berkel. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B06WD1HXTS>

More documents and user manuals: <https://manuals.plus/>