



Manuals.plus /

- › Braun /
- › Braun Silk-épil 3-270 Epilator User Manual

Braun 3270

Braun Silk-épil 3-270 Epilator User Manual

Model: 3270

PRODUCT OVERVIEW

The Braun Silk-épil 3-270 epilator is designed for effective and long-lasting hair removal. It features a 20-tweezer system to gently remove hairs from the root, providing smooth skin for weeks. This device is suitable for beginners and includes additional attachments for versatile use on various body areas.



Image: The Braun Silk-épil 3-270 epilator, its packaging, and included accessories: epilator head, shaver head, and trimmer comb.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons, always follow these precautions:

- Close supervision is needed when this appliance is used by, on, or near children or persons with disabilities.
- Use this appliance only for its intended use as described in the manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.

DANGER: To reduce the risk of electric shock:

- FOR HOUSEHOLD USE ONLY.

- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning.
- This appliance is provided with a special cord set with integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it.

WHAT'S INCLUDED

- 1 x Epilator
- 1 x Shaver Head
- 1 x Trimmer Head
- 1 x Cleaning Brush
- 1 x Charger



Image: A visual representation of the Braun Silk-épil 3 device and its included accessories: the epilator unit, trimmer cap, cleaning brush, and shaver head. The power cord is also included but not shown in this diagram.

SETUP AND FIRST USE

Before first use, ensure the device is clean and dry. Connect the charger to the device and plug it into an electrical outlet. The device is corded and does not require charging breaks during use.

Attach the desired head (epilator, shaver, or trimmer) firmly onto the device body until it clicks into place.

OPERATING INSTRUCTIONS

Epilation

Evenings are generally the best time for epilation, as your skin is more relaxed, and any minor redness will likely subside by morning. Prepare your skin by exfoliating in warm water. This helps to clean and relax the skin, and can reduce the occurrence of ingrown hairs. You may use an exfoliating scrub or mitt.

When epilating, hold the device at a 90-degree angle to your skin. Move the epilator in an upward motion, against the direction of hair growth. There is no need to press down hard; simply allow the epilator to lightly touch the skin. The Braun Silk-épil 3-270 features massage rollers that gently stimulate and massage your skin to help minimize discomfort during epilation. With regular use, epilation can become virtually painless.

**Weeks of smooth skin,
not days**

BRAUN

4 WEEKS
4 weeks of salon-like smooth skin

20-tweezer system
removes hairs at the roots

3-in-1
3-in-1 epilate, shave, or trim

Massage roller cap
reduces pain

Removes hair 4x shorter
shorter than waxing

#1
World's #1 Epilation Brand

BRAUN
Silk-épil 3

Image: An infographic illustrating the key benefits of the Braun Silk-épil 3, including long-lasting smoothness, the 20-tweezer system, multi-functionality, and pain reduction features.

Why epilate?


With Braun Silk-épil, keeping your body hair free is **inexpensive, thorough and simple**

- ✓ Less stubble than shaving
- ✓ Lasts as long as waxing
- ✓ Easy to do from home

Most importantly, it leaves your **skin smooth and silky** to the touch



Image: A woman demonstrating the use of the Braun Silk-épil epilator on her leg, highlighting the ease of use for at-home hair removal.



Easy, convenient, inexpensive

Epilation with Silk-épil creates **smooth skin that lasts for weeks**. Without the hassle and cost of going to a hair removal appointment

Image: A woman using the Braun Silk-épil epilator on her upper thigh, illustrating the convenience and economic benefits of epilation over salon waxing.

Shaving and Trimming

For sensitive areas or quick touch-ups, attach the shaver head or trimmer head. The shaver head provides a close shave, while the trimmer head allows for precise trimming of hair to a desired length. These attachments offer added versatility for your hair removal routine.

MAINTENANCE AND CLEANING

After each use, unplug the device. Remove the attachment head from the epilator body. Use the provided cleaning brush to remove any trapped hairs from the epilator head or shaver/trimmer heads. For thorough cleaning, the heads can be rinsed under running water. Ensure all parts are completely dry before reattaching or storing the device.

TROUBLESHOOTING

If the device does not turn on, ensure it is properly plugged into a working electrical outlet. If the device is not performing optimally (e.g., not removing hair effectively), ensure the attachment head is clean and free of hair buildup. If issues persist, refer to the safety information regarding damaged cords or plugs, and

consider contacting customer support.

SPECIFICATIONS

Feature	Detail
Model Number	3270
Brand	Braun
Color	Pink
Power Source	Corded Electric
Product Dimensions	7.76 x 7.09 x 0.1 inches
Item Weight	9.12 ounces (0.57 Pounds)
Water Resistance Level	Not Water Resistant
UPC	069055879771

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Braun website or the documentation included with your product. A user guide in PDF format is available online for detailed instructions and support.

Online User Guide: [Braun Silk-épil 3-270 User Guide \(PDF\)](#)