

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bontempi](#) /

› [Bontempi MP3Stage Microphone Model 4071 - User Instruction Manual](#)

Bontempi 4071

Bontempi MP3Stage Microphone Model 4071 - User Instruction Manual

Model: 4071 | Brand: Bontempi

INTRODUCTION

Thank you for choosing the Bontempi MP3Stage Microphone. This dynamic microphone with MP3 connection is designed to provide powerful vocal performances and versatile entertainment. Please read this manual carefully before use to ensure proper setup, operation, and maintenance.

SAFETY INFORMATION

WARNING: This product is intended for recreational use. Adult supervision is recommended, especially for younger users.

- Keep small parts away from children to prevent choking hazards.
- Do not expose the device to water or excessive moisture.
- Use only the recommended power source (battery-powered).
- Avoid dropping or subjecting the microphone to strong impacts.
- If the product is damaged, discontinue use immediately.

PACKAGE CONTENTS

- Microphone unit
- Adjustable stand
- MP3 connection cable (Auxiliary cable)
- Instruction Manual



Image: The Bontempi MP3Stage Microphone shown with its retail packaging, illustrating the product's appearance and included

components.

SETUP INSTRUCTIONS

- Assemble the Stand:** Carefully connect the stand components. Ensure all parts are securely fastened. The stand is adjustable in height.
- Attach the Microphone:** Place the microphone unit onto the designated holder on the stand.
- Insert Batteries:** Locate the battery compartment (usually at the base or control panel). Insert the required batteries (not included) according to the polarity indicators.
- Power On:** Turn on the microphone using the power switch, typically located on the control panel.





Image: The fully assembled Bontempi MP3Stage Microphone, showcasing its pink and white design with the microphone attached to the adjustable stand.

OPERATING INSTRUCTIONS

1. Basic Microphone Use

- Speak directly into the microphone for optimal sound pickup.
- Use the volume controls on the microphone unit to adjust your vocal output level.

2. MP3 Connection

1. **Connect Device:** Use the provided auxiliary cable to connect your smartphone, tablet, or MP3 player to the "MP3 IN" jack on the microphone unit.
2. **Play Music:** Start playing music on your connected device. The audio will be routed through the microphone's speaker system.
3. **Adjust Volume:** The music volume is primarily controlled by your connected device. You can also use the microphone's master volume control to balance the music with your vocals.



Image: A close-up view of the Bontempi MP3Stage Microphone's control panel, showing a smartphone connected via the auxiliary input, highlighting the MP3 connection feature.

3. Sound and Light Effects

- **Effect Buttons:** The control panel features buttons for various sound effects (e.g., applause, audience noise) and musical backing tracks. Press these buttons to activate the desired effects.
- **Light Show:** The microphone unit includes dynamic lighting effects that activate during use, adding a visual element to performances.

MAINTENANCE

- **Cleaning:** Wipe the microphone and stand with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight when not in use.
- **Battery Replacement:** If the sound quality deteriorates or the lights dim, replace the batteries. Always use new batteries of the specified type.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from microphone	<ul style="list-style-type: none"> ◦ Power switch off ◦ Dead batteries ◦ Microphone not connected properly 	<ul style="list-style-type: none"> ◦ Turn on power switch ◦ Replace batteries ◦ Ensure microphone cable is securely plugged in
No sound from connected MP3 device	<ul style="list-style-type: none"> ◦ MP3 device volume too low ◦ Auxiliary cable not connected ◦ Incorrect input selected (if applicable) 	<ul style="list-style-type: none"> ◦ Increase volume on MP3 device ◦ Connect auxiliary cable firmly ◦ Refer to device instructions for input selection
Distorted sound	<ul style="list-style-type: none"> ◦ Volume too high ◦ Low batteries 	<ul style="list-style-type: none"> ◦ Reduce volume on microphone or MP3 device ◦ Replace batteries

SPECIFICATIONS

Brand	Bontempi
Model Name	4071
Item Weight	500 Grams
Microphone Form Factor	Handheld
Item Dimensions (L x W x H)	46 x 46 x 94 centimeters
Power Source	Battery Powered
Material	Plastic
Number of Channels	1
Connectivity Technology	Auxiliary
Connector Type	3.5 mm Jack
Special Feature	Sound effects, MP3 connection
Compatible Devices	Smartphone, tablet, personal computer, laptop, home cinema
Recommended Age	36 months - 18 years
Educational Value	Create, Imagine, Invent

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Bontempi customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 Bontempi. All rights reserved.

Related Documents - 4071

	<p>Bontempi 48 5010 Wireless Microphone Speaker User Manual</p> <p>Comprehensive user manual for the Bontempi 48 5010 Wireless Microphone Speaker, detailing technical specifications, setup, operation, and troubleshooting in multiple languages.</p>
	<p>Bontempi 486200 Wireless Amplifier with Microphone - User Manual</p> <p>User manual for the Bontempi 486200 Wireless Amplifier with Microphone. Learn about its features, operation, connections, troubleshooting, and specifications.</p>
	<p>Bontempi Electronic Table Keyboard with Microphone - User Manual</p> <p>User manual for the Bontempi Electronic Table Keyboard with microphone (Model 12 3730), detailing features, operation, power supply, sound and rhythm selection, recording functions, effects, disposal information, and troubleshooting.</p>
	<p>Bontempi 49 1010 Wireless Speaker with Microphone & RGB Lights - Owner's Manual</p> <p>Owner's manual for the Bontempi 49 1010 wireless speaker, featuring microphone and RGB lighting. Includes instructions for setup and operation.</p>
	<p>Bontempi 49 1030 Wireless Speaker with Microphone & RGB Lights - User Manual</p> <p>User manual for the Bontempi 49 1030 Wireless Speaker. Learn about its features, controls, TWS function, power supply, and disposal guidelines. This portable speaker offers wireless connectivity, microphone input, and RGB lighting.</p>



[Bontempi 42 5030 Karaoke Sound Box with 2 Microphones - User Manual](#)

Comprehensive user manual for the Bontempi 42 5030 Karaoke Sound Box. Learn how to set up, operate, and troubleshoot your karaoke system, including features like voice recording, voice changer, and external audio input.