

[Manuals.plus](#) /

> [VINGLI](#) /

> VINGLI Portable Folding Outdoor Fish and Game Cleaning Table with Sink User Manual

VINGLI fish table

VINGLI Portable Folding Outdoor Fish and Game Cleaning Table with Sink User Manual

Model: fish table

INTRODUCTION

This manual provides instructions for the assembly, operation, maintenance, and troubleshooting of your VINGLI Portable Folding Outdoor Fish and Game Cleaning Table with Sink. Please read this manual thoroughly before use to ensure proper function and safety. Keep this manual for future reference.

The VINGLI cleaning table is designed for outdoor use, offering a convenient and portable solution for cleaning fish, game, or preparing food. It features a durable construction, an integrated sink with a faucet, and a drainage system.

SAFETY INFORMATION

- Always ensure the table is placed on a stable, level surface before use.
- Verify that all locking mechanisms for the legs are securely engaged to prevent collapse.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs).
- Keep children and pets away from the table during assembly and use.
- Exercise caution when handling sharp tools or knives on the table surface.
- Ensure proper drainage to prevent water accumulation and potential slipping hazards.
- Clean the table thoroughly after each use to maintain hygiene and product longevity.

PACKAGE CONTENTS

Before assembly, ensure all components are present and undamaged. If any parts are missing or damaged, contact VINGLI customer support.



Image: All components of the VINGLI cleaning table laid out, including the tabletop with integrated sink, faucet, drain assembly, and various connectors and seals.

- Folding Tabletop with Integrated Sink
- Faucet Assembly (Stainless Steel)
- Drain Assembly (including stopper and strainer)
- Flexible Drainage Hose
- Garden Hose Adapter
- Legs with Locking Mechanisms (pre-attached to tabletop)
- Assembly Guide (included in package)

SETUP INSTRUCTIONS

The VINGLI cleaning table is designed for quick and easy setup. Two people are recommended for assembly.

1. **Unfold the Table:** Place the folded table on a flat surface. Carefully unfold the tabletop.
2. **Extend and Lock Legs:** Extend each leg outwards until it is fully open. Locate the locking mechanisms on each leg and ensure they are securely engaged. This reinforces the table's stability.

HEAVY DUTY

Lockable Legs to Secure



Load Capacity: 330 LBS




Image: Detail of the table's robust legs and the locking mechanism that ensures stability during use.

- 3. Install Faucet:** Insert the faucet assembly into the designated hole on the sink. Secure it from underneath with the provided washer and nut, tightening firmly by hand.
- 4. Install Drain Assembly:** Place the drain strainer into the sink's drain hole. From underneath, attach the remaining drain components, including seals and nuts, ensuring a watertight seal. Connect the flexible drainage hose to the drain assembly.

CONVENIENT CLEANING SINK

Premium Hardware



Image: The integrated sink with the faucet and drain assembly, including the stopper, ready for water connection.

- 5. Connect Water Supply:** Attach a standard garden hose to the faucet's inlet connection. Use the provided adapter if necessary. Ensure all connections are tight to prevent leaks.

STANDARD GARDEN CONNECTION

Free Adapter Included



UPGRADED DRAINAGE HOSE

Higher Quality Material, More durable

Image: Details of the standard garden hose connection for water input and the flexible, upgraded drainage hose for wastewater output.

- Position Drainage Hose:** Direct the flexible drainage hose into a suitable receptacle or drainage area. Ensure the hose is not kinked and allows for free flow of water.



Image: The VINGLI cleaning table fully assembled, displaying its dimensions and the integrated sink with faucet.

OPERATING INSTRUCTIONS

Once assembled and connected to a water source, your VINGLI cleaning table is ready for use.

1. **Turn on Water Supply:** Slowly open the water spigot from your garden hose connection. Check for any leaks at the faucet and hose connections.
2. **Use the Faucet:** The stainless steel faucet can be swiveled and folded for flexible use. Adjust water flow as needed for cleaning tasks.
3. **Cleaning Surface:** Utilize the spacious tabletop for preparing or cleaning fish, game, or other food items. The integrated sink allows for washing and rinsing.

Perfect for Outdoor Fish/ Food Cleaning



✔ Portable Design

✔ Stable Design

✔ Large Space

✔ Suitable Height

✔ Standard Connection

✔ Reinforced packaging

Image: The VINGLI cleaning table in use, showing a person cleaning food items, highlighting its versatility for outdoor tasks.

- 4. Drainage:** Ensure the drainage hose is positioned correctly to direct wastewater away from your work area. The upgraded drainage hose is designed for durability and efficient water removal.
- 5. Folding for Storage:** When finished, turn off the water supply and disconnect the garden hose. Remove the drain hose from its receptacle. Fold the faucet down. Unlock the leg mechanisms and fold the legs inward. The table folds compactly for convenient transport and storage.



EASY TO CARRY

- Foldable
- Lightweight



 **Weight: 23 LBS**

Image: The VINGLI cleaning table in its folded state, illustrating its portability and ease of storage. The table weighs approximately 12.84 kg (28.3 lbs).

MAINTENANCE

Regular maintenance will extend the life of your VINGLI cleaning table.

- **Cleaning:** After each use, clean the tabletop and sink thoroughly with mild soap and water. Rinse completely and dry to prevent water spots or residue buildup.
- **Drainage System:** Periodically check the drainage hose and drain assembly for any blockages or debris. Clear any obstructions to ensure efficient water flow.
- **Faucet:** Inspect the faucet for any mineral buildup, especially in hard water areas. Clean with a descaling solution if necessary.
- **Storage:** Store the folded table in a dry, protected area away from extreme temperatures and direct sunlight when not in use.
- **Leg Mechanisms:** Occasionally check the leg locking mechanisms for proper function. Lubricate moving parts if they become stiff.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaks from faucet or hose connection.	Loose connection; damaged washer/seal.	Tighten connections. Check and replace washers/seals if damaged.
Slow or no drainage.	Drainage hose kinked or blocked; drain strainer clogged.	Straighten hose. Clear any debris from the drain strainer and hose.
Table feels unstable.	Legs not fully extended or locked; uneven surface.	Ensure all leg locking mechanisms are engaged. Move table to a level surface.
Faucet difficult to swivel.	Mineral buildup; lack of lubrication.	Clean with descaling solution. Apply a small amount of food-grade lubricant if needed.

SPECIFICATIONS

Feature	Detail
Model Number	fish table
Brand	VINGLI
Overall Dimensions (L x W x H)	115.06 cm x 58.93 cm x 94.49 cm (approx. 45.3 in x 23.2 in x 37.2 in)
Folded Dimensions (W x L)	59 cm x 114 cm (approx. 23.2 in x 44.9 in)
Item Weight	12.84 kg (28.3 lbs)
Maximum Weight Recommendation	150 kg (330 lbs)
Tabletop Material	High-Density Polyethylene (HDPE)
Frame Material	Plastic (with metal components for legs/mechanisms)
Faucet Material	Stainless Steel
Color	White (tabletop), Ecru (frame)
Assembly Required	Yes (2 people recommended)
Outdoor Use	Yes

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official VINGLI website. Please have your model number ("fish table") and purchase date available when contacting support.