

Helix ETAUDBTBLK

Helix Black Bluetooth Sports Earbuds User Manual

Model: ETAUDBTBLK

- Instructions
- Maintenance
- Overview
- Setup
- Operating
- Troubleshooting
- Specifications
- Warranty & Support

1. PRODUCT OVERVIEW

The Helix Black Bluetooth Sports Earbuds are designed for active lifestyles, providing high-fidelity audio and a secure fit during intense workouts. These sweat-resistant earbuds feature an inline microphone and remote for convenient control over your music and calls.

Key Features:

- HD Sound with Deep Bass and Clear Audio
- Wireless sweat-resistant design
- Winged Tips Keep Earbuds in Place Through High Intensity Workouts
- Built-in Mic for Hands-Free Calling and Track Controls
- Includes Tangle-Free Retractable Micro USB Cable





Figure 1.1: Overview of the Helix Black Bluetooth Sports Earbuds, showcasing their sleek design and inline controls.

2. SETUP

2.1 Charging the Earbuds

Before first use, fully charge your earbuds. Use the included retractable Micro USB cable to connect the earbuds to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status.

TAKE CONTROL

Built-In Mic for Hands-Free Calling
and Accessible Track Controls



Figure 2.1: Close-up of the inline remote showing the Micro USB charging port.

2.2 Pairing with a Bluetooth Device

1. Ensure the earbuds are charged and turned off.
2. Press and hold the multi-function button (usually the center button on the inline remote) until the indicator light flashes red and blue, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. The earbuds will appear as "Helix ETAUDBT" or similar.
5. Select the earbuds from the list to connect. Once connected, the indicator light will typically turn solid blue or flash slowly.

EASY PAIRING

Compatible with Any Bluetooth Enabled Device



Figure 2.2: Illustration of the easy pairing process with a mobile device, showing the earbuds successfully connected via Bluetooth.

The earbuds are compatible with any Bluetooth-enabled device.

3. OPERATING INSTRUCTIONS

3.1 Inline Remote Controls

The inline remote provides convenient control over audio playback and calls.

TAKE CONTROL

Built-In Mic for Hands-Free Calling
and Accessible Track Controls



Figure 3.1: Detailed view of the inline remote, highlighting the volume, track, play/pause, and call control buttons.

- **Power On/Off:** Press and hold the multi-function button.
- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Press the Volume Up (+) button.
- **Volume Down:** Press the Volume Down (-) button.
- **Answer/End Call:** Press the multi-function button once during an incoming call.
- **Reject Call:** Press and hold the multi-function button during an incoming call.

3.2 Wearing the Earbuds

The SportFit™ design with winged tips ensures the earbuds stay securely in place during high-intensity workouts. Insert the earbuds into your ears and adjust the winged tips for a comfortable and stable fit.




Figure 3.2: A person wearing the Helix earbuds, demonstrating how the SportFit™ winged tips provide a secure fit for active use.

4. MAINTENANCE

4.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene. Gently wipe the earbuds and ear tips with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive materials.

4.2 Storage

When not in use, store the earbuds in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tangling the cable by coiling it neatly.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Earbuds do not power on.	Low battery.	Charge the earbuds fully using the provided USB cable.
Cannot pair with device.	Earbuds not in pairing mode; device Bluetooth off; too far from device.	Ensure earbuds are in pairing mode (flashing red/blue). Turn device Bluetooth off and on. Move earbuds closer to device (within 10 meters).
No sound or low volume.	Volume too low on earbuds or device; earbuds not connected; incorrect audio output selected.	Increase volume on both earbuds and device. Re-pair the earbuds. Check device's audio output settings.
Poor sound quality or static.	Interference; low battery; distance from device.	Move away from other wireless devices. Charge earbuds. Reduce distance between earbuds and device.
Short battery life.	Battery degradation over time; continuous high volume use.	Ensure full charge before use. Reduce listening volume. Note that battery life naturally decreases over time.

6. SPECIFICATIONS

Feature	Detail
Model Name	ReTrak Essentials
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Included Components	Black Bluetooth Sport Earbuds, Retractable charging cable
Specific Uses For Product	Sports and Exercise
Control Type	Media Control
Control Method	Touch (referring to button presses, not touch surface)
Item Weight	2.11 ounces
Product Dimensions	0.3 x 0.06 x 0.59 inches
Item Model Number	ETAUDBTBLK
UPC	816983017009
Brand	Helix

Feature	Detail
Color	Black
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Active Noise Cancellation

7. WARRANTY INFORMATION

Helix products are manufactured to the highest quality standards. For specific warranty details and terms, please refer to the warranty card included with your product or visit the official Helix website. Keep your proof of purchase for warranty claims.



8. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Helix Black Bluetooth Sports Earbuds, please contact our customer support team. Contact information can typically be found on the product packaging or the official Helix website.

For the latest information and support resources, please visit: [Helix Official Store on Amazon](#)

© 2023 Helix. All rights reserved.

Related Documents

	<p>Helix True Wireless Earbuds EBP-B-042A User Manual</p> <p>User guide for Helix True Wireless High Fidelity Earbuds with Portable Charging Case (Model: EBP-B-042A), covering setup, Bluetooth pairing, button functions, troubleshooting, warranty, and FCC compliance.</p>
	<p>HELIX COMPOSE i5 Tweeter User Manual</p> <p>User manual for the HELIX COMPOSE i5 Tweeter, providing installation instructions, technical data, and disposal information. Engineered in Germany.</p>



[HELIX COMPOSE Ci7 M100FM-S3 Midrange User Manual](#)

This user manual provides detailed installation and technical information for the HELIX COMPOSE Ci7 M100FM-S3 midrange speaker. Learn about mounting options, wiring, technical specifications, and proper disposal.



[HELIX COMPOSE CB W165-S3 Midbass Speaker User Manual](#)

User manual for the HELIX COMPOSE CB W165-S3 midbass speaker, providing installation instructions, technical specifications, and warranty information from AUDIOTEC FISCHER.