

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rfiver](#) /

› [Rfiver Universal Swivel TV Stand Instruction Manual](#)

Rfiver Swivel Tabletop TV Stand for 27-55 inch

Rfiver Universal Swivel TV Stand Instruction Manual

MODEL: SWIVEL TABLETOP TV STAND FOR 27-55 INCH



1. Product Overview

The Rfiver Universal Swivel TV Stand is designed to provide a stable and versatile mounting solution for your television. This tabletop stand eliminates the need for wall mounting, offering flexibility in placement and viewing angles.

Key Features:

- TV Compatibility:** Supports most 27-60 inch TVs with VESA patterns: 100x100, 200x100, 200x200, 200x300, 300x300, 300x400, 400x400mm. Compatible with LCD, LED, OLED, QLED, Plasma, and Smart TVs.
- Strong Structure:** Heavy-duty steel frame and 8mm thick tempered glass base for enhanced stability and safety.
- Height Adjustment:** 6 levels of height adjustment, allowing you to set your TV at the optimal eye level.
- Swivel Function:** Swivels 30 degrees left or right for optimized viewing from various positions, reducing glare and neck strain.
- Cable Management:** Integrated wire management solution within the pole to keep cables organized and concealed.



Image: The Rriver Universal Swivel TV Stand supporting a television, showcasing its sleek design.

2. Safety Information

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in property damage, serious injury, or death.

- **Weight Capacity:** This TV stand is designed to hold TVs weighing up to 88 lbs (40 kg). Do NOT exceed this weight limit.
- **TV Size:** Ensure your TV size is within the recommended range of 27-60 inches.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern matches the stand's supported patterns (100x100 to 400x400mm).
- **Stable Surface:** Always place the TV stand on a flat, stable, and level surface to prevent tipping.
- **Tempered Glass:** The base is made of high-strength tempered glass. While durable, avoid dropping heavy objects on it or subjecting it to sharp impacts.
- **Children and Pets:** Keep children and pets away from the TV stand during assembly. Ensure the TV is

securely mounted to prevent accidental falls.

- **Safety Lock:** Utilize the provided safety lock mechanism to secure the TV to the stand after mounting.




Image: Diagram illustrating the sturdy structure and tempered glass thickness of the TV stand.

3. Parts List

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not attempt to assemble. Contact customer service for assistance.

Included Components:

- Tempered Glass Base
- Metal Support Pillar
- TV Mounting Bracket (Vesa compatible)
- Mounting Arms (2 pieces)
- Safety Lock Screws
- Non-Slip Pads

- Assorted TV Screws and Washers (for various TV models)
- Assembly Tools (e.g., Allen wrench, screwdriver)




Image: Breakdown of TV stand components including dimensions, safety lock, cable management, and non-slip pads.

4. Setup and Assembly

Assembly is designed to be quick and easy with no drilling required. Follow these steps carefully:

1. **Attach Support Pillar to Base:** Secure the metal support pillar to the tempered glass base using the provided screws and tools. Ensure it is firmly tightened.
2. **Install Mounting Bracket:** Attach the TV mounting bracket to the top of the support pillar.
3. **Attach Mounting Arms to TV:** Select the correct size screws and washers from the assorted hardware to attach the two mounting arms to the VESA holes on the back of your TV. Ensure the screws are flush against the TV and do not overtighten.
4. **Mount TV to Stand:** Carefully lift your TV and hook the mounting arms onto the TV mounting bracket on the stand. The arms have hooks that will engage with the bracket.

5. **Secure with Safety Lock:** Once the TV is hooked onto the stand, insert and tighten the safety lock screws at the bottom of the mounting arms to prevent accidental dislodgement.
6. **Apply Non-Slip Pads:** If desired, apply the non-slip pads to the bottom of the tempered glass base to prevent scratches and improve stability on your furniture.
7. **Cable Management:** Utilize the cable management solution on the back of the support pillar to organize and conceal your TV cables for a tidy appearance.

For a visual guide, please refer to the official installation video below:

Your browser does not support the video tag.

Video: Official installation guide for the Rriver Universal Swivel TV Stand, demonstrating assembly steps and features.



Image: Illustration showing the simplicity of assembling the TV stand without the need for drilling.

5. Operating Instructions

Once assembled, the Rriver Universal Swivel TV Stand offers flexible viewing options:

- **Swivel Function:** Gently push the sides of your TV to swivel it up to 30 degrees left or right. This allows you to adjust the viewing angle to suit your position in the room, reducing glare and improving visibility.
- **Height Adjustment:** The TV's height can be adjusted in 6 levels from 18.5 to 24.4 inches. This adjustment is made by repositioning the mounting arms on the TV's VESA holes during assembly. Each level adjusts the height by approximately 2.36 inches.



Image: Demonstrating the 30-degree swivel capability of the TV stand.

6. Maintenance

To ensure the longevity and appearance of your Rfiver TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe down the metal and glass surfaces. Avoid abrasive cleaners or harsh chemicals that could damage the finish or glass.
- **Glass Care:** For the tempered glass base, use a glass cleaner and a microfiber cloth to prevent streaks.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure. Retighten if necessary.

- **Avoid Overloading:** Do not place items heavier than the specified weight capacity on the stand or hang anything from the TV that would exceed the limit.

7. Troubleshooting

If you encounter any issues with your Rfiver Universal Swivel TV Stand, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
TV feels unstable or wobbly.	Loose screws; uneven surface; TV weight exceeds capacity.	Check and tighten all assembly screws. Ensure the stand is on a flat, level surface. Verify TV weight is within 88 lbs limit.
Swivel function is stiff.	Tight connections; dust/debris in swivel mechanism.	Ensure no cables are obstructing the swivel. Clean around the swivel point. Avoid overtightening the main pillar connection.
TV is not at desired height.	Mounting arms incorrectly positioned.	Re-adjust the mounting arms on the back of the TV to a different VESA hole level on the stand's bracket.
Cables are messy.	Cable management not utilized.	Route cables through the integrated cable management clips on the back of the support pillar.

If the problem persists, please contact Rfiver customer service for further assistance.

8. Specifications

Feature	Detail
Brand	Rfiver
Model Number	Swivel Tabletop TV Stand for 27-55 inch
TV Compatibility	27-60 Inches (LCD, LED, OLED, QLED, Plasma, Smart TVs)
VESA Patterns Supported	100x100, 200x100, 200x200, 200x300, 300x300, 300x400, 400x400mm
Maximum Weight Capacity	88 lbs (40 kg)
Height Adjustment	6 levels, from 18.5 to 24.4 inches
Swivel Angle	±30 degrees (left/right)
Material	Tempered Glass, Heavy-Duty Steel
Color	Black
Product Dimensions	16.9 x 11 x 24.4 inches (L x W x H)

Feature	Detail
Item Weight	8.47 pounds
UPC	761330649436



Image: Visual guide for TV compatibility, max load, and VESA patterns.

9. Warranty and Support


Rfiver products are designed for durability and performance. For any questions, concerns, or warranty claims, please contact our customer service team.

Our local customer service team is prepared to answer any of your questions and solve your problems with prompt reply.

For more information or to register your product, visit the official Rfiver store [Rfiver Store on Amazon](#)





© 2025 Rfiver. All rights reserved.

Related Documents - Swivel Tabletop TV Stand for 27-55 inch



[RFIVER TF3001U TV Stand Installation Manual](#)

Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.

	<p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p>
	<p>Rfiver TF2002 TV Stand Assembly Instructions and User Guide</p> <p>Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.</p>
	<p>RFIVER UT5002 TV Stand Assembly Instructions and User Guide</p> <p>This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.</p>
	<p>MOUNTUP MU0036 Universal TV Stand Installation Guide</p> <p>Detailed installation instructions for the MOUNTUP MU0036 Universal TV Stand. It is designed for flat-screen TVs ranging from 37 to 55 inches, supporting a maximum weight of 88 lbs (40 kg) and VESA patterns up to 400x400mm. Learn how to safely assemble and mount your TV with this height-adjustable stand featuring a tempered glass base and swivel functionality.</p>
	<p>USX-MOUNT XAS309-1 Swivel Universal TV Stand Instruction Manual</p> <p>Instruction manual for the USX-MOUNT XAS309-1, a swivel universal TV stand designed for 37-70 inch TVs. This guide provides detailed steps for assembly, installation, and adjustment, including VESA compatibility, weight limits, parts inventory, and dimensions. It ensures safe and proper setup for your television.</p>