

[Manuals.plus](#) /

› [BLACK+DECKER](#) /

› BLACK+DECKER Mini Box Fan User Manual

BLACK+DECKER BFB09W

BLACK+DECKER Mini Box Fan User Manual

Model: BFB09W

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the safe and efficient operation of your BLACK+DECKER 9-inch Mini Box Fan, Model BFB09W. Designed for personal cooling, this portable fan offers versatile air circulation for various indoor environments.

Key Features:

- Compact and frameless design for versatile placement.
- Three quiet speed settings for customized airflow.
- Lightweight and portable for easy transport.
- Simple dial control for straightforward operation.
- Durable construction with a 1-year manufacturer warranty.

2. PRODUCT FEATURES

2.1 Slim, Frameless Design

Slim Unique Frameless Design

Perfect for a Desk or Table



The fan features a slim, square, and frameless design, allowing it to fit perfectly on desktops, tabletops, counters, and even windowsills without occupying excessive space. Its compact form factor makes it ideal for personal cooling in various settings.

2.2 Three Speed Settings

3 Speed Settings

Easy to use Dial



1-Low



2-Medium



3-High




Customize your airflow with three distinct speed settings: Low, Medium, and High. This allows you to adjust the intensity of the breeze to your preference, ensuring optimal comfort in any environment.

2.3 9-inch Blade Span

9 in. Blade Span

Lightweight and portable



Equipped with a 9-inch blade, the fan is designed to provide effective air circulation for personal spaces. The blade size contributes to its efficiency while maintaining a compact overall footprint.

2.4 Easy to Use

Easy-to-Use

No assembly is required



The fan requires no assembly; simply plug it in to begin operation. Its intuitive dial control, located on the front bottom corner, allows for quick and simple adjustment of settings.

2.5 Low Noise Output

Low Noise Output

create a quiet environment



Designed for quiet operation, this fan helps create a comfortable environment without distracting noise. This feature makes it suitable for use in bedrooms, offices, and other areas where minimal sound is desired.

2.6 Compact Dimensions



With dimensions of approximately 10.9 inches (D) x 4.25 inches (W) x 10.9 inches (H) and a weight of 3.17 pounds, the fan is highly portable and easy to move between locations as needed.

2.7 Product Overview Video

Your browser does not support the video tag.

Watch this official product overview video to see the BLACK+DECKER Mini Box Fan in action and learn more about its features and

benefits.

3. SETUP

The BLACK+DECKER Mini Box Fan is designed for immediate use with minimal setup. No assembly is required.

1. Unpack the fan from its packaging.
2. Place the fan on a stable, flat surface in your desired location (e.g., desk, table, windowsill).
3. Ensure the fan is positioned away from curtains or other objects that could obstruct airflow or interfere with the blades.
4. Plug the power cord into a standard 120V AC electrical outlet.

4. OPERATING INSTRUCTIONS

The fan features a simple rotary dial for controlling power and speed settings.

1. To turn the fan ON, rotate the dial clockwise from the "OFF" position.
2. Select your desired speed setting:
 - **Setting 1:** Low speed for a gentle breeze.
 - **Setting 2:** Medium speed for moderate airflow.
 - **Setting 3:** High speed for maximum cooling.
3. To turn the fan OFF, rotate the dial counter-clockwise until it clicks into the "OFF" position.

Note: Always ensure your hands are dry before operating the fan or plugging/unplugging it from the power outlet.

5. MAINTENANCE

Regular cleaning and proper care will ensure the longevity and optimal performance of your fan.

Cleaning:

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan.
- Do not use abrasive cleaners or solvents, as these may damage the fan's finish.
- For cleaning the fan blades, use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust and debris from the grilles.
- Ensure the fan is completely dry before plugging it back in and operating.

Storage:

- If storing the fan for an extended period, clean it thoroughly and place it back in its original packaging or a suitable storage box.
- Store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you experience issues with your fan, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not turn on.	No power to the unit.	Ensure the fan is securely plugged into a working electrical outlet. Check the circuit breaker if necessary.
Weak airflow.	Fan speed setting is too low; obstructed air intake/output.	Increase the speed setting using the dial. Ensure there are no obstructions blocking the front or rear grilles of the fan. Clean dust from grilles if present.

Problem	Possible Cause	Solution
Unusual noise or rattling.	Fan is not on a stable surface; foreign object inside.	Place the fan on a firm, level surface. Unplug the fan and carefully check for any foreign objects inside the grilles.

If the problem persists after attempting these solutions, please contact customer support or refer to the full user manual (PDF) for further assistance.

7. SPECIFICATIONS

Brand:	BLACK+DECKER
Model Number:	BFB09W
Color:	White
Product Dimensions:	11"D x 11"W x 4"H
Item Weight:	3.17 Pounds
Power Source:	AC
Wattage:	40 watts
Voltage:	120 Volts
Number of Blades:	3
Blade Length:	9 Inches
Speed Settings:	3
Control Method:	Dial
Indoor/Outdoor Usage:	Indoor
Blade Material:	Plastic

8. WARRANTY AND SUPPORT

Your BLACK+DECKER Mini Box Fan comes with a **1-year Manufacturer Limited Warranty** covering parts and labor.

For detailed warranty information, product support, or to download the full user manual in PDF format, please visit the official BLACK+DECKER website or refer to the documentation included with your product.

[Download User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question