



Manuals.plus /

› Esperanza /

› Esperanza EGM201B MX201 Wired 7D Optical Gaming Mouse User Manual

Esperanza EGM201B MX201

Esperanza EGM201B MX201 Wired 7D Optical Gaming Mouse User Manual

Model: EGM201B MX201

INTRODUCTION

This manual provides detailed instructions for the Esperanza EGM201B MX201 Wired 7D Optical Gaming Mouse. Please read this manual thoroughly before using the product to ensure proper setup, operation, and maintenance. Keep this manual for future reference.

PRODUCT OVERVIEW

The Esperanza EGM201B MX201 is a wired optical gaming mouse designed for precision and comfort. It features an ergonomic design for extended use and a 7D optical sensor for accurate tracking. The mouse connects via a USB interface.



Image: Front view of the Esperanza EGM201B MX201 Gaming Mouse, showcasing its ergonomic shape and blue LED lighting.



Image: Side view of the Esperanza EGM201B MX201 Gaming Mouse, highlighting the main click buttons and scroll wheel.

SETUP

1. **Unpack the Mouse:** Carefully remove the Esperanza EGM201B MX201 mouse from its packaging. Ensure all components are present.
2. **Connect to Computer:** Locate an available USB port on your computer. Insert the USB connector of the mouse firmly into the USB port.
3. **Driver Installation:** The mouse is typically plug-and-play. Your operating system (e.g., Windows, macOS, Linux) should automatically detect and install the necessary drivers. Wait for the installation process to complete, which usually takes a few seconds.
4. **Verify Functionality:** Once the drivers are installed, move the mouse to check if the cursor responds on your screen. The blue LED lighting on the mouse should illuminate, indicating it is powered on.

OPERATING INSTRUCTIONS

The Esperanza EGM201B MX201 mouse features standard mouse controls for navigation and interaction.

- **Left Click Button:** Used for selecting items, opening files, and primary actions.
- **Right Click Button:** Used for accessing context menus and secondary actions.
- **Scroll Wheel:** Used for scrolling through documents and web pages. It can also function as a middle click button for specific applications.

While the product is marketed as a "7D Optical Gaming Mouse," the specifications indicate 3 buttons. The "7D" likely refers to advanced optical tracking technology rather than additional programmable buttons. For advanced customization or specific gaming functions, please refer to your operating system's mouse settings or any third-party software compatible with generic USB mice.

MAINTENANCE

- **Cleaning:**
 - Disconnect the mouse from your computer before cleaning.
 - Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.
 - Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the mouse's finish.

- For the optical sensor, use a cotton swab lightly dampened with isopropyl alcohol to gently clean the lens. Ensure no liquid enters the mouse's interior.

- **Storage:**

- Store the mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the mouse or its cable to prevent damage.

TROUBLESHOOTING

Problem: Mouse cursor does not move or is unresponsive.

- Ensure the USB cable is securely connected to a working USB port on your computer. Try a different USB port.
- Restart your computer.
- Check the optical sensor on the bottom of the mouse for any obstructions or dirt. Clean if necessary.
- Test the mouse on a different computer to determine if the issue is with the mouse or the computer.

Problem: Cursor movement is erratic or jumpy.

- Ensure you are using the mouse on a clean, non-reflective, and uniform surface. Mouse pads are recommended.
- Clean the optical sensor as described in the Maintenance section.
- Check for any strong light sources directly pointing at the mouse sensor.

Problem: Buttons are not responding.

- Ensure the mouse is properly connected to the computer.
- Restart your computer.
- Check your operating system's mouse settings to ensure buttons are configured correctly.
- If the issue persists, the button may be physically damaged.

SPECIFICATIONS

Feature	Detail
Brand	Esperanza
Model Name	EGM201B MX201
Model Number	5901299925447
Connectivity	Wired USB
Colour	Blue (accents)
Special Features	Ergonomic Design
Number of Buttons	3
Item Weight	0.18 Kilograms
Finish Type	Luminous
Operating System Compatibility	Generic USB mouse compatibility (e.g., Windows, macOS, Linux, Android)
Batteries Required	No

WARRANTY AND SUPPORT

Specific warranty terms and direct support contact information for the Esperanza EGM201B MX201 mouse are not provided in the available product details. For warranty claims or technical support, please refer to the retailer where the product was purchased or visit the official Esperanza website for general support information.

Always retain your proof of purchase for warranty purposes.