ZdalaMit N2QAYB000926

ZdalaMit N2QAYB000926 Replacement Remote Control User Manual

For Panasonic 2014 AS Series Smart LED LCD HD TVs

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your ZdalaMit N2QAYB000926 Replacement Remote Control. This remote is designed to function as a direct replacement for the original Panasonic N2QAYB000926 remote, compatible with various Panasonic 2014 AS series Smart LED LCD HD TVs.
Key Feature: No programming or pairing is required. Simply insert batteries, and the remote is ready for use.

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AA Alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote is ready for immediate use with compatible Panasonic TVs.




MENU
F
INFO
EXIT
HOME
APPS
INPUT
OK
OPTION
RETURN
R
G
Y
B
VOL
MUTE
CH
1@.
2ABC
3DEF
4GHI
5JKL
6MNO
7PQRS
8TUV
9WXYZ
0 *,
NETFLIX
MEDIA
PLAYER
eHELP
LAST
?
N2QAYB000926

Image: Front view of the ZdalaMit N2QAYB000926 Replacement Remote Control, showing all buttons and the model number at the bottom.

3. Operating Instructions

This remote control functions identically to the original Panasonic N2QAYB000926 remote. Point the remote directly at your television's infrared receiver for optimal performance.

3.1 Basic Functions

- **Power Button (●):** Turns the TV on or off.
- **Volume Up/Down (VOL +/-):** Adjusts the sound volume.
- **Channel Up/Down (CH ^/v):** Changes TV channels.
- **Mute:** Silences the TV audio.
- **Number Buttons (0-9):** Direct channel selection.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Home:** Accesses the TV's main menu or smart features.
- **Input:** Selects input sources (HDMI, AV, etc.).
- **Netflix:** Direct access to the Netflix application.
- **Media Player:** Controls media playback functions (Play, Pause, Stop, Fast Forward, Rewind).

For specific functions of other buttons, refer to your Panasonic TV's user manual.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Care

- Replace batteries when the remote's responsiveness decreases.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AA alkaline batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the effective operating range (up to 33 feet).
- **TV Power:** Confirm that the television is powered on.

Note: This replacement remote does not require any programming or pairing. If the remote does not function after installing new batteries and checking the above points, please contact customer support.

6. Specifications

Brand	ZdalaMit
Model Name	N2QAYB000926
Compatible Devices	Panasonic 2014 AS680, AS630, ASU534, AS530, AS520 Series Smart LED LCD HD TVs (e.g., TC-39AS530U, TC-40AS520U, TC-42AS630U, TC-50AS530U, TC-50AS530UE, etc.)
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Connectivity Technology	Infrared
Button Quantity	49
Maximum Range	33 Feet (approx. 10 meters)
Dimensions (L x W x H)	8.54"L x 1.99"W x 0.55"H (approx. 21.7cm x 5.05cm x 1.4cm)
Item Weight	2.5 Ounces (approx. 70.87 grams)

7. Warranty Information

This ZdalaMit remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.
Please retain your proof of purchase for warranty claims.

8. Customer Support

If you have any questions, concerns, or require assistance with your ZdalaMit N2QAYB000926 Replacement Remote Control, please do not hesitate to contact the manufacturer or seller. We are committed to providing support for our products.
Contact information can typically be found on the product packaging or the retailer's website where the item was purchased.

© 2026 ZdalaMit. All rights reserved.