Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit XRS551-C

ZdalaMit XRS551-C Replacement Remote Control User Manual

Model: XRS551-C | Brand: ZdalaMit

1. Introduction

This manual provides instructions for the setup and operation of your ZdalaMit XRS551-C replacement remote control. This remote is designed to function as a direct replacement for various VIZIO Home Theater Soundbar models, offering seamless control without the need for programming or pairing.

2. Package Contents

- 1 x ZdalaMit XRS551-C Replacement Remote Control

Note: AAA batteries and a user manual are not included in the package. This digital manual serves as your comprehensive guide.

3. Setup: Battery Installation

To begin using your remote control, you must install two AAA batteries. Follow these steps:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two 1.5V AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: Battery compartment with AAA batteries installed. Ensure correct polarity.

Once batteries are installed, the remote is ready for immediate use with compatible VIZIO soundbars; no programming or pairing is required.

4. Operating Instructions

The ZdalaMit XRS551-C remote control provides essential functions for your VIZIO soundbar. Refer to the image below for button layout and descriptions.


INPUT
MENU



Figure 4.1: Front view of the ZdalaMit XRS551-C Remote Control.

Button Functions:

- **Power ( ):** Turns the soundbar on or off.
- **INPUT:** Cycles through available audio input sources (e.g., Optical, Bluetooth, AUX).
- **MENU:** Accesses the soundbar's menu for settings adjustments.
- **Navigation Arrows (▲ ▼ ◀ ▶):** Used to navigate through menu options.
- **Play/Pause ( ):** Controls playback for media (e.g., Bluetooth audio).
- **Previous Track ( ):** Skips to the previous track.
- **Next Track ( ):** Skips to the next track.
- **Volume Down (-):** Decreases the soundbar's volume.
- **Mute ( ):** Mutes or unmutes the soundbar's audio.
- **Volume Up (+):** Increases the soundbar's volume.

5. Compatibility

The ZdalaMit XRS551-C replacement remote control is compatible with the following VIZIO Home Theater Soundbar models:

- SB3851C0
- SB3851-C0
- SB3851C0M
- SB3851-C0M
- SB3851D0
- SB3851-D0
- SB4051C0
- SB4051-C0
- SB4051D5
- SB4051-D5

6. Specifications

Feature	Detail
Model Number	XRS551-C
Power Supply	2 x 1.5V AAA Batteries (Not Included)
Connectivity Technology	Infrared (IR)
Maximum Range	33 Feet (approximately 10 meters)
Number of Buttons	11

Feature	Detail
Color	Black
Product Dimensions	13.97 x 3.81 x 1.4 cm
Weight	20 g
Compatible Devices	VIZIO Soundbar Home Theater Systems






Figure 6.1: Remote control dimensions for reference.

7. Troubleshooting

If your ZdalaMit XRS551-C remote control is not functioning as expected, consider the following:

- **Check Batteries:** Ensure that the AAA batteries are inserted correctly with the proper polarity (+/-). Replace old batteries with new ones if the remote is unresponsive.
- **Line of Sight:** The remote control operates using infrared (IR) technology. Ensure there is a clear line of sight between the remote and the soundbar's IR receiver. Obstructions can block the signal.
- **Remote Compatibility:** Verify that your VIZIO soundbar model is listed in the compatibility section (Section 5) of this manual.
- **Soundbar Power:** Ensure your VIZIO soundbar is powered on and not in standby mode.

8. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Care:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

9. Support

For any queries or assistance regarding your ZdalaMit XRS551-C replacement remote control, please contact the seller or manufacturer directly. They can provide further support and guidance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06WWPVSKC

More documents and user manuals: **https://manuals.plus/**