

BANZAI 23524

Banzai Sidewinder Falls Inflatable Water Slide and Water Park

MODEL: 23524

Important Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

Age Recommendation: This water slide is recommended for children aged 5 years and up.

Maximum Weight Capacity: The water slide can accommodate up to 150 lbs at one time.

Adult Supervision Required: Always ensure constant and active adult supervision when the water slide is in use. Never leave children unattended.

Clear Area: Set up the water slide on a level, soft surface, such as grass, free from rocks, sharp objects, or other debris. Ensure adequate clearance from fences, trees, and other structures.

No Diving or Sliding Headfirst: Instruct users to always slide feet first to prevent serious injury.

Water Depth: The splash pool is shallow. Do not dive into the splash pool.

What's in the Box

Your Banzai Sidewinder Falls Water Park package includes the following components:

- Inflatable Water Slide Unit
- Air Blower with GFCI (Ground Fault Circuit Interrupter)
- Storage Bag
- Repair Kit
- Anchor Stakes

Banzai

**INCLUDES
A BLOWER,
STORAGE BAG,
AND REPAIR KIT**



**FOR KIDS AGES
5-12 YEARS OLD;
SUPPORTS
UP TO 150 LBS.
COMBINED USER WEIGHT**

Figure 1: Included components: air blower, storage bag, and repair kit.

Setup Instructions

1. **Choose a Location:** Select a flat, clear, grassy area in your backyard, away from any obstacles, power lines, or sharp objects.
2. **Unroll the Water Slide:** Carefully unroll the inflatable water slide unit in the chosen area.
3. **Connect the Air Blower:** Attach the yellow inflation tube from the water slide to the air blower. Ensure the connection is secure.
4. **Inflate the Slide:** Plug the air blower into a GFCI-protected electrical outlet. Turn on the blower. The water slide will inflate in approximately 3 minutes. The blower must remain on continuously while the water slide is in use.
5. **Secure with Stakes:** Once fully inflated, use the provided anchor stakes to secure the water slide firmly to the ground at all designated points.
6. **Connect Water Hose:** Attach a standard garden hose to the water sprayer connection points on the water slide. Turn on the water supply to activate the sprinklers and fill the splash pool.



Figure 2: Air blower connected to the inflatable water slide.

Your browser does not support the video tag.

Video 1: Official Banzai Sidewinder Falls Water Park setup and usage demonstration. This video illustrates the inflation process, water connections, and various play features of the water park.

Operating Instructions

The Banzai Sidewinder Falls Water Park offers multiple play areas for continuous fun:

- **Climbing Wall:** Users can ascend the climbing wall to reach the top of the slide. Ensure only one person climbs at a time.
- **Curved Waterslide:** Slide down the curved path into the splash pool. Always slide feet first.
- **Secret Tunnel:** Explore the secret tunnel located beneath the main slide structure.
- **Splash Pool:** Enjoy splashing and playing in the integrated splash pool at the base of the slide.

- **Water Sprinklers:** Overhead sprinklers and water sprayers keep the slide surfaces wet and provide additional water play.



Figure 3: Key features of the Sidewinder Falls Water Park.



Figure 4: Children enjoying the various play elements of the water park.

Maintenance

Proper maintenance ensures the longevity and safety of your water slide:

- **Cleaning:** Regularly clean the water slide with mild soap and water. Rinse thoroughly.
- **Drying:** After each use, ensure the entire water slide is completely dry before deflating and storing. This prevents mold and mildew growth. If mold or mildew occurs, a solution of mostly water with a small amount of bleach can be used for cleaning.
- **Inspecting for Damage:** Periodically inspect the inflatable for any punctures, tears, or worn areas. Use the included repair kit for minor repairs.

Storage

To store your water slide:

- 1. **Deflate:** Turn off and unplug the air blower. Allow the water slide to fully deflate.
- 2. **Dry Thoroughly:** As mentioned in maintenance, ensure the unit is completely dry to prevent mold.
- 3. **Fold and Roll:** Carefully fold and roll the deflated water slide to fit into the provided storage bag.
- 4. **Store:** Store the water slide and all accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Water slide does not inflate fully.	Blower not connected properly; Blower not turned on; Power issue; Leak in inflatable.	Ensure blower is securely attached and turned on. Check power supply. Inspect for tears and use repair kit.
Water slide loses air during use.	Blower turned off; Puncture or tear in material.	Ensure blower remains on. Locate and repair punctures using the repair kit.
Water does not spray or fill pool.	Hose not connected; Water supply off; Clogged nozzles.	Connect garden hose securely. Turn on water supply. Check and clear any clogged sprinkler nozzles.
Mold or mildew appears on the slide.	Improper drying before storage.	Clean affected areas with a solution of mostly water and a small amount of bleach. Ensure thorough drying after each use and before storage.

Specifications

- **Product Dimensions (L x W x H):**201.97" x 179.92" x 125.2"
- **Item Weight:** 67 pounds
- **Age Range:** 5 years and up
- **Maximum Weight Recommendation:** 150 Pounds
- **Number of Players:** 3-5
- **Model Number:** 23524
- **UPC:** 191124235246
- **Manufacturer:** Banzai

Warranty and Support

For specific warranty details and customer support, please refer to the documentation included with your product or contact Banzai customer service directly. Information regarding returns and customer support may also be available from your retailer.

Customer Support: For assistance, please contact the seller or manufacturer directly.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question