Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Teamson Home 201605PT

Teamson Home 32.1 inch Wall-Mounted Lion Head Stone LED Outdoor Water Fountain Instruction Manual

Model: 201605PT

1. Introduction

Thank you for purchasing the Teamson Home Wall-Mounted Lion Head Stone LED Outdoor Water Fountain. This manual provides essential information for the safe assembly, operation, and maintenance of your new water feature. Please read all instructions carefully before installation and retain this manual for future reference.





Image 1.1: The Teamson Home Wall-Mounted Lion Head Stone LED Outdoor Water Fountain.

2. Safety Information

To reduce the risk of electric shock, fire, or injury, please observe the following safety precautions:

- Always disconnect the fountain from the power outlet before cleaning, performing maintenance, or moving it.
- Ensure the power cord is not damaged or pinched. Do not operate the fountain with a damaged cord or plug.
- Use only with a properly grounded outdoor wall outlet.
- Do not immerse the pump or electrical components in water beyond their intended design.
- Keep children and pets away from the fountain during operation to prevent accidents.
- Do not attempt to modify or repair any part of the fountain or pump. Contact qualified personnel for service.
- Position the fountain on a stable, level surface or securely mount it to a wall capable of supporting its weight when filled with water.

3. Package Contents

Verify that all components are present before beginning assembly:

- Fountain Unit (Main body with lion head and basins)
- Water Pump with Power Cord
- LED Light Assembly (integrated)
- Assembly Instruction Manual



Image 3.1: Example of a typical water pump and its accessories included with the fountain.

4. Setup and Assembly

Follow these steps to assemble and install your fountain:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Positioning:** Select a suitable location for your fountain. Ensure it is near a grounded electrical outlet and on a stable wall or surface that can support the fountain's weight when filled with water. The fountain measures 18.31 inches W x 9.65 inches D x 32.1 inches H.



Image 4.1: Diagram showing the dimensions of the fountain for proper placement.

3. **Install Pump:** Locate the water pump. Connect the pump's outlet nozzle to the tubing inside the fountain. Ensure a secure connection to prevent leaks.
4. **Fill with Water:** Fill the lower basin of the fountain with distilled water until the pump is fully submerged. Do not overfill.
5. **Connect Power:** Plug the power cord into a grounded outdoor electrical outlet. The pump and LED lights should activate, and water will begin to flow from the lion's mouth into the basins.



Image 4.2: The fountain installed on a stone wall, demonstrating a typical setup.

6. **Adjust Water Flow (if applicable):** Some pumps have an adjustable flow rate. If your pump has this feature, adjust it to achieve your desired water flow.

5. Operating Instructions

Operating your Teamson Home fountain is straightforward:

- **Power On/Off:** Plug the fountain into a grounded outlet to turn it on. Unplug it to turn it off.
- **Water Level:** Regularly check the water level. Due to evaporation, water levels will decrease over time. Refill with distilled water as needed to ensure the pump remains fully submerged. Operating the pump without sufficient water can cause damage.
- **LED Lights:** The fountain features integrated LED lighting that illuminates the cascading water, enhancing its visual appeal, especially in low-light conditions. These lights operate automatically when the fountain is powered on.




Image 5.1: Visual representation of the fountain's sculpted details, two-tier water flow, and integrated LED lights.

6. Maintenance

Regular maintenance will prolong the life and appearance of your fountain:

- **Cleaning:** Periodically clean the fountain and pump. Disconnect power, drain the water, and use a soft brush or cloth with mild soap and water to clean surfaces. Rinse thoroughly.
- **Pump Cleaning:** Remove the pump and clean any debris from its intake screen and impeller. This prevents blockages and ensures optimal water flow.



Image 6.1: Close-up view of water flowing into the fountain's basin, showing the protective mesh screen.

- **Water Quality:** Use distilled water to minimize mineral buildup and algae growth. If using tap water, consider adding a fountain algaecide or clarifier.
- **Winterization:** In freezing climates, drain all water from the fountain and pump before the first frost. Clean and store the pump indoors. Cover the fountain or store it in a sheltered location to prevent damage from ice expansion.

7. Troubleshooting

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
Fountain not operating	No power; pump clogged; insufficient water.	Check power connection; clean pump; add water.

Problem	Possible Cause	Solution
Water flow is weak	Pump clogged; low water level; kinked tubing.	Clean pump; add water; straighten tubing.
Excessive splashing	Water level too high; pump flow too strong.	Reduce water level; adjust pump flow (if applicable).
LED lights not working	Loose connection; damaged LED unit.	Check connections; contact support if damaged.

8. Specifications

- **Model Number:** 201605PT
- **Dimensions (L x W x H):** 18.31" x 9.65" x 32.09" (46.5 cm x 24.5 cm x 81.5 cm)
- **Item Weight:** 17.64 pounds (8 kg)
- **Material:** Polyresin (90%), Fiberglass (5%), Plastic (4.5%), Metal (0.5%)
- **Color:** Antique Bronze
- **Power Source:** Corded Electric
- **Special Features:** Durable, Lighted, Lightweight
- **Assembly Required:** Yes
- **UPC:** 816780021346

9. Warranty and Support

This Teamson Home fountain comes with a **30-day warranty** against manufacturer defects. For warranty claims or technical support, please contact Teamson Home customer service. Keep your proof of purchase for warranty validation. For further assistance, please visit the Teamson Home Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06X1F33K3

More documents and user manuals: **https://manuals.plus/**