**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Hasbro Gaming C16791010

# Hasbro Gaming La Bonne Paye Electronic Board Game Instruction Manual

Model: C16791010

## Introduction

Welcome to La Bonne Paye Electronic, the classic game of managing your finances with a modern electronic twist. This game challenges players to manage their budget, pay taxes, collect wages, and navigate various events to become the richest player by the end of the game. This manual provides detailed instructions for setup, gameplay, and maintenance.

The game is designed for 2 to 4 players, with a recommended age range of 8 years and up.

## Components

Before starting, ensure all components are present:

- 1 x Game Board
- 1 x Electronic Banking Unit
- 4 x Player Pawns (multicoloured)
- 4 x Electronic Bank Cards
- Dice
- Event Cards
- Acquisition Cards
- Mail Cards
- Instruction Manual (this document)




Image: All game components for La Bonne Paye Electronic, including the game board, electronic banking unit, player pawns, bank cards, and various card decks, are displayed on a table.

## Setup

1. **Place the Game Board:** Unfold the game board and place it on a flat playing surface.
2. **Electronic Banking Unit:** Insert 2x AAA batteries (not included) into the electronic banking unit. Turn it on. Each player selects a bank card and inserts it into the unit to register their starting balance.
3. **Player Pawns:** Each player chooses a pawn and places it on the "Start" space on the game board.
4. **Card Decks:** Shuffle the Event, Acquisition, and Mail cards separately. Place each deck face down on their designated spaces on the game board.
5. **Dice:** Place the dice near the game board.




Image: The Hasbro La Bonne Paye Electronic game box is shown alongside the fully set up game board, electronic banking unit, various card decks, and player pawns, ready for play.

## Operating Instructions (How to Play)

### Game Objective:

The goal of La Bonne Paye Electronic is to be the player with the most money at the end of the game. Players earn money through wages, investments, and lucky events, while also managing expenses like bills, taxes, and unexpected costs.

### Gameplay Overview:

Players take turns moving around the game board, landing on spaces that trigger various actions. These actions involve drawing cards, paying or receiving money, or making decisions that affect their financial standing.

### Player Turn Sequence:

1. **Roll the Dice:** The current player rolls the dice and moves their pawn clockwise the corresponding number of spaces.
2. **Land on a Space:** Follow the instructions on the space where your pawn lands. This may include:
    - **Pay Day:** If you pass or land on a "Pay Day" space, collect your monthly wage using the electronic banking unit.
    - **Event Space:** Draw an Event card and follow its instructions.

- **Mail Space:** Draw a Mail card and follow its instructions.
- **Acquisition Space:** You may have the option to buy an Acquisition card (e.g., property, investment).
- **Bill/Tax Space:** Pay the specified amount using the electronic banking unit.

3. **Electronic Transactions:** All money transactions (paying, receiving, transferring) are handled by the electronic banking unit. Insert your bank card and follow the prompts on the unit.
4. **End of Turn:** Once all actions for the space are completed, the turn passes to the next player clockwise.

### Game End:

The game ends after a predetermined number of months (e.g., 6 or 12 months, as agreed upon by players or specified in advanced rules). At the end of the final month, players calculate their total wealth (money in their bank account plus the value of any acquisitions). The player with the highest total wealth wins.

## Maintenance

- **Cleaning:** Wipe the game board, electronic unit, and plastic components with a soft, dry cloth. Do not use abrasive cleaners or immerse the electronic unit in water.
- **Storage:** Store all game components in their original box in a cool, dry place away from direct sunlight.
- **Battery Care:** Remove batteries from the electronic banking unit if the game will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly.
- **Card Care:** Handle game cards carefully to prevent bending or tearing.

## Troubleshooting

| Problem | Solution |
|---|---|
| Electronic unit does not turn on. | Check if batteries are inserted correctly. Replace with fresh AAA batteries. |
| Electronic unit displays an error during transaction. | Ensure the bank card is fully inserted and clean. Try re-entering the transaction. If the problem persists, reset the unit by turning it off and on. |
| Game cards are damaged or missing. | Contact Hasbro customer support for replacement parts. |

## Specifications

- **Model Name:** La Bonne Paye Electronique
- **Model Number:** C16791010
- **Brand:** Hasbro Gaming
- **Age Range:** 8 years and up (Manufacturer Minimum Age: 96 months)
- **Number of Players:** 2 to 4 players
- **Power Source:** Batteries (2x AAA required for electronic unit, not included)
- **Material:** Paper, Cardboard, Plastic
- **Item Dimensions:** Approximately 26.7 x 5 x 40 cm (Package size)
- **Educational Objective:** Learn, share, have fun, financial management

## Warranty and Support

For warranty information, replacement parts, or further assistance, please refer to the official Hasbro Gaming website or contact their customer support directly. Keep your proof of purchase for any warranty claims.

**Manufacturer:** HASBRO FRANCE

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B06X9RJ492**

More documents and user manuals: **https://manuals.plus/**