

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /


- › [Pure Enrichment](#) /
- › [Pure Enrichment PureClean XL Rolling Steam Cleaner \(PEROLSTM\) Instruction Manual](#)

Pure Enrichment PEROLSTM

Pure Enrichment PureClean XL Rolling Steam Cleaner (PEROLSTM) Instruction Manual

INTRODUCTION

The Pure Enrichment PureClean XL Rolling Steam Cleaner provides a chemical-free solution for deep cleaning various surfaces in your home and vehicle. This manual contains important information regarding the safe operation, maintenance, and troubleshooting of your steam cleaner. Please read it thoroughly before first use and retain it for future reference.



Chemical-Free Rolling Steamer

Heats up to 208°F in 8 minutes
to deep clean your home.

Image: The PureClean XL Rolling Steam Cleaner with its main body, hose, and floor cleaning attachment.

PRODUCT COMPONENTS

Your PureClean XL Rolling Steam Cleaner comes with a comprehensive set of accessories designed for various cleaning tasks:

- Rolling Steam Cleaner Unit
- Mop Head
- Microfiber Mop Pads (2)
- Triangle Brush
- Steam Jet Nozzle
- Squeegee
- Nylon Utility Brushes (5)
- Brass Utility Brush
- Scrub Pad
- Extension Wands (2)
- Measuring Cup

- Funnel



Image: A visual representation of the PureClean XL Rolling Steam Cleaner and all its included accessories, laid out on a wooden floor.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Ensure the unit is unplugged and cool. Unscrew the safety cap. Use the provided measuring cup and funnel to fill the 1.5-liter water tank with distilled water. Do not overfill. Securely replace the safety cap.
3. **Attach Accessories:** Select the appropriate accessory for your cleaning task. Connect the desired attachment (e.g., extension wands, mop head, steam jet nozzle) to the steam gun until it clicks securely into place.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Easy To Use & Maneuver



Image: A diagram highlighting key components and controls of the steam cleaner, including the ergonomic handle, continuous steam switch, steam button, 1.5-liter boiler, on/off switch, and easy-roll wheels.

OPERATING INSTRUCTIONS

1. **Power On:** Press the On/Off switch to turn on the unit. The indicator light will illuminate.
2. **Heating Time:** Allow approximately 8 minutes for the 1.5L tank to heat the water to 208°F and produce steam. The indicator light may change or turn off when ready, depending on the model.
3. **Steam Activation:** Press the steam button on the handle to release steam. For continuous steam, engage the steam lock switch.
4. **Cleaning Surfaces:**
 - **Floors:** Attach the mop head with a microfiber pad. Move the mop head slowly over the floor surface to allow steam to penetrate and clean.
 - **Upholstery/Fabrics:** Use the steam jet nozzle or a brush attachment. Hold the nozzle a few inches away from the fabric and move it steadily. Test on an inconspicuous area first.
 - **Grout/Tight Spaces:** Use the nylon or brass utility brushes with the steam jet nozzle for concentrated cleaning.
 - **Windows/Glass:** Attach the squeegee tool. Apply steam and then wipe with the squeegee for streak-

free results.

- **Kitchen Appliances/Grills:** Use appropriate brush attachments to loosen grease and grime with steam, then wipe clean.

5. **Continuous Cleaning:** The 1.5L tank provides up to 45 minutes of continuous steam.

6. **Refilling:** If the steam output decreases or stops, the water tank may be empty. Turn off and unplug the unit, allow it to cool for a few minutes, then carefully unscrew the safety cap and refill with distilled water.

Your browser does not support the video tag.

Video: Official product video demonstrating the PureClean XL Rolling Steam Cleaner in use for various cleaning tasks around the home.



Image: A collage showing the steam cleaner effectively cleaning upholstery, floors, tile, windows, grease on a stovetop, and carpet.

MAINTENANCE

- **Draining Water:** After each use, ensure the unit is cool and unplugged. Carefully unscrew the safety cap and drain any remaining water from the tank.

- **Cleaning Accessories:** Wash microfiber pads and scrub pads as needed. Nylon and brass brushes can be rinsed with water. Ensure all accessories are dry before storing.
- **Descaling:** Over time, mineral deposits may build up in the boiler. To descale, fill the tank with a mixture of 50% white vinegar and 50% water. Let it sit for several hours or overnight, then drain and rinse thoroughly. Run a tank of clean distilled water through the unit before next use.
- **Storage:** Store the steam cleaner in a cool, dry place. The hose can be wrapped around the handle, and the power cord has a built-in wrap for compact storage.



Image: The PureClean XL Rolling Steam Cleaner stored with its hose wrapped around the handle, demonstrating its compact design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty; Unit not heated sufficiently; Mineral buildup.	Refill water tank; Allow 8 minutes for heating; Descale the unit.

Problem	Possible Cause	Solution
Water leaking from attachments	Attachment not securely connected; O-ring damaged.	Ensure attachment is clicked into place; Contact customer support for replacement parts.
Unit not turning on	Not plugged in; Power outlet issue.	Check power connection; Test outlet with another appliance.

SPECIFICATIONS

Feature	Detail
Brand	Pure Enrichment
Model Name	PEROLSTM
UPC	853975005934
Tank Volume	1.5 Liters
Heating Time	Approx. 8 minutes
Continuous Steam Time	Up to 45 minutes
Steam Temperature	208°F
Wattage	120W
Item Weight	15.4 Pounds
Power Source	AC
Cord Length	16 ft (4.8 m)
Special Feature	Steam Lock Switch

WARRANTY AND SUPPORT

The Pure Enrichment PureClean XL Rolling Steam Cleaner is backed by a **5-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or to inquire about replacement parts, please contact Pure Enrichment customer support.

For further assistance, please visit the official Pure Enrichment website or refer to the contact information provided in your product packaging.

Note: Always use distilled water to prolong the life of your steam cleaner and prevent mineral buildup, which may not be covered under warranty.