Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC 11005 (Compatible with LT-55UE76, 48C6)

JVC LT-55UE76 48C6 TV Base Stand 11005 Instruction Manual

Model: 11005 (Compatible with LT-55UE76, 48C6)
Brand: JVC

Introduction

This manual provides detailed instructions for the assembly, installation, and maintenance of your JVC LT-55UE76 48C6 TV Base Stand, model 11005. Please read this manual thoroughly before proceeding with installation to ensure proper setup and safe operation. This stand is designed specifically for JVC LT-55UE76 and 48C6 television models.

Important Safety Information

- Always ensure the TV is placed on a stable, level surface.
- Do not exceed the weight capacity of the stand. This stand is designed for specific JVC TV models.
- Keep small parts, such as screws, out of reach of children to prevent choking hazards.
- Ensure all screws are securely tightened during assembly. Overtightening may cause damage.
- If you encounter any difficulties during installation, consult a qualified technician.
- Do not attempt to modify the stand in any way.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact JVC customer support.

- JVC TV Base Stand (2 main components)
- Mounting Screws (Quantity and type as required for your specific TV model)

Setup and Installation

Follow these steps carefully to assemble and install the TV base stand.

Step 1: Identify Stand Components

Unpack the stand components. You should have two main metal pieces that form the base. Observe their shape and how

they are designed to interlock.




Image: The two distinct metal components of the JVC TV base stand, ready for assembly.

Step 2: Interlock the Stand Pieces

Carefully align the two stand pieces. One piece will have a slot or opening designed to receive a protrusion or tab from the other piece. Gently slide them together until they interlock securely. You may hear a click or feel them seat firmly.



Image: A detailed view of the interlocking section of the stand, highlighting the connection point and a screw hole for securing.

Step 3: Secure the Interlocked Pieces (if applicable)

Some stand designs may require a screw to secure the two interlocked pieces together. If there is a designated screw hole at the interlocking point (as shown in the image), insert the appropriate screw and tighten it firmly with a screwdriver. Do not overtighten.

Step 4: Attach Stand to TV

1. Place your JVC LT-55UE76 or 48C6 TV face down on a soft, clean surface to prevent screen damage. Ensure you have enough space and assistance if needed.
2. Locate the mounting holes on the bottom rear of your television. These are typically where the original stand or VESA mount would attach.
3. Align the assembled base stand with these mounting holes. The stand should fit flush against the TV's bottom panel.
4. Insert the provided mounting screws into the designated holes on the stand and into the TV's mounting points.
5. Using a screwdriver, tighten all screws securely. Ensure the stand is firmly attached and does not wobble.

Step 5: Position the TV

With the stand securely attached, carefully lift the TV and place it upright on a stable, level surface, such as a TV cabinet or entertainment center. Ensure the TV is balanced and not prone to tipping.

Usage

Once installed, the JVC TV Base Stand provides a stable foundation for your television. Ensure the TV is placed in a location where it will not be easily bumped or knocked over. Keep the area around the TV clear to allow for proper ventilation.

Maintenance

To maintain the appearance and integrity of your TV stand:

- Clean the stand with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents, as these can damage the finish.
- Periodically check all screws to ensure they remain tight.

Troubleshooting

Problem	Possible Cause	Solution
Stand is wobbly after installation.	Screws are not fully tightened. Stand not properly interlocked.	Ensure all screws attaching the stand to the TV and any internal stand screws are securely tightened. Re-check that the two stand components are fully interlocked.
Stand does not fit the TV.	Incorrect TV model or stand model.	Verify that your TV model is either LT-55UE76 or 48C6. This stand is specifically designed for these models. If your TV is a different model, this stand may not be compatible.
Missing parts (e.g., screws).	Packaging error.	Contact JVC customer support for assistance.

Specifications

Model Number	11005 (Compatible with JVC LT-55UE76 and 48C6 TV models)
Brand	JVC
Material	Metal
UPC	604296568598
Manufacturer	JVC
Date First Available	February 25, 2017

Warranty and Support

For information regarding warranty coverage, technical support, or to purchase replacement parts, please contact JVC customer service directly. Refer to your original TV purchase documentation or the official JVC website for contact details.
You can visit the official JVC store on Amazon for more products and information:JVC Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XBKHGZ7

More documents and user manuals: **https://manuals.plus/**