

[Manuals.plus](#) /

› [Djeco](#) /

› DJECO DJ08779 Floating Boats Origami Craft Kit Instruction Manual

## Djeco DJ08779

# DJECO DJ08779 Floating Boats Origami Craft Kit

## INSTRUCTION MANUAL

### 1. Overview

The DJECO DJ08779 Floating Boats Origami Craft Kit provides an engaging activity for children aged 6 and above. This kit allows users to create a flotilla of unique paper boats complete with decorative elements. It is designed to foster fine motor skills, dexterity, patience, and creative expression through the art of origami.

### 2. Safety Information

**WARNING: CHOKING HAZARD – Small parts. Not suitable for children under 3 years. Adult supervision is recommended during assembly and play.**

### 3. Package Contents

Please verify that all the following components are included in your kit:

- 15 sheets of printed origami paper
- 18 individual sailor/character cutouts
- 5 sails
- 15 unique flags
- 40 decorative stickers
- 1 spool of string (approximately 2 meters)
- 1 instruction booklet

NIVEAU

3



2m




x5



x5



x5



x1



x2



x2

Image 1: Complete contents of the DJECO Floating Boats Origami Craft Kit. It includes stacks of patterned origami paper, a spool of orange string, sheets of pre-cut character figures, sails, flags, and various decorative stickers. A 'NIVEAU 3' (Level 3) indicator is visible, suggesting the complexity level.

## 4. Setup

Before beginning assembly, ensure you have a suitable workspace:

1. Unpack all components from the kit and confirm all listed items are present.
2. Prepare a clean, flat, and well-lit surface for crafting.
3. Carefully read through the entire instruction booklet provided before starting the folding process.

## 5. Assembly Instructions

Follow these general steps to assemble your floating boats. Refer to the included instruction booklet for detailed, step-by-step folding diagrams specific to each boat design.




Image 2: The instruction booklet included in the kit. The cover features an illustration of finished boats. An open page displays step-by-step diagrams for folding the origami boats, labeled 'A', 'B', and 'C', demonstrating the progression of the folding process.

1. **Select Paper:** Choose one sheet of printed origami paper for your boat.
2. **Fold the Boat:** Carefully follow the step-by-step diagrams in the instruction booklet to fold the paper into the desired boat shape. Pay close attention to creases and alignment for the best results.
3. **Add Characters:** Once the boat is folded, select an individual sailor or character cutout. Insert the character into the designated slot or position within the boat, as shown in the instructions.
4. **Attach Sails and Flags:** Use the provided string to create rigging for sails, if applicable. Attach sails and flags to the boat using the string and/or stickers, following the guidance in the instruction booklet or your own creative design.
5. **Decorate:** Further personalize your boat using the included decorative stickers.



Image 3: Examples of completed origami floating boats. Each boat features distinct paper patterns, a unique character figure (such as a pirate or captain), and various decorative elements like sails and flags, showcasing the creative possibilities of the kit.

## 6. Maintenance

To ensure the longevity of your finished paper boats:

- Store the finished boats in a dry place, away from direct sunlight, to prevent fading or damage to the paper and colors.
- Avoid contact with water, as this is a paper craft kit and water will damage the materials.
- Handle the boats gently, as they are delicate paper constructions.

## 7. Troubleshooting

- **Difficulty with folding:** Refer to the instruction booklet's diagrams carefully. If a step is unclear, try unfolding and re-folding slowly. Online origami tutorials for basic boat shapes may also be helpful.
- **Missing parts:** Verify all components against the 'Package Contents' list. If any essential parts are missing, contact Djeco customer support.

- **Stickers not adhering:** Ensure the surface is clean and dry before applying stickers. Press firmly for good adhesion.

## 8. Specifications

|                             |                                                                                                        |
|-----------------------------|--------------------------------------------------------------------------------------------------------|
| Brand                       | Djeco                                                                                                  |
| Model Number                | DJ08779                                                                                                |
| Age Range                   | 6 years and up                                                                                         |
| Material                    | Primarily Paper (kit components)                                                                       |
| Item Dimensions (L x W x H) | 21.6 x 1 x 24.1 cm (packaging)                                                                         |
| Item Weight                 | 0.53 Pounds (approx. 240g)                                                                             |
| Included Components         | Craft kit (15 origami sheets, 18 sailors, 5 sails, 15 flags, 40 stickers, string, instruction booklet) |

## 9. Warranty and Support

For product support, inquiries, or to report missing components, please contact Djeco customer service. Refer to the product packaging or Djeco's official website for specific contact details and any applicable warranty information.

© 2023 Djeco. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**