

[Manuals.plus](#) /

> [INJUSA](#) /

> Injusa 6775 Kawasaki 6V Electric Motocross for Children - Instruction Manual

INJUSA 6775

Injusa 6775 Kawasaki 6V Electric Motocross for Children - Instruction Manual

Model: 6775 | Brand: INJUSA

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Injusa 6775 Kawasaki 6V Electric Motocross. This manual provides essential information for the safe assembly, operation, and maintenance of your child's new electric motorcycle. Please read it thoroughly before use and retain it for future reference.

This 6V Kawasaki motocross features a modern and realistic design, capable of reaching speeds of 5-6 km/h. It includes a 6V battery, charger, and training wheels for enhanced stability, making it ideal for young riders.

- **Realistic Design:** Authentic Kawasaki motocross styling.
- **Speed:** Achieves speeds of 5-6 km/h.
- **Stability:** Equipped with training wheels for beginner riders.
- **Electric Brake:** For safe stopping.
- **Throttle Grip:** Easy acceleration control.

2. SAFETY INFORMATION

WARNING: ADULT SUPERVISION IS REQUIRED AT ALL TIMES.

- This product is suitable for children aged 36 months (3 years) to 6 years.
- Maximum user weight: 30 kg.
- Always ensure the child wears appropriate protective gear, including a helmet, knee pads, and elbow pads.
- Do not use on public roads, near vehicles, on steep slopes, or near bodies of water.
- Only use on flat, dry surfaces. Avoid rough terrain or obstacles.
- Regularly check all bolts, nuts, and connections to ensure they are secure.
- Do not allow children to touch the wheels or other moving parts while the vehicle is in motion.
- The vehicle is equipped with safety belts (if applicable). Ensure they are fastened before use.

3. PACKAGE CONTENTS

Carefully unpack all components and check against the list below. If any parts are missing or damaged, contact customer support.

- Motocross body
- Front wheel
- Handlebars
- Front fender
- Training wheels (2)
- 6V Battery
- Battery Charger
- Assembly tool (wrench)
- Instruction Manual
- Hardware pack (screws, bolts, etc.)



Image: All components included in the package, ready for assembly.

4. SETUP AND ASSEMBLY

Assembly should be performed by an adult. Follow these steps carefully:

1. **Attach the Front Wheel:** Secure the front wheel to the front fork using the provided axle and fasteners.
2. **Install the Handlebars:** Insert the handlebars into the steering column and tighten the bolts securely with the included wrench.
3. **Mount the Front Fender:** Attach the front fender to the front fork.
4. **Attach Training Wheels:** Securely fasten the training wheels to the rear axle of the motocross. These can be removed once the child gains confidence and balance.
5. **Connect Battery:** Locate the battery compartment (usually under the seat). Connect the battery terminals as indicated in the manual.

Note: The assembly process is straightforward and typically takes about 30 minutes. All necessary accessories and hardware are separately packaged for convenience.

Kawasaki



Image: Fully assembled Injusa 6775 Kawasaki 6V Electric Motocross.

Assembly and Operation Video (Similar Model)

Video: This video demonstrates the assembly and basic operation of a similar electric motocross model. While not identical to the Injusa 6775, it provides helpful visual guidance for the setup process, including unboxing, identifying parts, and securing components. It also shows the location of controls and how a child interacts with the bike.

5. OPERATING INSTRUCTIONS

The Injusa 6775 is designed for simple and intuitive operation.

1. **Power On/Off:** Locate the main power button (usually a red button with a power symbol) on the dashboard. Press to turn the motocross on or off.
2. **Speed Selection:** The motocross offers two speed settings: 'High' and 'Low'. Use the dedicated buttons on the dashboard to select the desired speed. This allows the child to gradually get accustomed to the vehicle.
3. **Acceleration:** To move forward, twist the throttle grip on the right handlebar.
4. **Braking:** The motocross features an electric brake. Releasing the throttle grip will automatically engage the brake, bringing the vehicle to a stop.



Image: Close-up of the handlebars and control panel, showing the power button and speed selection.



Image: Child operating the motocross, demonstrating its use in an outdoor setting.

6. CHARGING THE BATTERY

The motocross is powered by a 6V rechargeable battery. Proper charging ensures optimal performance and battery longevity.

- **First Charge:** Before initial use, charge the battery for 8-10 hours. Do not exceed 10 hours.
- **Subsequent Charges:** A full charge typically takes 6 hours.
- **Charging Port:** The charging port is located under the seat. Lift the seat to access it.
- **Battery Indicator:** The dashboard includes a battery indicator to show the remaining charge level.
- **Autonomy:** A fully charged battery provides approximately 45 minutes of continuous use, depending on terrain and speed.
- Always use the original charger provided with the product.
- Do not charge the battery for more than 10 hours to avoid damage.

7. MAINTENANCE

Regular maintenance will extend the life of your electric motocross.

- **Cleaning:** Wipe the motocross with a damp cloth. Do not use abrasive cleaners or immerse the vehicle in water.
- **Battery Care:** Store the battery in a cool, dry place. If not used for an extended period, charge the battery at least once a month to maintain its health.
- **Check Connections:** Periodically inspect all electrical connections and ensure they are secure.
- **Fasteners:** Regularly check and tighten all bolts and screws to ensure the structural integrity of the motocross.
- **Tires:** Inspect tires for wear and tear. Ensure training wheels are securely attached if in use.

8. TROUBLESHOOTING

If you encounter issues, refer to this section before contacting customer support.

Problem	Possible Cause	Solution
Motocross does not start	Battery is low or not connected; Power switch is off; Loose wiring.	Charge the battery; Ensure power switch is on; Check all electrical connections.
Motocross moves slowly	Low battery; Overload (child too heavy); Used on rough terrain.	Charge the battery; Ensure child's weight is within limits; Use on flat, smooth surfaces.
Charger not working	Charger or outlet faulty.	Check the power outlet; Try a different charger if available; Contact customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	INJUSA
Model Number	6775
Material	Plastic
Product Dimensions (L x W x H)	111 cm x 56 cm x 76 cm
Item Weight	11 Kilograms
Maximum Weight Capacity	30 Kilograms
Maximum Speed	5-6 km/h
Battery	6V

Feature	Detail
Recommended Age	36 months to 6 years
Assembly Required	Yes (Minor assembly)




Image: Product dimensions for reference.

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions.

For technical support, replacement parts, or any other inquiries, please contact Injusa customer service through their official website or the retailer where the product was purchased.

Contact Information:

- **Brand Website:** www.injusa.com
- **Retailer Support:** Refer to your purchase receipt for retailer contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B06XC55W8F>

More documents and user manuals: <https://manuals.plus/>