

[Manuals.plus](#) /

› [Bose](#) /

› Bose SoundLink Revolve Portable Bluetooth Speaker User Manual

Bose 739523-1110

Bose SoundLink Revolve Portable Bluetooth Speaker User Manual

Model: 739523-1110

INTRODUCTION

The Bose SoundLink Revolve is engineered to deliver deep, loud, and immersive sound with true 360-degree coverage. Its tapered cylindrical shape makes it easy to grab and go, while its durable aluminum body and water-resistant design (IPX4) ensure worry-free protection. Enjoy up to 12 hours of playtime from its rechargeable lithium-ion battery.





Image: The Bose SoundLink Revolve speaker in Triple Black, showcasing its cylindrical design and speaker grille.

KEY FEATURES

- **360-Degree Sound:** Delivers consistent, immersive audio in every direction.
- **Built-in Microphone:** For clear conference or personal calls with approximately 30 feet wireless range.
- **Durable and Water-Resistant:** Seamless aluminum body with IPX4 water resistance.
- **Long Battery Life:** Up to 12 hours of playtime from a rechargeable lithium-ion battery.
- **Voice Prompts:** Guides you through wireless Bluetooth pairing.
- **Voice Assistant Access:** Easily access Siri or Google Now directly from the speaker.
- **Party & Stereo Mode:** Pair two SoundLink speakers for enhanced performance or immersive stereo sound.

- **Bose SimpleSync Technology:** Pair with Bose Smart Home Family devices for synchronized playback.
- **Auxiliary Input:** Allows connection to other audio sources.



Image: The Bose SoundLink Revolve speaker providing ambient music for a group of friends.

WHAT'S IN THE BOX

- Bose SoundLink Revolve Bluetooth speaker
- USB cable
- Wall charger

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the USB cable to the speaker's Micro B USB port and the wall charger. A full charge provides up to 12 hours of playtime.





Image: The bottom section of the speaker, highlighting the charging port and auxiliary input.

2. Powering On/Off

Press the **Power button** located on the top of the speaker to turn it on or off.





Image: Top panel of the speaker showing the power, Bluetooth, source, volume, and multi-function buttons.

3. Bluetooth Pairing

1. Turn on the speaker. A voice prompt will indicate "Ready to pair" and the Bluetooth indicator light will blink blue.
2. On your mobile device, enable Bluetooth and select "Bose Revolve" from the list of available devices.
3. Once connected, a voice prompt will confirm "Connected to [Device Name]" and the Bluetooth indicator light will glow solid white.
4. To pair another device, press and hold the **Bluetooth button** until the indicator blinks blue again.

OPERATING INSTRUCTIONS

Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the top of the speaker to adjust the audio level. You can also control the volume from your connected device.

Source Selection

Press the **Source button** (circular arrow icon) to switch between Bluetooth and auxiliary input sources.

Voice Assistant / Speakerphone

Press the **Multi-function button** (three dots icon) to activate your device's voice assistant (Siri or Google Now) or to answer/end calls when using the built-in speakerphone.

Party Mode & Stereo Mode

For an enhanced audio experience, you can pair two SoundLink Revolve speakers using the Bose Connect app. This allows you to play audio in:

- **Party Mode:** Play the same audio on both speakers simultaneously for wider coverage.
- **Stereo Mode:** Designate one speaker as the left channel and the other as the right channel for a true stereo sound experience.

MAINTENANCE

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use any solvents or chemicals. Ensure all ports are dry before charging.



Image: The speaker's top surface covered in water droplets, illustrating its water-resistant design.

Water Resistance

The SoundLink Revolve is IPX4 water-resistant, meaning it can withstand splashes of water. It is not designed to be submerged in water.

TROUBLESHOOTING

No Power

- Ensure the battery is charged. Connect the speaker to the wall charger.
- Press the Power button firmly.

Bluetooth Connection Issues

- Make sure the speaker is in pairing mode (blinking blue Bluetooth indicator).
- Ensure your device's Bluetooth is enabled and within range (approx. 30 feet).
- Forget "Bose Revolve" from your device's Bluetooth settings and try pairing again.
- Restart both the speaker and your Bluetooth device.

No Sound or Low Volume

- Increase the volume on both the speaker and your connected device.
- Ensure the correct source is selected (Bluetooth or Aux).
- If using Aux, ensure the cable is fully inserted and functional.

SPECIFICATIONS

Feature	Detail
Brand	Bose
Model Name	SoundLink Revolve
Model Number	739523-1110
Color	Triple Black
Dimensions	3.3"D x 3.3"W x 6"H
Item Weight	1.5 Pounds (1.46 pounds)
Connectivity Technology	Bluetooth, Auxilliary
Wireless Communication Technology	Bluetooth
Bluetooth Range	30 Feet
Battery Life	Up to 12 Hours
Water Resistance Level	IPX4 (Water Resistant)

Audio Output Mode	Surround, Stereo
Speaker Type	Portable Bluetooth Speaker




Image: Dimensions of the Bose SoundLink Revolve speaker.

WARRANTY & SUPPORT

The Bose SoundLink Revolve comes with a Limited Warranty. For detailed warranty information and support, please refer to the official Bose website or the user manual provided with your product.

You can also visit the [Bose Store on Amazon](#) for additional product information and accessories.

For a comprehensive user guide, you may download the official PDF manual:[User Guide \(PDF\)](#).

© 2024 Bose Corporation. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question