

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Spirit Of Gamer](#) /
- › [Spirit of Gamer Race Wheel Pro 2 User Manual for Multi-Platform Gaming](#)

## Spirit Of Gamer SOG-RWP2

# Spirit of Gamer Race Wheel Pro 2 User Manual

Model: SOG-RWP2

## 1. INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Spirit of Gamer Race Wheel Pro 2. This multi-platform racing wheel and pedal set is designed to offer an immersive driving experience across various gaming systems.

The Race Wheel Pro 2 is compatible with Nintendo Switch, PlayStation® 4, Xbox One®, PlayStation® 3, and PC.



Image 1.1: Front view of the Spirit of Gamer Race Wheel Pro 2, showcasing the steering wheel with integrated buttons and the central Spirit of Gamer logo.

## 2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Spirit of Gamer Race Wheel Pro 2 Steering Wheel
- Pedal Set (Accelerator and Brake)
- Table Clamp
- User Manual (this document)

## 3. COMPONENTS IDENTIFICATION

Familiarize yourself with the main components of your Race Wheel Pro 2:

- **Steering Wheel:** Features a Grip Control coating for enhanced comfort and control. Offers a 180°

steering angle.

- **Paddle Shifters:** Located behind the steering wheel for sequential gear changes.
- **Gear Lever:** For manual gear shifting.
- **Pedal Set:** Includes accelerator and brake pedals with a dual-spring mechanism for realistic feel.
- **Buttons:** 8 analog buttons, 4 digital buttons, and 8 programmable buttons. A dedicated Home button provides direct access to system settings.
- **D-Pad:** A precise 8-way directional pad.
- **Vibration Motors:** Dual vibration motors provide immersive force feedback.
- **USB Connection Cable:** 1.80m cable for connecting to your gaming system.
- **USB Port on Wheel:** Used for connecting a controller for PS4/Xbox One compatibility.



Image 3.1: The Spirit of Gamer Race Wheel Pro 2 shown alongside its pedal unit, illustrating the complete racing setup.

## 4. SETUP

### 4.1 Mounting the Racing Wheel

The Race Wheel Pro 2 offers two methods for secure mounting:

1. **Suction Cups:** The base of the wheel features 7 suction cups. Place the wheel on a clean, smooth, flat surface (e.g., a table or desk) and press down firmly to engage the suction cups for a stable grip.
2. **Table Clamp:** For enhanced stability, use the included table clamp. Attach the clamp to the front edge of your table and tighten the screw until the wheel is securely fastened.



Image 4.1: Side view of the racing wheel demonstrating its secure attachment to a table using the included clamp.

## 4.2 Connecting the Pedal Set

Connect the cable from the pedal set to the designated port on the back of the racing wheel.

## 4.3 Platform-Specific Connection Instructions

Follow the instructions below for connecting your Race Wheel Pro 2 to your desired gaming platform:

- **PlayStation® 4 / Xbox One®:** To function, you must connect your DualShock 4 controller (for PS4) or Elite Xbox One controller (for Xbox One) to the USB port located on the racing wheel. Ensure the

controller is powered off before connecting.

- **PlayStation® 3:** Connect the racing wheel directly to your console via the USB cable.
- **PC:** Connect the racing wheel directly to your PC via the USB cable.
- **Nintendo Switch:** Activate the wired communication for Pro Controllers. Navigate to Home / Console Settings / Controllers and Sensors / Pro Controller Wired Communication and set it to “ON”. Then, connect the racing wheel directly to your Switch dock via the USB cable.



Image 4.2: The racing wheel and pedal set configured for use with a Nintendo Switch console, displayed on a desk with a monitor.

## 5. OPERATING INSTRUCTIONS

### 5.1 Basic Controls

- **Steering:** Rotate the wheel left or right to steer in-game. The 180° rotation provides precise control.
- **Pedals:** Press the right pedal for acceleration and the left pedal for braking.
- **Gear Shifting:** Use the sequential paddle shifters located behind the wheel or the dedicated gear lever for manual gear changes.
- **D-Pad and Buttons:** Utilize the 8-way D-pad and various buttons for menu navigation, in-game actions,

and specific functions as defined by your game.

## 5.2 Programmable Buttons

The Race Wheel Pro 2 features 8 programmable buttons with integrated memory. Refer to your game's control settings to customize these buttons for optimal gameplay. The Home button provides direct access to system settings on compatible platforms.

## 5.3 Vibration Feedback

The dual vibration motors provide realistic force feedback, enhancing the immersion by simulating road conditions, collisions, and other in-game effects.

# 6. MAINTENANCE

---

## 6.1 Cleaning

To clean your Race Wheel Pro 2, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the product's finish and components.

## 6.2 Storage

When not in use, store the racing wheel and pedal set in a cool, dry place away from direct sunlight and extreme temperatures. Ensure cables are not tightly coiled or kinked to prevent damage.

# 7. TROUBLESHOOTING

---

If you encounter issues with your Race Wheel Pro 2, please refer to the following common solutions:

- **Wheel Not Recognized:**
  - Ensure all cables are securely connected.
  - Verify that the platform-specific connection instructions (Section 4.3) have been followed correctly. For PS4/Xbox One, confirm the original controller is connected to the wheel's USB port and powered off.
  - Try connecting the wheel to a different USB port on your console or PC.
  - Restart your console or PC.
- **No Force Feedback/Vibration:**
  - Check in-game settings to ensure vibration or force feedback is enabled.
  - Ensure the wheel is properly connected to your system.
- **Buttons Not Responding:**
  - Confirm the wheel is correctly recognized by your system.
  - Test button functionality in your system's controller settings or a different game.
- **Pedals Not Responding:**
  - Ensure the pedal set cable is firmly connected to the racing wheel.
  - Check in-game settings for pedal calibration or sensitivity.

If the issue persists after trying these steps, please contact Spirit of Gamer customer support for further assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Spirit Of Gamer
Model Number	SOG-RWP2
Compatibility	PS4, Xbox One, PS3, PC, Nintendo Switch
Connectivity Technology	USB
Steering Angle	180°
Vibration Feedback	Dual Vibration Motors
Buttons	8 Analog, 4 Digital, 8 Programmable
D-Pad	8-way Precise D-pad
Mounting	7 Suction Cups, Table Clamp
Cable Length	1.80m (USB)
Weight	2 Kilograms
Color	Black
Special Feature	Ergonomic design, Grip Control coating

## 9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Spirit of Gamer website. Keep your proof of purchase for any warranty claims.