



Manuals.plus /

› **vidaXL** /

› vidaXL Storage Bench Baroque Style MDF White Instruction Manual

vidaXL 242646

vidaXL Storage Bench Baroque Style MDF White

INSTRUCTION MANUAL

Product Overview

This manual provides essential information for the safe and proper assembly, operation, and maintenance of your vidaXL Storage Bench Baroque Style MDF White, model 242646. Please read all instructions carefully before use and retain this manual for future reference.



Image: The vidaXL Storage Bench Baroque Style MDF White, featuring its decorative front panel and classic design, positioned in a room.

Safety Information

Always follow these safety guidelines to prevent injury or damage to the product:

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 240 pounds (approximately 108 kg) for seating. Distribute weight evenly.
- **Child Safety:** Keep children away from the storage compartment when opening or closing the lid to prevent pinching. Do not allow children to play inside the bench.
- **Stability:** Ensure the bench is placed on a flat, stable surface. Do not stand on the bench.
- **Material Care:** The bench is made of Engineered Wood (MDF). Avoid exposure to excessive moisture or direct heat sources.
- **Moving the Bench:** When moving the bench, lift it rather than dragging it to prevent damage to the feet and structure.

Package Contents

Carefully unpack all components and check against the list below. If any parts are missing or damaged, contact customer support before proceeding with assembly.

- 1x vidaXL Storage Bench main unit (pre-assembled body with lid)
- 4x Bench feet
- 1x Hardware pack (screws for feet, if not pre-attached to feet)

Setup and Assembly

The vidaXL Storage Bench is largely pre-assembled. The only required assembly step is attaching the four feet.

1. **Prepare the Bench:** Carefully place the main bench unit upside down on a soft, clean surface (e.g., a blanket or carpet) to prevent scratching the finish.
2. **Attach the Feet:** Locate the pre-drilled holes or mounting plates at each corner on the underside of the bench. Align each foot with its corresponding mounting point. Insert the provided screws (if applicable) and tighten them securely with a screwdriver. Ensure all feet are firmly attached and stable. *Do not overtighten.*
3. **Position the Bench:** Carefully turn the bench upright and place it in its desired location. Ensure it is stable and does not wobble. Adjust the feet if necessary (if they have adjustable glides).




Image: A close-up view of the internal hinge and lid support mechanism, which assists in holding the lid open.

Operation

The storage bench serves as both a seating option and a storage solution.

- **Seating:** The bench is designed to comfortably seat up to two individuals, with a maximum weight capacity of 240 pounds. Sit gently and avoid sudden impacts.
- **Accessing Storage:** To access the storage compartment, lift the lid from the front edge. The lid is equipped with a support mechanism to hold it open, allowing for easy access to the interior.
- **Closing the Lid:** Gently lower the lid until it rests securely on the bench frame. Ensure no objects are obstructing the closing path.
- **Storage Capacity:** The spacious interior compartment is suitable for storing various items such as blankets, books, shoes, or other household goods.



Image: The storage bench with its lid fully open, showcasing the ample interior space available for storage.



Image: An overhead view looking into the open storage compartment of the bench, highlighting its depth and capacity.

Maintenance

Proper care will extend the life and appearance of your storage bench.

- **Cleaning:** Wipe the surface with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Environmental Conditions:** Keep the bench in a dry environment. Avoid direct sunlight for prolonged periods to prevent fading or material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Bench wobbles	Uneven floor surface or loose feet.	Move the bench to a level surface. Check and tighten all feet screws. If feet have glides, adjust them.
Lid does not close properly	Obstruction in the storage compartment or hinge misalignment.	Remove any items blocking the lid. Inspect hinges for damage or misalignment; gently adjust if possible.
Squeaking sound when opening/closing lid	Dry or stiff hinges.	Apply a small amount of silicone-based lubricant to the hinge mechanisms.

Specifications




Image: A diagram illustrating the key dimensions of the storage bench: 96 cm (37.8") length, 32 cm (12.6") depth, and 51 cm (20.1") height.

- **Model Number:** 242646
- **Material:** Engineered Wood (MDF)

- **Color:** White
- **Overall Dimensions (L x W x H):** Approximately 37.8 x 12.6 x 20.1 inches (96 x 32 x 51 cm)
- **Item Weight:** Approximately 18 Kilograms (39.7 lbs)
- **Maximum Weight Recommendation:** 240 Pounds (108 kg)
- **Seating Capacity:** 2 persons
- **Assembly Required:** Yes (minimal, feet attachment)
- **Product Care Instructions:** Wipe with Dry Cloth

Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require assistance with assembly, parts, or have any questions regarding your vidaXL Storage Bench, please contact vidaXL customer support or your point of purchase.

You can often find support contact details on the manufacturer's official website or through the retailer where the product was purchased.