

[manuals.plus](#) /› [Sauder](#) /› [Sauder Palladia Corner TV Stand Console Instruction Manual, Model 420714](#)**Sauder 420714**

Sauder Palladia Corner TV Stand Console Instruction Manual

Model: 420714 | Brand: Sauder

1. PRODUCT OVERVIEW

The Sauder Palladia Corner TV Stand Console Entertainment Credenza, Model 420714, is designed to optimize space in your living room or entertainment area. This corner unit accommodates TVs up to 60 inches and features spacious open shelving with two adjustable shelves for media equipment. It also includes adjustable corner display shelves on each side for decor and two easy-gliding drawers for storage. The enclosed back panel provides cord access for organized wire management. The unit is finished in a beautiful Vintage Oak and accented with black hardware, adding both style and functionality to your home.



Image 1.1: The Sauder Palladia Corner TV Stand Console in Vintage Oak, shown with a television and various media devices.

2. SAFETY INFORMATION

Always follow all assembly instructions carefully. Ensure all fasteners are securely tightened before use. Do not overload shelves or drawers. Place the unit on a level surface to prevent tipping. For added safety, consider securing the unit to a wall using anti-tip hardware (if included or recommended by local regulations).

3. PARTS LIST

Your Sauder Palladia Corner TV Stand Console includes all necessary assembly instructions, hardware, and materials. Please refer to the detailed parts list provided in your physical assembly manual to ensure all components are present before beginning assembly.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the step-by-step instructions provided in the included assembly manual. Ensure you have adequate space and the necessary tools before starting. For visual guidance on specific assembly steps, refer to the videos below.

4.1 Identifying Rails

Video 4.1: This video demonstrates how to correctly identify the different types of rails used in the assembly process.

4.2 Identifying Drawer Glides

Video 4.2: Learn how to properly identify and differentiate between the various drawer glides for correct installation.

4.3 Cam and Dowel Fastening System

Video 4.3: A guide to understanding and correctly using the cam and dowel fastening system for secure assembly.

4.4 Adjusting Drawers Using Slides with Cams

Video 4.4: Instructions on how to adjust drawers using slides with cams to ensure smooth operation and proper alignment.

5. OPERATING INSTRUCTIONS

This TV stand is designed for easy use and organization.

- **Adjustable Shelves:** The central open shelves and side display shelves are adjustable. To change the height, remove the shelf, reposition the shelf pins to the desired height, and then reinsert the shelf.
- **Drawers:** The two lower drawers operate on smooth metal runners. Pull gently to open and push firmly to close. Avoid forcing the drawers.
- **Cable Management:** Utilize the cord access in the enclosed back panel to route and organize your television and media device cables, keeping them tidy and out of sight.



Image 5.1: Detail of the adjustable shelves, ideal for organizing video and gaming equipment.



Image 5.2: An open drawer demonstrating the ample storage capacity for various household items.

6. MAINTENANCE AND CARE

To maintain the appearance and longevity of your TV stand, wipe surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the Vintage Oak finish. Promptly clean up spills to prevent staining.

7. TROUBLESHOOTING

- **Wobbly Unit:** Ensure all cam locks and screws are fully tightened. Verify the unit is on a level surface.
- **Drawers Not Gliding Smoothly:** Check that drawer glides are correctly installed and free from obstructions. Refer to the "Adjust Drawer Using Slides with Cams" video in Section 4.4 for adjustment guidance.
- **Missing Parts:** If any parts are missing or damaged, please contact Sauder customer support immediately.

8. SPECIFICATIONS

Brand	Sauder
Model Number	420714
Color	Vintage Oak
Product Dimensions	18.47"D x 61.1"W x 27.4"H
Item Weight	60 Pounds
Weight Limit	95 Pounds
Material	Engineered Wood
Assembly Required	Yes
Special Features	Adjustable Shelf, Adjustable Corner Display Shelves



Image 8.1: Detailed dimensions of the TV stand for planning placement.

9. WARRANTY AND SUPPORT

This Sauder product comes with a **5-year parts warranty**. For warranty claims, replacement parts, or additional support, please visit the official Sauder service website or contact their domestic call center.

- **Sauder Service Website:** sauder.com/service
- **Customer Support Phone:** 800-523-3987



Image 9.1: Sauder customer support information for assistance.

© 2024 Sauder. All rights reserved.