

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SoBuy](#) /

› [SoBuy FRG177-W Toilet Paper Holder Bathroom Cabinet Instruction Manual](#)

### SoBuy FRG177-W

# SoBuy FRG177-W Toilet Paper Holder Bathroom Cabinet Instruction Manual

Model: FRG177-W

## PRODUCT OVERVIEW

The SoBuy FRG177-W is a practical and space-saving bathroom cabinet designed for organizing toilet paper, cleaning supplies, or a toilet brush. Its white finish complements most bathroom decors, offering both functionality and style.

Key features include:

- Integrated toilet paper holder.
- Four freely adjustable shelves for versatile storage.
- Compact design, ideal for small spaces.
- Constructed from white lacquered MDF (E1).
- Maximum load capacity: 4.5 kg (0.5 kg per removable shelf).



Image: The SoBuy FRG177-W bathroom cabinet positioned next to a toilet and sink, showcasing its compact design and storage capabilities. A plant is placed on the top shelf, and a toilet paper roll is visible in its designated holder.



Image: A visual highlighting the extra-slim format of the cabinet, measuring 20x23cm, emphasizing its suitability for small spaces.

## IMPORTANT SAFETY INFORMATION

---

**Warning: Do not load more than 4.5 kg. Please follow the assembly instructions carefully to ensure stability and safe use.**

## 1. SETUP AND ASSEMBLY

---

This cabinet requires assembly. Please ensure all parts are present before beginning. A detailed assembly instruction manual is included in the package. You may also scan the QR code on the packaging for digital instructions.

**Tools Required:** A Phillips head screwdriver (a short one may be helpful for certain steps).

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify against the parts list in the included manual.
2. **Identify Parts:** Each component is numbered. Match the numbers to the diagrams in the assembly instructions.
3. **Assemble the Base:** Attach the side panels to the base according to the diagrams. Ensure all screws are tightened securely.
4. **Install Shelves:** Insert the plastic shelf supports into the pre-drilled holes at your desired height. The cabinet includes 4 freely adjustable shelves.
5. **Attach Back Panel:** Secure the back panel to the cabinet frame. This is crucial for stability.
6. **Mount Door:** Attach the door using the provided hinges. Ensure it opens and closes smoothly.
7. **Install Door Handle:** Fasten the door handle.
8. **Insert Toilet Paper Holder Rod:** Place the removable toilet paper holder rod into its designated slots.

# Grand espace de rangement

Optimisez votre salle de bain avec des compartiments spacieux pour tous vos



Image: A detailed diagram showing the dimensions of the SoBuy FRG177-W cabinet (23 x 20 x 100 cm) and its various sections, including the top shelf, open shelves, and the lower cabinet with a door.



Image: Close-up views highlighting key features: a stable top surface, high-quality metal hardware for the door, moisture-resistant materials, and waterproof feet designed to protect the cabinet from bathroom humidity.

## 2. OPERATING INSTRUCTIONS

The SoBuy FRG177-W cabinet is designed for versatile storage in your bathroom.

### 2.1. Using the Toilet Paper Holder

The cabinet features a dedicated slot for a toilet paper roll. Simply slide the roll onto the removable rod and place it in the designated opening.



Image: A visual demonstrating the removable toilet paper holder rod. It shows the rod in place with a toilet paper roll, and an alternative configuration where the rod is removed to allow for taller items like bottles to be stored in the open shelf.

## 2.2. Utilizing Storage Compartments

The cabinet offers multiple storage options:

- **Top Shelf:** Ideal for decorative items, small plants, or frequently used toiletries.
- **Open Shelves:** Use for additional toilet paper rolls, small towels, or other bathroom essentials. The shelves are adjustable to accommodate items of different heights.
- **Lower Cabinet:** The enclosed cabinet with a door is suitable for storing cleaning supplies, spare toilet paper rolls, or personal care products, keeping them out of sight.



Image: A visual demonstrating the cabinet's large storage capacity, showing various items like a hairdryer, toilet paper, shower gel, and cosmetics stored within its compartments.



Image: A close-up view of the adjustable shelves inside the cabinet, illustrating how their height can be changed to fit various items, such as different sizes of toilet paper rolls.

## 3. MAINTENANCE AND CARE

To ensure the longevity and appearance of your SoBuy FRG177-W cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the lacquered finish.
- **Spills:** Immediately wipe up any spills, especially water, to prevent moisture damage to the MDF

material.

- **Load Capacity:** Adhere to the maximum load capacity of 4.5 kg for the entire unit and 0.5 kg per removable shelf to prevent structural damage.
- **Ventilation:** Ensure adequate ventilation in the bathroom to minimize humidity, which can affect wood-based furniture over time.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

## 4. TROUBLESHOOTING

If you encounter any issues with your SoBuy FRG177-W cabinet, refer to the following common solutions:

### 4.1. Stability Issues

- **Wobbling:** Ensure all assembly screws are fully tightened. Verify that the back panel is securely attached, as it contributes significantly to the cabinet's stability.
- **Uneven Surface:** If the floor is uneven, consider placing small, thin shims under the cabinet's feet to level it.

### 4.2. Door Not Closing Properly

- **Hinge Alignment:** Check if the hinges are correctly aligned and securely fastened to both the door and the cabinet frame. Adjust if needed.
- **Obstruction:** Ensure there are no items inside the cabinet obstructing the door's closure.

### 4.3. Chemical Odor

Some new furniture items may emit a slight chemical odor initially. This is typically due to manufacturing processes and usually dissipates over time.

- **Ventilation:** Place the cabinet in a well-ventilated area for several days before placing it in a confined space like a bathroom.
- **Cleaning:** Wipe down surfaces with a mild, non-abrasive cleaner or a solution of vinegar and water, then air dry thoroughly.

If the issue persists or you experience other problems, please contact customer support.

## 5. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	FRG177-W
Dimensions (L x W x H)	23 x 20 x 100 cm
Weight	5.5 kg
Color	White
Finish	Lacquered

Material	Engineered Wood (MDF E1)
Installation Method	Freestanding
Maximum Supported Weight	4.5 kg (0.5 kg per removable shelf)
Special Features	Removable shelf, Adjustable shelf
Components Included	Accessory kit, Toilet paper holder rod

## 6. WARRANTY INFORMATION

SoBuy products are designed for quality and durability. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims.

For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official SoBuy website.

## 7. CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, maintenance, or troubleshooting of your SoBuy FRG177-W cabinet, please contact SoBuy customer support.

### Contact Information:

- Refer to the contact details provided in your product packaging.
- Visit the official SoBuy website for support resources and contact options.
- For issues related to delivery or returns, please contact the retailer where the product was purchased.

When contacting support, please have your model number (FRG177-W) and proof of purchase readily available.