

[Manuals.plus](#) /

› [Ikea](#) /

› IKEA GRUNDTAL Stainless Steel Wall Shelf - Instruction Manual

Ikea CO007

IKEA GRUNDTAL Stainless Steel Wall Shelf - Instruction Manual

Model: CO007

1. PRODUCT OVERVIEW

The IKEA GRUNDTAL Stainless Steel Wall Shelf is a durable and practical storage solution designed to maximize space in your kitchen or other areas. Its stainless steel construction ensures longevity and easy maintenance, making it ideal for environments where hygiene and resistance to moisture are important. This shelf is designed for wall mounting, providing a sturdy surface for various items.



Figure 1: The IKEA GRUNDTAL Stainless Steel Wall Shelf, showcasing its sleek design and wall-mounting brackets.

2. SAFETY INFORMATION

WARNING:

- Ensure the wall mounting hardware is appropriate for your wall type and is securely installed. Improper installation can lead to the shelf detaching from the wall, causing injury or damage.
- Do not exceed the maximum load capacity of **15 kg (33 lbs)**. Overloading the shelf can cause it to collapse, resulting in personal injury or property damage.
- Distribute weight evenly on the shelf to maintain stability.
- Keep small children away from the installation area during assembly.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. The package should contain:

- 1 x GRUNDTAL Wall Shelf unit (stainless steel)
- Mounting hardware (screws, wall plugs - *specific types may vary based on region and wall material, consult local hardware store if unsure*)
- Assembly instructions (this manual)

4. SETUP AND INSTALLATION

Follow these steps for proper installation of your GRUNDTAL wall shelf:

1. **Choose Location:** Select a suitable wall location, ensuring it is free from electrical wires, water pipes, or other obstructions. Consider the height and accessibility.
2. **Gather Tools:** You will need a drill, spirit level, measuring tape, pencil, and screwdriver.
3. **Mark Drilling Points:** Hold the shelf against the wall at the desired height and use a spirit level to ensure it is perfectly horizontal. Mark the drilling points for the mounting brackets with a pencil.
4. **Drill Holes:** Drill holes at the marked points. The drill bit size should match the wall plugs provided or recommended for your wall type.
5. **Insert Wall Plugs:** Insert the appropriate wall plugs into the drilled holes. Ensure they are flush with the wall surface.
6. **Attach Shelf:** Align the shelf's mounting brackets with the wall plugs and secure it to the wall using the provided screws. Tighten the screws firmly but do not overtighten.
7. **Verify Stability:** Gently pull on the shelf to ensure it is securely fastened to the wall before placing any items on it.

For optimal safety, it is recommended to consult a qualified professional if you are unsure about the appropriate mounting hardware for your specific wall material.

5. USAGE

The GRUNDTAL wall shelf is designed for general storage in kitchens, bathrooms, or utility rooms. Place items on the shelf, ensuring the total weight does not exceed 15 kg. Distribute heavier items closer to the mounting points for better stability.

6. MAINTENANCE

To keep your stainless steel shelf in excellent condition:

- **Cleaning:** Wipe clean with a soft cloth dampened with water and a mild dish detergent or soap.

- **Drying:** Always dry thoroughly with a clean, dry cloth to prevent water spots and maintain the shine.
- **Avoid Abrasives:** Do not use scouring powders, steel wool, or hard or sharp tools that can scratch the stainless steel surface.
- **Rust Prevention:** While stainless steel is resistant to rust, prolonged exposure to moisture or harsh chemicals can cause discoloration or surface rust. Clean spills promptly.

7. TROUBLESHOOTING

- **Shelf feels wobbly after installation:**
Solution: Ensure all mounting screws are tightened securely. If the issue persists, the wall plugs may not be suitable for your wall material, or the holes may be too large. Consider using different wall anchors or consulting a professional.
- **Surface discoloration or minor rust spots appear:**
Solution: This can occur due to prolonged moisture exposure or contact with certain chemicals. Clean the area immediately with a mild stainless steel cleaner and dry thoroughly. For stubborn spots, a non-abrasive stainless steel polish may help. Avoid using abrasive cleaners or steel wool.

8. SPECIFICATIONS

Feature	Detail
Model Number	CO007
Brand	IKEA
Material	Stainless Steel
Color	Grey (Stainless Steel finish)
Dimensions (L x W x H)	60 cm x 27 cm x 20 cm (23.6 in x 10.6 in x 7.9 in)
Product Weight	1.7 kg (3.7 lbs)
Maximum Load Capacity	15 kg (33 lbs)
Mounting Type	Wall Mount

9. WARRANTY AND SUPPORT

Specific warranty details for the IKEA GRUNDTAL Stainless Steel Wall Shelf are not provided in this manual. For information regarding warranty coverage, returns, or technical support, please refer to your purchase receipt or contact IKEA customer service directly. You can typically find contact information on the official IKEA website or in the documentation included with your purchase.

Please retain your proof of purchase for any warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question