ZdalaMit XRT112

ZdalaMit XRT112 Replacement Remote Control User Manual

For Vizio Smart Internet LED TVs with Netflix/iHeart APP Keys

1. Introduction

This manual provides instructions for the ZdalaMit XRT112 Replacement Remote Control, designed for use with various Vizio Smart Internet LED TV models. This remote offers a straightforward, pre-programmed solution for controlling your Vizio television, including dedicated buttons for popular streaming services.





Figure 1: Front view of the XRT112 Replacement Remote Control.

2. Setup

The XRT112 remote control is designed for immediate use without any programming or pairing. Simply install the batteries, and it will be ready to operate your compatible Vizio TV.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

The remote is now ready for use. No further setup is required.



Figure 2: Back view of the remote showing the battery compartment.

3. Operating Instructions

The XRT112 remote control features a standard layout with dedicated buttons for various functions, including quick access to streaming applications.



Figure 3: XRT112 Remote Control button layout and functions.

- **INPUT:** Change the currently-displayed input.
- **POWER:** Turns the TV on or off.
- **Amazon/Netflix/iHeart Radio APP Keys:** Launches the app indicated by the button.

- **A/V CONTROLS:** Control USB media player (Play, Pause, Stop, Rewind, Fast Forward).
- **CC:** Open the closed caption menu.
- **INFO:** Display the info window.
- **EXIT:** Close the on-screen menu.
- **MENU:** Display the on-screen menu.
- **Directional Pad (Up, Down, Left, Right) & OK:** Select the highlighted menu option.
- **BACK:** Go to the previous on-screen menu.
- **GUIDE:** Display the info window.
- **VOL +/-:** Increase or decrease loudness of the audio.
- **V BUTTON:** Open the VIA dock.
- **MUTE:** Turn the audio off or on.
- **CHANNEL UP/DOWN:** Change the channel.
- **NUMBER PAD (0-9):** Manually enter a channel.
- **LAST:** Return to the channel last viewed.
- **WIDE:** Switch the display mode.
- **DASH (-):** Use with number pad to manually enter a digital sub-channel (e.g., 18-4 or 18-5).

4. Compatibility

The XRT112 Replacement Remote Control is compatible with a wide range of Vizio Smart Internet LED TV models. Some compatible models include, but are not limited to:

- E231i-B1, E280i-A1, E320i-B0, E390i-A1, E400i-B2, E420i-A1, E500D-A0, E550i-A0
- E241i-A1, E280i-B1, E320i-B1, E390i-B0, E401i-A2, E420i-A0, E500i-B1, E500i-B0, E550i-A0E
- E241i-A1, E291i-A1, E320i-B2, E390i-B1, E420i-B0, E550i-B2
- E241i-B1, E320i-A2, E480i-B2, E551i-A2, E600i-B3
- E320i-A0, E420d-A0, E422VLE, E470i-A0, E472VLE, E500i-A0, E552VLE
- M320SL, M370SL, E551d-A0

If your Vizio TV model is not listed, please refer to your TV's original manual or contact customer support to confirm compatibility.

5. Specifications

Feature	Specification
Product Dimensions	5 x 1.5 x 0.5 inches
Item Weight	1.41 ounces
Item Model Number	XRt112
Batteries Required	2 AAA batteries (not included)
Special Feature	Pre-programmed
Color	Black
Max Number of Supported Devices	1 (Vizio TV)

Compatible Devices	Television



Figure 4: Remote control dimensions.

6. Troubleshooting

If you experience issues with your XRT112 Replacement Remote Control, please try the following steps:

- **Check Batteries:** Ensure that the batteries are inserted correctly with the proper polarity and are not depleted. Replace with fresh AAA alkaline batteries if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and your Vizio TV's infrared sensor. Obstructions can block the signal.
- **Remote Compatibility:** Verify that your Vizio TV model is listed as compatible with the XRT112 remote.

- **TV Power Cycle:** Turn off your Vizio TV, unplug it from the power outlet for a few minutes, then plug it back in and turn it on. This can sometimes resolve minor communication issues.

7. Support & Warranty

For any queries or further assistance, please contact ZdalaMit customer support. While specific warranty details are not provided in this manual, general product support is available.
Contact Information: Please refer to the seller's contact details on the product packaging or the platform where the purchase was made.

8. Product Video

Watch this video for a closer look at the XRT112 Remote Control and its features.

Video: Overview of the XRT112 Remote Control by Delighted Inc.

© 2026 ZdalaMit. All rights reserved.