

Moen 84603

Moen Adler Chrome Two Handle Bathroom Faucet - Model 84603

User Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen 84603 Adler Chrome Two Handle Bathroom Faucet. Please read all instructions carefully before beginning installation to ensure proper function and longevity of your product.

The Moen Adler faucet, with its smooth curves and minimalist aesthetics, is designed to complement a variety of bathroom décors. Its low arc profile makes it an ideal choice for smaller bathrooms or powder rooms.

PRODUCT FEATURES

- **VERSATILE DESIGN:** Chrome finish is highly reflective for a mirror-like look that works with any decorating style.
- **EASY TO INSTALL:** 4-inch centerset design allows for easy installation.
- **ECO-FRIENDLY:** 1.2 gpm flow rate is WaterSense Certified.
- **ADA COMPLIANT:** Complies with Americans with Disabilities Act (ADA) specifications.
- **EVERY DROP, CERTIFIED SAFE:** Every Moen residential kitchen and bath faucet complies with the Federal Safe Drinking Water Act and NSF 61 standards — making Moen the safe choice for clean drinking water.
- **WARRANTY:** Backed by Moen's Limited Lifetime Warranty.

SETUP & INSTALLATION

The Moen 84603 faucet is designed for a 4-inch centerset, 3-hole installation. Ensure your sink is compatible with this configuration before proceeding.



Figure 1: Sink compatibility diagram for 3-hole installation.

Before installation, turn off the main water supply. Clear the area under the sink and ensure you have all necessary tools and components as listed in the packaging. Follow the detailed instructions provided in the included user manual (PDF) for step-by-step guidance on securing the faucet to the deck, connecting water supply lines, and installing the drain assembly.



Figure 2: Moen Adler faucet properly installed in a bathroom setting.

OPERATING INSTRUCTIONS

Your Moen 84603 faucet features two lever handles for precise control of water temperature and flow. The left handle controls hot water, and the right handle controls cold water.

- To turn on the water, lift either handle.
- To increase water flow, lift the handle further.
- To adjust temperature, move the hot (left) and cold (right) handles simultaneously until the desired temperature is achieved.
- To turn off the water, push the handles down to their original closed position.



Figure 3: Faucet in operation, demonstrating water flow.

MAINTENANCE

To maintain the chrome finish and ensure optimal performance of your Moen faucet, follow these simple maintenance tips:

- **Cleaning:** Clean the faucet regularly with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome finish.
- **Water Spots:** To prevent water spots, wipe the faucet dry after each use.
- **Aerator Cleaning:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and rinse thoroughly before reattaching.



Figure 4: The Moen Adler faucet, showcasing its chrome finish.

TROUBLESHOOTING

If you encounter issues with your Moen 84603 faucet, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves.	Clean or replace aerator; fully open shut-off valves.
Leaking from Spout	Worn out cartridge.	Replace the cartridge (refer to detailed manual).
Leaking from Handle Base	Loose packing nut; worn O-rings or seals.	Tighten packing nut; replace O-rings or seals.
Difficulty Turning Handles	Mineral buildup; worn cartridge.	Clean around handles; replace cartridge.

For more complex issues or if troubleshooting steps do not resolve the problem, please contact Moen customer support.

SPECIFICATIONS


Key specifications for the Moen 84603 Adler Chrome Two Handle Bathroom Faucet:

Attribute	Detail
Brand	Moen
Model Name	Adler

Attribute	Detail
Part Number	84603
Finish Type	Chrome
Material	Plastic
Number of Handles	2
Handle Type	Lever
Mounting Type	Deck Mount
Installation Type	Centerset
Maximum Flow Rate	1.75 Gallons Per Minute
Spout Reach	4.9 Inches
Product Dimensions	4.9"D x 4.25"W x 10.16"H
Item Weight	2.95 Pounds
UPC	026508271759

Will this faucet fit my sink?

This faucet fits a three hole configuration.



MOEN®

Figure 5: Dimensional overview of the Moen Adler faucet.

WARRANTY

The Moen 84603 Adler Chrome Two Handle Bathroom Faucet is backed by Moen's Limited Lifetime Warranty. This warranty covers defects in material and manufacturing workmanship for the original consumer purchaser. For full details regarding warranty coverage, terms, and conditions, please refer to the official Moen warranty documentation or visit the Moen website.

SUPPORT

For additional support, product information, or to purchase replacement parts, please visit the official Moen Store online or contact Moen customer service directly.

Visit the [Moen Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question