

Extol Light 43810

Extol Light 43810 Radio Lamp Holders (2-pack) E27 - User Manual

INTRODUCTION

Thank you for choosing the Extol Light 43810 Radio Lamp Holders. This manual provides essential information for the safe and efficient use of your new product. Please read these instructions carefully before installation and operation, and retain them for future reference.

The Extol Light 43810 is a set of two radio-controlled lamp holders designed for E27 light bulbs. These lamp holders allow for wireless control of your lighting when paired with compatible Extol Light remote controls or WLAN sockets (sold separately). Each lamp holder operates independently or can be controlled simultaneously with other units within a 30-meter range.

SAFETY INFORMATION

- **Electrical Safety:** Always ensure the power supply is disconnected before installing or replacing light bulbs or lamp holders. Installation should be performed by a qualified electrician if you are unsure.
- **Indoor Use Only:** These lamp holders are designed for indoor use in dry conditions. Do not expose them to moisture, water, or extreme temperatures.
- **Load Capacity:** Do not exceed the maximum wattage specified for the lamp holders (100W for incandescent bulbs, 60W for LED bulbs).
- **Compatibility:** Use only with E27 base light bulbs.
- **Children:** Keep out of reach of children.
- **Disposal:** Dispose of the product responsibly according to local regulations for electronic waste.

PACKAGE CONTENTS

The package contains the following items:


- 2 x Extol Light 43810 Radio Lamp Holders (E27)

- User Manual (this document)

Note: Remote controls (Extol Light 43820, 43822) or WLAN sockets (Extol Light 43800) are sold separately and are required for wireless operation.



Item No.
43800



Item No.
43822



Item No.
43820

RF Signal



Item No.
43810

230 V
~50 Hz



E27



Max. 100 W



LED
Max. 60 W

RF SIGNAL



30 m

PRODUCT OVERVIEW

The Extol Light 43810 radio lamp holder is designed to convert a standard E27 light fitting into a wirelessly controllable light source. It receives RF signals from compatible Extol Light control devices to switch the connected bulb on or off.



Image: Diagram illustrating the Extol Light wireless system. It shows the 43810 lamp holder (E27, 230V, Max 100W incandescent, Max 60W LED, 30m range) being controlled by various devices: Item No. 43800 (Wi-Fi socket), Item No. 43822 (wall switch), and Item No. 43820 (remote control). The diagram also indicates that the lamp holder is not waterproof.

Key Features:

- Wireless control for E27 light bulbs.
- Operating range of up to 30 meters.
- Compatible with Extol Light remote controls (43820, 43822) and WLAN socket (43800).
- Supports incandescent bulbs up to 100W and LED bulbs up to 60W.
- Operates on 230V ~50Hz.

SETUP

1. **Power Off:** Ensure the power supply to the lamp fitting is switched off at the main circuit breaker before installation.
2. **Install Lamp Holder:** Screw the Extol Light 43810 radio lamp holder into your existing E27 lamp fitting. Ensure it is securely tightened.
3. **Install Light Bulb:** Screw an E27 light bulb (incandescent max 100W, LED max 60W) into the Extol Light 43810 lamp holder.
4. **Power On:** Restore power to the lamp fitting at the main circuit breaker.
5. **Pairing with Control Device:**
 - Refer to the instruction manual of your Extol Light remote control (43820, 43822) or WLAN socket (43800) for specific pairing instructions.
 - Generally, the pairing process involves putting the control device into pairing mode and then activating the lamp holder (e.g., by switching the power on/off a few times) to establish a connection.
 - Once paired, the lamp holder will respond to commands from the control device.

OPERATING

Once the Extol Light 43810 lamp holders are installed and paired with a compatible control device, operation is straightforward:

- **Switching On/Off:** Use the ON/OFF buttons on your paired Extol Light remote control (43820, 43822) or the interface of your WLAN socket (43800) to switch the connected light bulb on or off.
- **Range:** Ensure the control device is within the 30-meter operating range of the lamp holder for reliable communication. Obstacles like walls and ceilings may reduce the effective range.
- **Independent Control:** If multiple lamp holders are paired, they can often be controlled individually or as a group, depending on the capabilities of your specific Extol Light control device. Consult your control device's manual for details.

MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Wipe the lamp holder with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Always switch off the power supply before replacing a light bulb. Allow the bulb to cool down completely before handling.
- **Storage:** If storing the lamp holders for an extended period, keep them in a dry, cool place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light bulb does not turn on.	No power to the lamp fitting. Light bulb is faulty. Lamp holder is not paired. Control device is out of range or has flat batteries. Lamp holder is faulty.	Check the main circuit breaker and wall switch. Replace the light bulb. Refer to the "Setup" section for pairing instructions. Move the control device closer or replace its batteries. Contact customer support.
Intermittent control.	Interference from other wireless devices. Control device is at the edge of its range. Obstructions blocking the signal.	Try to minimize interference sources. Move the control device closer to the lamp holder. Reposition the lamp holder or control device.
Lamp holder does not respond to a new control device.	Not properly paired.	Follow the pairing instructions carefully for the new control device.

SPECIFICATIONS

Model Number	43810
Brand	Extol Light
Quantity	2 pieces
Base Type	E27 (Medium)
Voltage	230 V ~50 Hz
Max. Wattage (Incandescent)	100 W
Max. Wattage (LED)	60 W
Wireless Range	Up to 30 meters (open field)
Control Compatibility	Extol Light 43820 (remote), 43822 (wall switch), 43800 (WLAN socket)
Color	White
ASIN	B06XFSZ67G

WARRANTY

The product comes with a 2-year warranty from the date of purchase, as indicated in the product specifications. This warranty covers manufacturing defects and material faults under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

Please retain your proof of purchase for warranty claims. For warranty service, contact Extol Light customer support.

SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Extol Light customer support. Contact information can typically be found on the manufacturer's website or product packaging.

Manufacturer: Extol

Brand: Extol Light

For the latest information and support resources, please visit the official Extol Light website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question