Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Nerf /
- > Nerf Elite Electronic Target Instruction Manual

Nerf NER0156

Nerf Elite Electronic Target Instruction Manual

Model: NER0156 Brand: Nerf

1. PRODUCT OVERVIEW

The Nerf Elite Electronic Target by Jazwares is an electronic target shooting game that allows for fun aiming and shooting at targets that react when hit. Designed for children aged 8 and up, this game develops precision, concentration, and motor skills in a playful manner. The principle is simple: just aim at the targets with a Nerf dart blaster and press the trigger to shoot. When a dart hits a target, it reacts thanks to an integrated electronic system. Depending on the area hit, the target can light up, vibrate, count points, or even fall! The target is designed for both wall mounting and tabletop use, making it versatile for various play environments.



Figure 1.1: Front view of the Nerf Elite Electronic Target, showing its scoring zones and display area.



Figure 1.2: The electronic target positioned on a desk, ready for play, with Nerf darts nearby.

2. SAFETY INFORMATION

Important Safety Warnings

- **WARNING:** Not suitable for children under 36 months due to small parts which may present a choking hazard.
- · Do not aim at eyes or face.
- Use only official Nerf darts. Other darts may not meet safety standards.
- · Adult supervision is recommended during play.
- Keep away from water and excessive moisture to prevent damage to electronic components.

3. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x Nerf Elite Electronic Target
- 10 x Suction Cup Darts (Note: Blaster and additional ammunition are NOT supplied and must be purchased separately.)



Figure 3.1: The product packaging, indicating contents and features.

4. SETUP

4.1 Battery Installation

The Nerf Elite Electronic Target requires 1 'A' battery (not included) for operation.

- 1. Locate the battery compartment on the back of the target.
- 2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
- 3. Insert 1 'A' battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
- 4. Replace the battery compartment cover and secure it with the screw.

4.2 Assembly

Assembly of the Nerf Elite Electronic Target is very simple. Just assemble the components together using the integrated stand according to the provided diagrams.

- 1. Unfold the integrated stand located on the back of the target until it clicks into place. This allows the target to stand upright on a flat surface.
- 2. Alternatively, for wall mounting, use appropriate hardware (not included) to hang the target from a wall using the designated mounting points.



Figure 4.1: Angled view of the target, illustrating the integrated stand for tabletop use.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To power on the target, locate the power switch (usually on the side or back) and slide it to the 'ON' position. The target will emit a sound and the display will light up.
- To power off, slide the switch to the 'OFF' position.

5.2 Basic Operation

- 1. Once powered on, select your desired game mode using the 'Mode' button (refer to Section 6 for game modes).
- 2. Aim your Nerf blaster at the target's scoring zones.
- 3. Shoot the suction cup darts at the target. The target will react with lights, sounds, and score updates on the LCD display when hit.
- 4. Collect your darts after each round or as needed.

6. GAME MODES

The Nerf Elite Electronic Target offers multiple game modes for single or multi-player fun. Use the 'Mode' and 'Selection' buttons located near the LCD display to navigate and choose your preferred game.

- Single Player Mode: Practice your precision and aim to achieve the highest score.
- Multi-Player Mode: Compete with friends to see who can score the most points. The target's
 electronic system tracks scores for each player.

Refer to the on-screen prompts on the LCD display for specific game rules and objectives within each mode.

7. MAINTENANCE

- **Cleaning:** Wipe the target surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the target in water.
- **Storage:** When not in use, store the target in a cool, dry place away from direct sunlight. If storing for an extended period, remove the battery to prevent leakage.
- Darts: Keep darts clean and free of debris to ensure optimal performance and target reaction.

8. TROUBLESHOOTING

- Target not powering on:
 - Ensure the power switch is in the 'ON' position.
 - Check battery installation and polarity.
 - Replace with a fresh 'A' battery.

• Target not reacting to hits:

- Ensure you are using official Nerf suction cup darts.
- Check if darts are clean and not damaged.
- Ensure darts are hitting the designated scoring zones directly.
- Verify battery level. Low battery can affect sensor sensitivity.

Display not working correctly:

- Turn the target off and then on again to reset.
- Check battery level.

9. Specifications

Feature	Detail
Model Number	NER0156
Brand	Nerf

Feature	Detail
Age Recommendation	6 to 99 years
Main Material	Plastic
Color	Multicolored
Dimensions (L x W x H)	5.08 x 24.77 x 30.48 cm (2 x 9.75 x 12 inches)
Weight	440 grams (0.97 lbs)
Batteries Required	1 x 'A' battery (not included)
Included Components	1 Electronic Target, 10 Suction Cup Darts




Figure 9.1: Product dimensions, indicating a height of approximately 10 inches (25 cm).

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Nerf website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Nerf. All rights reserved.



NERF Digital Target User Guide: Setup, Games, and Instructions

Comprehensive user guide for the NERF Digital Target (model 11588). Learn how to set up, play, and master the different game modes like Point Counter, Speed Breaker, and Accuracy Blast. Includes battery information, safety warnings, and features.



Nerf Strike 'N Score Digital Target Game - Instructions and How to Play

Official instructions for the Nerf Strike 'N Score Digital Target Game by Wilder Toys Inc. Learn how to set up, play different game modes like Overtime, Red vs Blue, Perfect 100, and Tag Team, and battery information.



Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions

A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.



Nerf N-Strike Elite Alpha Trooper CS-12 Barrel Replacement Guide

Detailed guide on how to replace the barrel of the Nerf N-Strike Elite Alpha Trooper CS-12 toy gun. Includes tools required and step-by-step instructions for disassembly and reassembly.



NERF N-Strike Elite AccuStrike FalconFire Blaster: Instructions and Features

Official instructions and overview for the NERF N-Strike Elite AccuStrike Series FalconFire dart blaster, including how to load, fire, and store the toy. Features product details and safety information.



Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions

Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.