

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BOBLOV](#) /

> [BOBLOV 1296P Police Body Camera HLX077-I0411B1 Instruction Manual](#)

## BOBLOV HLX077-I0411B1

# BOBLOV 1296P Police Body Camera Instruction Manual

Model: HLX077-I0411B1

## 1. PACKAGE CONTENTS


---

Verify that all items are present in the package:

- BOBLOV Body Camera
- User Manual
- Shoulder Clip
- Car Charger
- 2 x Lithium Ion Batteries (1950mAh each)
- USB Cable
- Charging Base
- Short Clip



1\* Body Camera



1 \* User Manual



1\* Shoulder Clip



1\* Car Charger



2\*Batteries  
(One in camera)



1 \* USB Cable



1\* Charging Base



1 \* Short Clip

Image: The package contents include the body camera, user manual, two clips, car charger, two batteries, USB cable, and charging base.

## 2. SETUP

### 2.1 Battery Installation and Charging

The camera comes with two 1950mAh Lithium Ion batteries. Ensure batteries are fully charged before first use.

1. Insert one battery into the dedicated slot on the charging base.
2. Place the body camera onto the charging base. The base allows simultaneous charging of one battery and the camera.
3. Connect the USB cable to the charging base and a power source (e.g., wall adapter, car charger, or computer USB port).
4. Charging time is approximately 3 hours for a full charge.

# High Capacity Battery

Equipped with two 1950mAh rechargeable batteries and charging base

USAGE TIME 

**9 HOURS**

9 hours (1080P with screen off)

CHARGING TIME 

**3 HOURS**



Image: The body camera and a spare battery are shown charging in the dual charging dock.

## 2.2 Memory Card

The camera supports external TF (MicroSD) cards up to 128GB. A 64GB internal storage is included.

1. Locate the TF card slot on the side of the camera.
2. Gently insert the TF card into the slot until it clicks into place.
3. To remove, press the card inward until it springs out.



Image: The body camera features an external TF card slot, supporting cards up to 128GB for expanded storage.

## 3. OPERATING INSTRUCTIONS

### 3.1 Power On/Off

Press and hold the Power button for 3 seconds to turn the camera on. To turn off, press and hold the Power button for 5 seconds.

### 3.2 Video Recording

From standby mode, short press the Video Record button to start recording. The red light will flash, and the camera will vibrate twice. Short press again to stop recording and save the file.

### 3.3 Photo Capture

From standby mode, short press the Photo button to take a single photo. The camera will vibrate once.

### 3.4 Audio Recording

From standby mode, short press the Audio Record button to start audio-only recording. Short press again to stop and save.

### 3.5 Night Vision

The camera features automatic infrared night vision. In low light conditions, the IR lights will activate to capture clear footage up to 15 meters (approximately 49 feet) away.

## Auto Infrared Night Vision

Captures clear footage 3-15M away in full dark or low light condition

3M

15M

Max support 32ft

0 5ft 10ft 15ft 20ft 25ft 32ft

BOBLOV

1080P30 0:08:25

00000-00000

2020/11/08 21:12:03:21 64G

Image: The body camera captures clear footage in low light, showing objects at 3 meters and 15 meters with night vision activated.

### 3.6 Playback

Use the menu buttons to navigate through recorded videos, photos, and audio files on the 2-inch LCD screen. Select a file and press the OK button to play.

### 3.7 Mounting and Wear

The camera comes with rotatable clips for flexible mounting options. Attach the desired clip to the back of the camera.



Image: The body camera is shown with rotatable clips, allowing for 360-degree rotation and 180-degree tilt for optimal positioning.



*Image: A person in uniform wears the BOBLOV body camera clipped to their shirt pocket, demonstrating a typical use case.*

## **4. MAINTENANCE**

---

### **4.1 Cleaning**

Wipe the camera body and lens with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

### **4.2 Data Transfer**

Connect the camera to a computer using the provided USB cable to transfer recorded files. The camera will appear as a removable disk drive.

### **4.3 Firmware Updates**

Check the manufacturer's website periodically for firmware updates to ensure optimal performance and access to new features.

## **5. TROUBLESHOOTING**

---

Problem	Possible Cause	Solution
Machine cannot boot	Running down of battery	Full charge the battery.
Machine cannot boot	Machine protection	Press reset button or reboot.
Machine working time is short	Undercharge	Full charge more than 4 hours.
Cannot copy data to computer	USB interface in front of computer power supply is insufficient	Connect the data line to the computer's back USB interface.

## 6. SPECIFICATIONS

---

Feature	Detail
Video Resolution	1296P (Effective 1296 Pixels)
Video Capture Format	MPEG-4
Field of View	170 Degrees
Night Vision	Yes (Low light technology: Night Color)
Water Resistance Level	Waterproof (IP67)
Internal Storage	64GB
External Storage	Supports TF card up to 128GB
Battery Type	2 Lithium Ion batteries (1950mAh each)
Item Weight	1 Pound
Connectivity Technology	USB
Model Number	HLX077-I0411B1

## 7. WARRANTY AND SUPPORT

---

For warranty information or technical assistance, please contact BOBLOV Customer Service. Refer to the user manual included in your package for specific contact details or visit the official BOBLOV website.

General Customer Service Email: [Support@Boblov.com](mailto:Support@Boblov.com)

## 8. OFFICIAL PRODUCT VIDEOS

---

Below are official product videos from the seller for additional guidance and demonstrations.

### BOBLOV BODY CAM Real Video Visual effects

*Video: This video demonstrates the real-world visual effects and video quality of the BOBLOV body camera.*