Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Grandeur /
- Grandeur 810955 Carre Plate Dummy Knob Instruction Manual

Grandeur 810955

Grandeur 810955 Carre Plate Dummy Knob Instruction Manual

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Grandeur 810955 Carre Plate Dummy with Bouton Knob. Please read these instructions carefully before beginning installation to ensure proper function and longevity of your product. Keep this manual for future reference.

PRODUCT OVERVIEW

The Grandeur 810955 Carre Plate Dummy with Bouton Knob is a non-functional door hardware component designed for aesthetic purposes or as a pull handle on doors where no latching mechanism is required. It features a solid forged brass construction and a Timeless Bronze finish, ensuring durability and a consistent appearance. This dummy knob does not turn or operate a latch.



Image: Grandeur 810955 Carre Plate Dummy with Bouton Knob in Timeless Bronze. This image displays the complete dummy knob assembly, featuring a rectangular backplate with stepped edges and a round bouton knob, all in a dark, matte bronze finish.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Non-functioning Knob/Lever (1)
- Longplate for one side of door (1)
- Dummy Spindle (1)
- Mounting Screws (set)

SETUP AND INSTALLATION

This dummy knob is designed for easy installation on various door types. No complex mechanisms are involved as it does not operate a latch.

Tools Required:

- · Phillips Head Screwdriver
- Pencil
- Measuring Tape
- Drill with appropriate bit (optional, for pilot holes)

Installation Steps:

- 1. **Determine Placement:** Position the Carre Plate and Bouton Knob on the desired side of the door. Ensure it is at a comfortable height and aesthetically aligned.
- 2. **Mark Mounting Points:** Using a pencil, carefully mark the locations for the mounting screws through the screw holes on the backplate.
- Drill Pilot Holes (Optional but Recommended): For wood doors, drilling small pilot holes at the
 marked points can prevent wood splitting and make screw insertion easier. Ensure the drill bit size is
 smaller than the screw diameter.
- 4. Attach Dummy Spindle: Insert the dummy spindle into the knob assembly.
- 5. **Mount the Assembly:** Align the backplate and knob assembly with the marked holes. Insert the mounting screws and tighten them securely with a Phillips head screwdriver. Do not overtighten.
- 6. Verify Stability: Gently pull on the knob to ensure it is firmly attached to the door.

OPERATING INSTRUCTIONS

The Grandeur 810955 Carre Plate Dummy with Bouton Knob is a non-functional piece of hardware. It is designed to remain stationary and does not turn or engage a latch. Its primary function is to serve as a decorative element or a fixed pull handle for opening and closing a door that does not require a latching mechanism.

MAINTENANCE

To maintain the appearance and integrity of your Grandeur dummy knob, follow these simple guidelines:

- Cleaning: Wipe the surface regularly with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes, as these can damage the Timeless Bronze finish.
- **Inspection:** Periodically check the mounting screws for tightness. If the knob feels loose, gently tighten the screws with a Phillips head screwdriver.

TROUBLESHOOTING

As a non-functional dummy knob, troubleshooting is generally limited to installation and stability issues.

Problem	Possible Cause	Solution
Knob feels loose after installation.	Mounting screws are not fully tightened.	Tighten the mounting screws with a Phillips head screwdriver. Do not overtighten.
Knob is difficult to pull.	This is a dummy knob and does not turn. Ensure the door itself is operating smoothly.	Check door hinges and frame for proper alignment. The knob is for pulling only.

SPECIFICATIONS

Feature	Detail
Model Number	810955
Brand	Grandeur
Product Type	Dummy Knob with Carre Plate
Material	Solid Forged Brass
Finish	Timeless Bronze
Dimensions (Product)	2.5 x 2.5 x 4.75 inches (approximate)
Item Weight	3.2 pounds
Special Feature	Easy to Install

WARRANTY AND SUPPORT

Your Grandeur 810955 Carre Plate Dummy with Bouton Knob is backed by a**Lifetime Mechanical Warranty**. This warranty covers defects in material and workmanship for the lifetime of the product under normal use.

For warranty claims, technical assistance, or any questions regarding your product, please contact Grandeur customer support. Refer to the product packaging or the official Grandeur website for current contact information.

Related Documents - 810955



Grandeur Gas Range Use and Care Guide: Models URY3055AS, URY3655AS, URY4855AS

Comprehensive use and care guide for Grandeur gas ranges, including safety instructions, operation, cleaning, and troubleshooting for models URY3055AS, URY3655AS, and URY4855AS.



Grandeur 36-Inch 6-Burner Gas Range - Grand Assurance Warranty Information

Details the Grandeur Grand Assurance Warranty for 36-inch 6-burner gas ranges, covering 2-Year Parts & Labor and 10-Year Limited Warranty. Register online for peace of mind.



Prop 65 Warning for Grandeur Gas Ranges

California Proposition 65 warning for Grandeur gas ranges, detailing potential exposure to lead and its health risks. Information provided for Grandeur URY3655AS and URY3055AS models.



Grandeur URY3655AS 36-Inch Freestanding Professional Gas Range - Specifications & Features

Explore the Grandeur URY3655AS, a 36-inch freestanding professional gas range featuring 6 high-powered sealed burners, a 5.2 cu. ft. oven, commercial convection fan, and durable cast-iron grates. Detailed specifications and features for this stainless steel appliance.



Bosma Aegis Lock Compatibility Guide

A comprehensive guide detailing the compatibility of the Bosma Aegis Lock with various deadbolt brands and models, door specifications, WiFi requirements, and mobile device support.