

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ProMaster](#) /

› [ProMaster Specialist Series SP528K Professional Tripod Kit with Head - Instruction Manual](#)

ProMaster SP528K

ProMaster Specialist Series SP528K Professional Tripod Kit with Head - Instruction Manual

Model: SP528K | Brand: ProMaster

1. INTRODUCTION

The ProMaster Specialist Series SP528K Professional Tripod Kit with Head is engineered for photographers demanding exceptional stability and precision. This heavy-duty and durable tripod provides a reliable platform for capturing high-quality images and videos. Its design prioritizes both robust performance and user-friendly operation, making it an ideal choice for various photographic endeavors. The included professional-grade head allows for smooth and precise adjustments, offering full control over camera positioning and composition. The tripod's construction ensures long-lasting performance, even in demanding shooting conditions.

2. SETUP

Follow these steps to correctly set up your ProMaster SP528K Tripod Kit:

- 1. Unfold the Tripod Legs:** Gently spread the tripod legs until they are fully extended or set to your desired angle. The leg angle selectors allow for multiple positions to adapt to uneven terrain.
- 2. Extend the Legs:** Loosen the leg locks on each section of the tripod legs. Extend each leg section to the desired height. Ensure all locks are securely tightened after adjustment to maintain stability.
- 3. Adjust the Center Column:** If additional height is needed, loosen the locking collar on the center column and carefully raise it. Tighten the collar firmly once the desired height is reached.
- 4. Attach the Ball Head:** The professional-grade ball head comes pre-attached. Ensure it is securely fastened to the center column.
- 5. Mount Your Camera:**
 - Locate the quick release plate on the ball head.
 - Attach the quick release plate to the bottom of your camera by screwing it into the camera's tripod socket. Ensure it is tightly secured.
 - Slide the camera with the attached quick release plate into the receiver on the ball head. Lock the plate securely using the designated lever or knob.



Figure 1: Close-up of the professional-grade ball head, showing adjustment knobs and quick release plate mechanism.



Figure 2: Detail of the tripod leg locks and feet, illustrating the robust construction for stability.

3. OPERATING THE TRIPOD

The ProMaster SP528K Tripod Kit offers versatile adjustments for various shooting scenarios:

- **Ball Head Adjustments:** Use the main locking knob on the ball head to control the movement of your camera. Loosen it to adjust the camera's angle (tilt, pan, and rotation) and tighten it firmly to secure the position. Some ball heads may include a separate friction control knob for finer adjustments.
- **Panning:** For smooth horizontal movements, ensure the panning lock (if available) is loosened while the main ball head lock is tightened. This allows the head to rotate horizontally without changing the camera's tilt.
- **Leg Angle Adjustment:** Each leg features an angle adjustment mechanism. Press the release button or lever at the top of each leg to change its angle. This is crucial for stability on uneven surfaces or for achieving low-angle shots.
- **Monopod Conversion (if applicable):** One of the tripod legs may be detachable for use as a monopod. Refer to the specific instructions for detaching and reattaching the monopod leg.



Figure 3: A photographer utilizing the ProMaster SP528K tripod on a rocky cliff, demonstrating its adaptability to challenging environments.



Figure 4: A camera mounted on the ProMaster SP528K tripod on a beach, highlighting its stability for outdoor photography.

4. MAINTENANCE

To ensure the longevity and optimal performance of your tripod, regular maintenance is recommended:

- **Cleaning:** After each use, especially in dusty or sandy environments, wipe down the tripod legs and head with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Lubrication:** Periodically check the leg locks and ball head mechanisms. If movement becomes stiff, apply a small amount of silicone-based lubricant to the moving parts. Avoid oil-based lubricants as they can attract dirt.
- **Storage:** Store the tripod in its carrying case in a cool, dry place away from extreme temperatures and humidity. Ensure all locks are slightly loosened during storage to prevent stress on the mechanisms.
- **Inspection:** Regularly inspect all screws, bolts, and moving parts for any signs of wear or damage. Tighten any loose fasteners.

5. TROUBLESHOOTING

If you encounter issues with your tripod, consider the following:

- **Ball Head Stiffness/Looseness:** If the ball head is difficult to adjust or does not hold position firmly, check the main locking knob and any friction control knobs. Ensure they are properly adjusted. Lubrication may also be required.
- **Quick Release Plate Sliding:** If the camera's shoe mount slides on the tripod head despite being tightened, ensure the quick release plate is correctly seated and fully locked into the ball head receiver. Verify that the screw attaching the plate to the camera is tight.
- **Leg Extension Issues:** If a leg extension is difficult to extend/retract or breaks, check for any obstructions or damage to the leg locks. Ensure they are clean and free of debris. Avoid forcing leg sections.
- **General Instability:** Ensure all leg sections are fully extended and all locks are securely tightened. Verify that the tripod is placed on a stable, level surface. Adjust leg angles as needed for optimal balance.

6. SPECIFICATIONS

Feature	Value
Product Dimensions	0.01 x 0.01 x 0.01 inches
Item Weight	6.69 pounds
Item Model Number	ProMaster SP528K
Brand	ProMaster
Color	black
Compatible Devices	Camera
Material	Aluminum

Feature	Value
Weight Limit	22 Pounds
Maximum Height	130 Centimeters
Tripod Head Type	Ball Heads
Minimum Height	18.4 Centimeters
Folded Size	19 5/8" / 49.8 cm

7. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact ProMaster customer service directly. Keep your purchase receipt as proof of purchase.

Visit the official ProMaster website for the most up-to-date contact information and support resources:

[ProMaster Store](#)