

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Westinghouse](#) /
- › [Westinghouse Cayuga 60-inch Ceiling Fan with LED Light Kit \(Model 7207700\) Instruction Manual](#)

## Westinghouse 7207700

# Westinghouse Cayuga 60-inch Ceiling Fan with LED Light Kit Instruction Manual

Model: 7207700

## INTRODUCTION

---

Thank you for choosing the Westinghouse Cayuga 60-inch Ceiling Fan with LED Light Kit. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before beginning installation and retain them for future reference.

## IMPORTANT SAFETY INFORMATION

---

To reduce the risk of electric shock, fire, or personal injury, always follow these basic safety precautions:

- Read all instructions before installing the fan.
- Ensure the installation site is suitable for a ceiling fan and can support the fan's weight (approximately 23.4 lbs).
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Disconnect power at the main circuit breaker before installation or servicing.
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is in operation.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- Six Reversible Fan Blades (Rosewood/Light Maple finish)
- LED Light Kit with Opal Frosted Glass
- Two 8-watt (60-watt equivalent) Dimmable T7 LED Bulbs (E26 base)
- Remote Control with Wall Mount
- Down Rod

- Mounting Hardware and Wiring Connectors



Image: Westinghouse Cayuga 60-inch Ceiling Fan with LED Light Kit in Brushed Nickel, featuring light wood blades and an integrated LED light.

## SETUP AND INSTALLATION

---

Professional installation is recommended for optimal safety and performance. Ensure power is disconnected at the circuit breaker before proceeding.

### 1. Mounting the Fan

1. Secure the mounting bracket to the ceiling outlet box. The outlet box must be securely fastened to the building structure.
2. Attach the down rod to the fan motor assembly.
3. Carefully lift the fan assembly and hang it from the mounting bracket.

### 2. Electrical Wiring

4. Connect the fan's electrical wires to the household wiring according to the provided wiring diagram. Ensure all connections are secure.
5. Install the remote control receiver into the fan's canopy, ensuring the antenna is positioned for optimal signal reception.

### 3. Attaching Blades and Light Kit

6. Attach the fan blades to the motor housing using the provided screws. The blades are reversible, offering a choice between rosewood and light maple finishes.
7. Install the LED light kit to the bottom of the fan motor assembly.
8. Insert the two 8-watt T7 LED bulbs into the light kit sockets.
9. Secure the opal frosted glass shade to the light kit.



Image: The Westinghouse Cayuga 60-inch ceiling fan with light wood blades and LED light kit, installed in a room setting.





Image: A close-up view of the Westinghouse Cayuga fan, highlighting the brushed nickel finish and the dark wood side of the reversible blades.

## OPERATING INSTRUCTIONS

---

### Remote Control Functions

Your Westinghouse Cayuga ceiling fan is operated using the included remote control. Ensure the remote has working batteries.

- **OFF:** Turns the fan off.
- **HIGH:** Sets the fan speed to high.
- **MED:** Sets the fan speed to medium.
- **M.LOW:** Sets the fan speed to medium-low.
- **LOW:** Sets the fan speed to low.
- **LIGHT:** Toggles the light on/off. Press and hold to dim the light.



Image: The remote control for the Westinghouse Cayuga ceiling fan, showing buttons for fan speed control (Off, High, Med, M.Low, Low) and light control.

Video: An overview of the Westinghouse Cayuga ceiling fan, demonstrating its aesthetic appeal and functionality in a living room setting.

Video: A brief demonstration highlighting the quiet operation of the Westinghouse Cayuga ceiling fan.

Video: A user's perspective on the Westinghouse Cayuga ceiling fan, showcasing its modern design and features.

## Seasonal Operation (Reverse Function)

Most ceiling fans include a reverse switch (often located on the motor housing) to change the direction of blade rotation. This allows for seasonal optimization:

- **Summer Mode (Counter-clockwise):** Creates a downward breeze, providing a cooling effect.
- **Winter Mode (Clockwise):** Draws warm air up towards the ceiling and circulates it down the walls, helping to redistribute heat.

Consult the specific diagram in your fan's physical manual for the exact location of the reverse switch.

## CARE AND MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** The LED light kit uses two 8-watt T7 LED bulbs with an E26 base. Ensure power is off before replacing bulbs.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan blades and mounting hardware.

## TROUBLESHOOTING GUIDE

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control not paired or faulty.	Check circuit breaker; Verify all wire connections are secure; Re-pair remote control or replace batteries.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting hardware.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting hardware is secure.
Light does not work	Bulbs loose or burnt out; Wiring issue in light kit.	Check and tighten bulbs; Replace bulbs if necessary; Inspect light kit wiring.
Remote control not working	Dead batteries; Remote not paired; Obstruction between remote and receiver.	Replace remote batteries; Re-pair remote with receiver; Ensure clear line of sight.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Westinghouse
Model Number	7207700
Model Name	Cayuga
Color	Brushed Nickel
Style	Remote Control
Blade Size	60 inches
Blade Finish	Reversible (Rosewood/Light Maple)
Light Source	LED
Bulb Type	2 x 8-watt (60-watt equivalent) Dimmable T7 LED

Feature	Detail
Bulb Base	E26
Brightness	1600 lumen
Control Method	Remote Control
Mount Type	Down Rod Only
Voltage	120 Volts
Item Weight	23.4 Pounds
Required Assembly	Yes
Certification	ETL

## WARRANTY AND CUSTOMER SUPPORT

---

Westinghouse provides a limited lifetime motor warranty and a two-year warranty on all other parts for this ceiling fan. For detailed warranty information or technical assistance, please refer to the warranty card included with your product or visit the official Westinghouse website.

For customer support, please contact Westinghouse directly through their official channels.