Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- myTouchSmart /
- Jasco myTouchSmart Simple Set Indoor Plug-in Digital Timer User Manual

myTouchSmart 36253

myTouchSmart Simple Set Indoor Plug-in Digital Timer

Model: 36253 | Brand: myTouchSmart

PRODUCT OVERVIEW

The myTouchSmart Simple Set Indoor Plug-in Digital Timer is designed to automate your indoor lighting and electronics, offering convenience and energy savings. Its slim bar design ensures it does not block the second outlet, making it ideal for various applications.

Key Features:

- Save time, money, and energy by scheduling indoor lights, lamps, small appliances, electronics, and seasonal lighting.
- Easy setup: simply set current time and custom ON/OFF times.
- Features one (1) polarized outlet and a digital display.
- Compatible with CFL, LED, incandescent, and halogen light sources, including dimmable LED and CFL bulbs.
- · Space-saving slim bar design prevents blocking the second outlet.
- Backup battery preserves settings during power outages or disconnections.



Figure 1: The myTouchSmart timer can be used to schedule indoor lights or other devices such as lamps, small appliances, electronics, and seasonal decor.

SETUP INSTRUCTIONS

Follow these steps to set up your myTouchSmart Digital Timer:

- 1. Plug In: Insert the timer into a standard 125V wall outlet.
- 2. **Set Current Time:** Use the "clock" button and arrow buttons (up/down) to set the current time. The digital display will show the time.
- 3. **Program ON/OFF Cycles:** The timer supports up to four programmable ON/OFF cycles. Use the "set" button and "my on time" / "my off time" buttons to program your desired schedules.




Figure 2: Simple setup guide for the timer, illustrating how to scroll to set the time and program custom ON/OFF times.

OPERATING INSTRUCTIONS

The myTouchSmart Digital Timer allows for easy automation of your devices. Understand its controls and programming options:

- **Digital Display:** Shows current time, program status (AUTO), and AM/PM indicator.
- "my on time" / "my off time" Buttons: These buttons are used to set specific ON and OFF times for your connected devices. The timer supports two custom daily ON/OFF programs.
- Up/Down Arrow Buttons: Used to scroll through time settings and adjust values during programming.
- "on/off" Button: Manually overrides the programmed schedule to turn the connected device ON or OFF.




Figure 3: Detailed view of the timer's controls, including the digital display, custom ON/OFF time buttons, and scroll buttons.

2 Custom Daily ON/OFF Times



Program 1





Timer is set to turn **ON** at 6:00 A.M. and turn **OFF** at 9:00 A.M.

Program 2



Timer is set to turn **ON** at 4:00 P.M. and turn **OFF** at 10:00 P.M.

Figure 4: Example of two custom daily ON/OFF programs, demonstrating how the timer can be set to turn devices on and off at specific times.

MAINTENANCE

The myTouchSmart Digital Timer requires minimal maintenance. Keep the device clean and dry. Do not immerse in water or expose to extreme temperatures.

The built-in backup battery ensures your settings are retained during power outages. No user replacement of the battery is required.

TROUBLESHOOTING

If you encounter issues with your timer, consider the following:

- Timer not turning ON/OFF: Ensure the timer is securely plugged into a working outlet and the connected device is properly plugged into the timer. Verify that the programmed ON/OFF times are correct and the timer is in "AUTO" mode.
- **Display is blank:** Check the power connection. The backup battery should maintain settings, but the display requires main power to operate.
- Settings lost after power outage: While a backup battery is present, prolonged power outages or a depleted backup battery might cause settings to reset. Reprogram the timer as needed.

For further assistance, refer to the official user manual or contact customer support.

SPECIFICATIONS

Attribute	Value
Color	White
Brand	My Touchsmart
Product Dimensions	1.2"D x 2.5"W x 2"H
Item Weight	0.17 Pounds (2.72 ounces)
Number of settings	4
UPC	030878362535
Screen Size	2 Inches
Manufacturer	Jasco Products Company, LLC
Item model number	36253
Date First Available	March 16, 2017
Electrical Ratings	125V 50/60Hz, 15A 1875W General Purpose/Resistive, 5A 625W Tungsten, 1/2HP

PRODUCT VIDEOS

Your browser does not support the video tag.

Video 1: Product Overview Video. This video provides a brief introduction to the myTouchSmart Digital Bar Outlet Timer, highlighting its features and ease of use.

WARRANTY AND SUPPORT

This product comes with a **1-year limited warranty** from Jasco Products Company, LLC. For detailed information, please refer to the official User Manual:

Download User Manual (PDF)

For customer support, please contact Jasco Products Company, LLC directly.

Related Documents - 36253



myTouchSmart Simple Set Plug-In Timer: Setup and Programming Guide

A concise guide to setting up and programming the myTouchSmart Simple Set Plug-In Timer for automated control of lights and appliances. Learn how to set on/off times, understand features, and follow safety instructions.



myTouchSmart Simple Set Plug-In Timer - User Guide

Instructions and specifications for the myTouchSmart Simple Set Plug-In Timer, an outdoor/indoor digital timer for automating lights and appliances. Learn how to mount, set the time, program on/off times, and understand safety warnings.



myTouchSmart Simple Set Indoor Plug-In Digital Timer - User Guide

Learn how to set up and program your myTouchSmart Simple Set Indoor Plug-In Digital Timer for automated lighting control. Includes instructions for custom schedules, preset times, and countdown features.



myTouchSmart SunSmart Plug-In Timer User Manual

User manual for the myTouchSmart SunSmart Plug-In Timer, detailing setup, programming options, and specifications for indoor digital timing. Learn how to automate your indoor lighting and appliances.



myTouchSmart In-Wall Digital Timer 26893 User Manual & Installation Guide

Comprehensive user manual and installation guide for the myTouchSmart In-Wall Digital Timer (Model 26893). Learn how to safely install and use this programmable timer for indoor/outdoor lights and fans.



myTouchSmart Wi-Fi Smart Devices Quick Start Guide and App Setup

Comprehensive guide to setting up myTouchSmart Wi-Fi smart switches, outlets, and plugs using the myTS app, including voice assistant integration with Alexa and Google Assistant.