Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney B06XS99HCG

Bambi Blu-ray User Manual

Your comprehensive guide to using the timeless classic.

Introduction

This manual provides instructions for the proper use and care of your Bambi Blu-ray disc. Please read thoroughly to ensure optimal viewing experience and to preserve the quality of your disc.
The Bambi Blu-ray disc (Model: B06XS99HCG) contains the animated film*Bambi*, originally released in 1942, and is presented in high definition as part of the Walt Disney Signature Collection.

Product Overview



Figure 1: Front cover of the Bambi Blu-ray disc case. This image displays the main characters Bambi, Thumper, and Flower, along with the Disney logo and indications of Blu-ray, DVD, and Digital HD formats included. The Walt Disney Signature Collection seal is also visible.



Figure 2: Back cover of the Bambi Blu-ray disc case. This view provides information on the included bonus features, such as "Bambi: Inside Walt's Story Meetings" and "The Bambi Effect," along with technical specifications like aspect ratio, audio formats, and subtitle options. A barcode with the number 0786936853582 is also visible.

Official Product Videos

No official product videos from the seller are available for embedding in this manual.

Setup

1. **Unpack the Disc:** Carefully remove the Bambi Blu-ray disc from its packaging. Hold the disc by its edges to avoid touching the playback surface.
2. **Prepare Your Blu-ray Player:** Ensure your Blu-ray player is connected to your television or display device and a power source. Refer to your Blu-ray player's manual for specific connection instructions.
3. **Insert the Disc:** Open the disc tray or slot on your Blu-ray player. Gently place the Bambi Blu-ray disc into the tray with the label side facing up. Close the disc tray or allow the player to pull the disc in.
4. **Select Input:** Switch your television or display device to the correct input source (e.g., HDMI 1, HDMI 2) that your Blu-ray player is connected to.

Operating Instructions

Playing the Movie

1. **Automatic Playback:** Most Blu-ray players will automatically load the disc and display the main menu or begin playback of the movie.
2. **Navigating Menus:** Use your Blu-ray player's remote control (directional arrows, Enter/OK button) to navigate the on-screen menu. Select "Play Movie" to start the film.
3. **Language Selection:** If prompted, select your preferred audio language (English, French, Spanish) and subtitle language (English, French, Spanish) from the disc menu.

Accessing Special Features

The Bambi Blu-ray disc includes various bonus features. These can typically be accessed from the main menu under a section like "Special Features," "Bonus Content," or "Extras."

- **Studio Stories: Bambi Walt Disney's Recordings:** Insights into the production.
- **Deleted Scenes:** Explore scenes not included in the final film.
- **The Bambi Effect:** Learn how Disney artists were inspired by nature and technology.
- **Inside Walt's Story Meetings - Extended Edition:**Deeper dive into the creative process.
- **Bambi Fawn Facts - Forest Animal Fun Facts:**Educational content about forest animals.
- **Short Film: Oswald the Lucky Rabbit in Africa Before Dark:**An additional animated short.

Maintenance and Care

- **Handling:** Always hold the disc by its outer edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth (e.g., microfiber cloth) from the center outwards in a straight line. Do not wipe in circular motions. Do not use abrasive cleaners or solvents.
- **Storage:** Store the disc in its original case when not in use to protect it from dust, scratches, and direct sunlight. Keep discs away from extreme temperatures and humidity.
- **Avoid Damage:** Do not bend the disc, apply stickers, or write on the playback surface with permanent markers.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty or scratched; incorrect disc format; player malfunction.	Clean the disc carefully. Ensure your player supports Blu-ray discs. Try another Blu-ray disc to check player functionality.
No audio or video during playback.	Incorrect audio/video settings; loose cables; TV input not selected correctly.	Check HDMI/audio cables. Verify TV input. Adjust audio settings on your player or TV.
Skipping or freezing during playback.	Disc surface damage; dust on player lens.	Clean the disc. If issues persist, the disc may be damaged. Consider a lens cleaning disc for your player.

Specifications

- **ASIN:** B06XS99HCG
- **Format:** Blu-ray
- **Aspect Ratio:** 1.33:1
- **MPAA Rating:** G (General Audience)
- **Run Time:** 1 hour and 10 minutes
- **Release Date:** June 6, 2017
- **Actors:** Ann Gillis, Donnie Dugan, Hardy Albright, Peter Behn, Tim Davis
- **Director:** David Hand
- **Dubbed Languages:** French, Spanish
- **Subtitles:** English, French, Spanish
- **Audio Languages:** English (DTS-HD High Res Audio), French (Dolby Digital 5.1), Spanish (Dolby Digital 5.1)
- **Number of Discs:** 2
- **Product Dimensions:** 0.7 x 7.5 x 5.4 inches; 3.2 ounces
- **Studio:** Sony Pictures Home Entertainment

Warranty and Support

This Blu-ray disc itself does not typically come with a separate manufacturer's warranty beyond standard consumer rights for defective goods. Any warranty or support related to playback issues would generally pertain to your Blu-ray player or television.
For technical support regarding your Blu-ray player, please refer to the manufacturer's documentation that came with your device.
For information on the Walt Disney Signature Collection or other Disney products, please visit the official Disney website.

Additional Resources

For more details about the film Bambi, you may visit:

- Bambi Blu-ray Product Page on Amazon
- Hardy Albright (Actor) on Amazon
- David Hand (Director) on Amazon

© 2024 Disney. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XS99HCG

More documents and user manuals: **https://manuals.plus/**